


Panasonic[®]

Operating Instructions

PTZ Network Camera

Model No. PM-VP4ULVR-W



Before attempting to connect or operate this product, please read these instructions carefully and save this manual for future use

About This Manual

- ▶ This manual is provided for user reference only, without legal restraint.
- ▶ This manual is available for many models. Some functions introduced in the manual may be not available for some models. Please take the real models as the standard.
- ▶ This content of this manual is subject to change without prior notice, and the updates will be added into the new version of this manual.
- ▶ This manual may contain several technically incorrect places or printing errors, please feel free to let us know. We will readily improve or update the procedures described in the manual.

Notes on Safety

- Please use the specified power supply to connect.
- Do not attempt to disassemble the camera; in order to prevent electric shock, do not remove screws or covers.
- There are no user-serviceable parts inside. Please contact the nearest service center as soon as possible if there is any failure.
- Avoid from incorrect operation, shock vibration, heavy pressing which can cause damage to the product.
- Do not use corrosive detergent to clean main body of the camera. If necessary, please use soft dry cloth to wipe dirt; for hard contamination, use neutral detergent. Any cleanser for high grade furniture is applicable.
- Avoid aiming the camera directly towards extremely bright objects, such as, sun, as this may damage the image sensor.
- Please follow the instructions to install the camera. Do not reverse the camera, or the reversing image will be received.
- Do not operate it in case temperature, humidity and power supply are beyond the limited stipulations.
- Keep away from heat sources such as radiators, heat registers, stove, etc.
- Do not expose the product to the direct airflow from an air conditioner. Otherwise, it may cause moisture condensation inside the clear dome due to temperature difference between internal and external of the dome camera.

Disclaimer

■ With regard to the product with internet access, the use of product shall be wholly at your own risks. Our company shall be irresponsible for abnormal operation, privacy leakage or other damages resulting from cyber attack, hacker attack, virus inspection, or other internet security risks; however, Our company will provide timely technical support if necessary.

■ Surveillance laws vary from country to country. Check all laws in your local region before using this product for surveillance purposes. We shall not take the responsibility for any consequences resulting from illegal operations.

Regulatory Information

FCC Information

1. FCC compliance

The products have been tested and found in compliance with the council FCC rules and regulations part 15 subpart B. These limits are designed to provide reasonable protection against harmful interference. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. The user will be required to correct the interface at his own expense in case the harmful interference occurs.

2. FCC conditions:

Operation of this product is subject the following two conditions: (1) this device may not cause harmful interface, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE Information



The products have been manufactured to comply with the following directives.
EMC Directive 2014/30/EU

RoHS

The products have been designed and manufactured in accordance with Directive EU RoHS Directive 2011/65/EU and its amendment Directive EU 2015/863 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.



2012/19/EU (WEEE directive): The Directive on waste electrical and electronic equipment (WEEE Directive). To improve the environmental management of WEEE, the improvement of collection, treatment and recycling of electronics at the end of their life is essential. Therefore, the product marked with this symbol must be disposed of in a responsible manner.

Directive 94/62/EC: The Directive aims at the management of packaging and packaging waste and environmental protection. The packaging and packaging waste of the product in this manual refers to must be disposed of at designated collection points for proper recycling and environmental protection.

REACH(EC1907/2006): REACH concerns the Registration, Evaluation, Authorization and Restriction of Chemicals, which aims to ensure a high level of protection of human health and the environment through better and earlier identification of the intrinsic properties of chemical substances. The product in this manual refers to conforms to the rules and regulations of REACH. For more information of REACH, please refer to DG GROWTH or ECHA websites.

Contents

1	Network Connection.....	1
1.1	LAN	1
1.1.1	Access through Panasonic IP Manager Tool	1
1.1.2	Directly Access through IE	3
1.2	WAN	4
2	Live View	7
3	Camera Configuration	9
3.1	System Configuration.....	9
3.1.1	Basic Information	9
3.1.2	Date and Time Configuration	9
3.1.3	Local Config.....	10
3.1.4	Storage.....	11
3.2	Image Configuration	13
3.2.1	Display Settings.....	13
3.2.2	Video / Audio Configuration	16
3.2.3	OSD Configuration	17
3.2.4	Video Mask.....	18
3.3	PTZ Configuration	19
3.3.1	PTZ and Password Setting.....	19
3.3.2	Restore	20
3.3.3	PTZ Function	20
3.4	Alarm Configuration	25
3.4.1	Motion Detection	25
3.4.2	Exception Alarm	27
3.4.3	Alarm Input.....	29
3.4.4	Alarm Out	30
3.4.5	Alarm Server.....	31
3.4.6	Audio Alarm	32
3.4.7	Light Alarm	33
3.4.8	Smart Tracking	33
3.5	Event Configuration	35
3.5.1	Video Exception	36
3.5.2	Line Crossing Detection	37
3.5.3	Region Intrusion	40
3.5.4	Region Entrance.....	42
3.5.5	Region Exiting	42
3.5.6	Target Counting	42
3.5.7	Face Comparison	45
3.6	Network Configuration	50
3.6.1	TCP/IPv4	50
3.6.2	Port	51

3.6.3	Server Configuration.....	52
3.6.4	Onvif.....	52
3.6.5	DDNS Configuration	53
3.6.6	SNMP	54
3.6.7	802.1X	55
3.6.8	RTSP.....	56
3.6.9	RTMP	57
3.6.10	UPnP.....	57
3.6.11	E-mail	58
3.6.12	FTP	58
3.6.13	HTTP POST	60
3.6.14	HTTPS	61
3.6.15	QoS	62
3.7	Security Configuration	62
3.7.1	User Configuration	62
3.7.2	Online Video User	64
3.7.3	Block and Allow Lists	65
3.7.4	Security Management	65
3.8	Maintenance.....	66
3.8.1	Backup & Restore.....	66
3.8.2	Reboot Device	67
3.8.3	Upgrade	67
3.8.4	Log.....	67
4	Playback	69
4.1	Image Search.....	69
4.2	Video Search.....	71
4.2.1	Local Video Search.....	71
4.2.2	SD Card Video Search	72
5	Face Match Result Search.....	74
6	Q & A	75
Appendix	Preset Description.....	77

1 Network Connection

System Requirement

For proper operating the product, the following requirements should be met for your computer.

Operating System: Windows 7 Home basic or higher

CPU: 2.0GHz or higher

RAM: 1G or higher

Display: 1920*1080 resolution or higher (recommended)

Web browser: IE (plug-in required)/ Firefox/Edge/Safari/Google Chrome

It is recommended to use the latest version of these web browsers.

The menu display and operation of the camera may be slightly different by using the browser with plug-in or without plug-in. Installing the applicable plug-in will display more functions of the camera.

Connect IP-Cam via LAN or WAN. Here only take IE browser for example. The details are as follows:

1.1 LAN

In LAN, there are two ways to access the device: 1. access through Panasonic IP Manager Tool; 2. direct access through IE browser.


1.1.1 Access through Panasonic IP Manager Tool

Network connection:



① Make sure the PC and device are connected to the LAN and the Panasonic IP Manager Tool is installed in the PC.

② Double click the Panasonic IP Manager Tool icon on the desktop to run this software as shown below:



The default IP address of the camera is **192.168.0.10**.

③ Double click the IP address and then the system will pop up the IE browser to connect the device. After you read the privacy statement, check and click “Already Read”. Then activate the device.

Device Activation

User Name

☒ Activate Onvif User

New Password


8~16 characters; Numbers, special characters, upper case letters and lower case letters must be included.

Confirm Password

Please self-define the password of admin according to the tip.

If “Activate Onvif User” is enabled, the ONVIF user can be activated simultaneously. When you connect the camera through the ONVIF protocol in the third-party platform, you can use the default username and the password set above to connect.

After that, follow directions to download, install and run the Active X control if prompted. Re-connect your camera via IE browser and then a login box will appear.



Please enter the user name (admin) and password.

The security questions should be set after you click “Login” button. It is very important for you to reset your password. Please remember these answers.

Safety Question	
Security Question1	
Answer	
Security Question2	
Answer	
Security Question3	
Answer	
OK	

1.1.2 Directly Access through IE

The default network settings are as shown below:

IP address: 192.168.0.10


Subnet Mask: 255.255.255.0

Gateway: 192.168.0.1

HTTP: 80


Data port: 9008

You may use the above default settings when you log in the camera for the first time. You may directly connect the camera to the computer through network cable.




- ① Set the IP address of the PC and make sure the network segment should be as the same as

the default settings of the IP camera. Open the network and share center. Click “Local Area Connection” to pop up the following window.




Select “Properties” and then select internet protocol according to the actual situation (for example: IPv4). Next, click “Properties” to set the network of the PC.



- ② Open the IE browser and enter the default address of IP-CAM and confirm.
- ③ Follow directions to download and install the plug-in.
- ④ Enter the default username and password and then enter to view.

1.2 WAN

- Access through the router or virtual server



- ① Make sure the camera is well connected via LAN and then log in the camera via LAN and go to **Config → Network → Port** menu to set the port number.

HTTP Port	80
HTTPS Port	443
Data Port	9008
RTSP Port	554

- ② Go to **Config → Network → TCP/IPv4** menu to modify the IP address.

IPv4	IPv6	PPPoE Config	IP Change Notification Config
☐ Obtain an IP address automatically			
☒ Use the following IP address			
IP Address	192.168.226.201	Test	
Subnet Mask	255.255.255.0		
Gateway	192.168.226.1		
Preferred DNS Server	210.21.196.6		
Alternate DNS Server	8.8.8.8		

- ③ Go to the router's management interface through IE browser to forward the IP address and port of the camera in the "Virtual Server".


Port Range					
Application	Start	End	Protocol	IP Address	Enable
1	9007	to 9008	Both	192.168.1.201	☒
2	80	to 81	Both	192.168.1.201	☒
3	10000	to 10001	Both	192.168.1.166	☐
4	21000	to 21001	Both	192.168.1.166	☐

Router Setup

④ Open the IE browser and enter its WAN IP and http port to access.

➤ **Access through PPPoE dial-up**

Network connection



You may access the camera through PPPoE auto dial-up. The setting steps are as follow:

- ① Go to **Config → Network → Port** menu to set the port number.
- ② Go to **Config → Network → TCP/IPv4** menu. Check “PPPoE Config” and then enter the user name and password which you can get from your internet service provider.

IP Config	PPPoE Config	IP change notification Config
☐ Enable		
User Name		
Password		

- ③ Go to **Config → Network → DDNS** menu. Before you configure the DDNS, please apply for a domain name first. Please refer to [DDNS Configuration](#) for detail information.
- ④ Open the IE browser and enter the domain name and http port to access.

➤ **Access through static IP**

Network connection




The setting steps are as follow:

- ① Go to **Config → Network → Port** menu to set the port number.
- ② Go to **Config → Network → TCP/IPv4** menu to set the IP address. Check “Use the following IP address” and then enter the static IP address and other parameters.
- ③ Open the IE browser and enter its WAN IP and http port to access.

2 Live View

After you log in, you will see the following window.



Plug-in free live view: when the main stream is set over 1080P, only the sub stream or third stream tab can be displayed on the above interface by default.
The descriptions of the icon on the live view interface are as follows:

Icon	Description	Icon	Description
	Original size		Rule information display
	Fit correct scale		Color abnormal indicator
	Auto (fill the window)		Abnormal clarity indicator
	Full screen		Scene change indicator
	Start/stop live view		Line crossing indicator
	Start/stop two-way audio		Sensor alarm indicator (only some models support)
	Enable/disable audio		Intrusion indicator
	Snapshot		Motion alarm indicator
	Start/stop local recording		Region entrance indicator

Icon	Description	Icon	Description
	Zoom in		Region exiting indicator
	Zoom out		Face detection indicator
	PTZ control		Target counting indicator
	Face Detection		SD card recording indicator

: Move the cursor to view the live image in all direction after you click this button. Additionally, hold and drag the left mouse button to zoom in the live image.

- Those smart alarm indicators will flash only when the camera supports those functions and the corresponding events are enabled.
- In full screen mode, double click on the mouse or press the ESC key on the keyboard to exit.
- Plug-in free live view: two-way audio and local recording are not supported and the preview mode switch (real-time/balanced/fluent mode) is not available too.

Click  to show PTZ control panel. In the live view interface, you can view the image from every direction by controlling PTZ panel.

The descriptions of the control panel are as follows:

Icon	Description	Icon	Description
	Move upper left direction		Move upper right direction
	Move up		Stop movement
	Move left		Move right
	Move lower left direction		Move lower right direction
	Move upper left direction		Speed adjustment
	Zoom out		Zoom in
	Focus -		Focus +
	Iris -		Iris +
	Auto scan		Wiper (only some models support)
	Light		Radom scan
	Group scan		Preset
	Cruise		Trace

Select preset and click  to call the preset. Select and set the preset and then click  to save the position of the preset. Select the set preset and click  to delete it. Select cruise and click  to start cruise.

3 Camera Configuration

In the Webcam client, choose “Config” to go to the configuration interface.

Note: Wherever applicable, click “Save” to save the settings.

3.1 System Configuration

The “System configuration” includes four sub-menus: Basic Information, Date and Time, Local Config and SD Card.

3.1.1 Basic Information

In the Basic Information interface, you can check the relative information of the device.

Device Name	
Product Model	IPC
Brand	Customer
Software Version	5.1.1.0(39732)
Software Build Date	2022-11-18
Onvif Version	22.06
OCX Version	2.2.7.17
MAC	00:18:ae:c6:bf:84
PTZ Version	V1.8.11(2022/5/26)
Camera Type	
About this machine	View
Privacy Statement	View

Some versions may support device ID and QR code. Having been enabled P2P (*Config → Network Configuration → [P2P](#)*), the network camera can be quickly added to mobile surveillance client, by scanning the QR code or entering device ID.

3.1.2 Date and Time Configuration

Go to *Config → System → Date and Time*. Please refer to the following interface.

Zone		Date and Time	
Time Zone:	GMT+08 (Beijing, Hong Kong, Shanghai, Taipei)		
☐ DST			
☒ Auto DST			
☐ Manual DST			
Start Time	May	First	Tuesday 15 Hour
End Time	August	First	Tuesday 15 Hour
Time Offset	30 Minutes		

Select the time zone and DST as required.

Note: The time zone of the camera and the computer must be the same. It is recommended to modify the time zone of the camera according to the time zone of the computer. If the time zone of the computer is modified, the current web client needs to be closed. Then re-open it and log in again.

Click the “Date and Time” tab to set the time mode and time format.

Zone		Date and Time	
Time Mode:			
☒ Synchronize with NTP server			
NTP server:		time.windows.com	Update period: 1440 Minutes
☐ Synchronize with computer time			
Date		2021-09-01	Time 17:37:36
☐ Set manually			
		2021-09-01 09:37:32	
Time Format	24-Hour		
Save			

3.1.3 Local Config

Go to **Config**→**System**→**Local Config** to set up the storage path of captured pictures and recorded videos on the local PC. There is also an option to enable or disable the bitrate display in the recorded files.

Picture Path	C:\Program Files\NetAIIPCcamera	Browse
Record Path	C:\Program Files\NetAIIPCcamera	Browse
Video Audio Settings	☐ Open ☒ Close	
Show Bitrate	☐ Open ☒ Close	
Local Smart Snapshot Storage	☐ Open ☒ Close	

Additionally, “Local smart snapshot storage” can be enabled or disabled here. If enabled, the captured pictures triggered by smart events (like line crossing detection, region intrusion, etc.) will be saved to the local PC.

3.1.4 Storage

Go to *Config* → *System* → *Storage* to go to the interface as shown below.

Management	Record	Snapshot
Total picture capacity	11933 MB	
Picture remaining space	0 MB	
Total recording capacity	47680 MB	
Record remaining space	0 MB	
State	Normal	
Snapshot Quota	20	%
Video Quota	80	%
Changes in the quota ratio need to be formatted before they become effective.		
EjectFormat		

- SD Card Management

Click “Format” to format the SD card. All data will be cleared by clicking this button. Click “Eject” to stop writing data to SD card. Then the SD card can be ejected safely.

Snapshot Quota: Set the capacity proportion of captured pictures on the SD card.

Video Quota: Set the capacity proportion of record files on the SD card.

- Schedule Recording Settings

1. Go to *Config* → *System* → *Storage* → *Record* to go to the interface as shown below.

Management	Record	Snapshot
Record Parameters		
Record Stream	Main stream	
Pre Record Time	No Pre Record (H264,H265,MJPEG)	
Cycle Write	Yes	
Timing		
☒ Enable Schedule Record		

2. Set record stream, pre-record time, cycle writing.

Pre Record Time: Set the time to record before the actual recording begins.

3. Set schedule recording. Check “Enable Schedule Record” and set the schedule.

☐ Erase ☒ Add

Week Schedule

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Sun.	00:00-24:00																								
	Manual Input																								
Mon.	00:00-24:00																								
	Manual Input																								
Tue.	00:00-24:00																								
	Manual Input																								
Wed.	00:00-24:00																								
	Manual Input																								
Thu.	00:00-24:00																								
	Manual Input																								
Fri.	00:00-24:00																								
	Manual Input																								
Sat.	00:00-24:00																								
	Manual Input																								

Holiday Schedule

Date

09-01

+
-

0

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

00:00-24:00
Manual Input

Save

Weekly schedule

Set the alarm time from Monday to Sunday for a single week. Each day is divided in one hour increments. Green means scheduled. Blank means unscheduled.

“Add”: Add the schedule for a special day. Drag the mouse to set the time on the timeline.

“Erase”: Delete the schedule. Drag the mouse to erase the time on the timeline.

Manual Input: Click it for a specific day to enter specific start and end times. This adds more granularities (minutes).

Day schedule

Set the alarm time for alarm a special day, such as a holiday.

Note: Holiday schedule takes priority over weekly schedule.

● Snapshot Settings

Go to **Config** → **System** → **Storage** → **Snapshot** to go to the interface as shown below.

Management	Record	Snapshot
Snapshot Parameters		
Image Format	JPEG ▼	
Resolution	704x480 ▼	
Image Quality	Low ▼	
Event Trigger		
Snapshot Interval	1	Second
Snapshot Quantity	5	
Timing		
☒ Enable Timing Snapshot		
Snapshot Interval	5	Second

Set the format, resolution and quality of the image saved on the SD card and the snapshot interval and quantity and the timing snapshot here.

Snapshot Quantity: The number you set here is the maximum quantity of snapshots. The actual quantity of snapshots may be less than this number. Supposing the occurrence time of an alarm event is less than the time of capturing pictures, the actual quantity of snapshots is less than the set quantity of snapshots.

Timing Snapshot: Enable timing snapshot first and then set the snapshot interval and schedule. The setup steps of schedule are the same as the schedule recording (See [Schedule Recording](#)).

3.2 Image Configuration

3.2.1 Display Settings

Go to **Image→Display** interface as shown below. The image's brightness, contrast, hue and saturation and so on for common, day and night mode can be set up separately. The image effect can be quickly seen by switching the configuration file.

Note: The camera parameters of different models may be slightly different. The following picture and descriptions are for reference only.

Camera Parameters

Profile Management

2023/02/14 14:34:23



Video Adjustment

Frequency

50HZ

Infra-red Mode

Auto

Image Mirror

☐ Open
 ☒ Close

Image Flip

☐ Open
 ☒ Close

Focus Limit

1M

Zoom Display

☒

Zoom Speed

3

Scan Speed

10

Lens Initialization

Lens Initialization

Set North

North

Config File

Common

Brightness

50

Contrast

50

Hue

50

Saturation

50

Sharpness

☐

100

Noise Reduction

☐

100

Defog

☐

100

BLC

Off

Antiflicker

Off

White Balance

Auto

Day/Night Mode

Auto

Sensitivity

Mid

Smart IR

Auto

Exposure Mode

Auto

Gain Limit

50

Default

Revoke

Brightness: Set the brightness level of the camera's image.

Contrast: Set the color difference between the brightest and darkest parts.

Hue: Set the total color degree of the image.

Saturation: Set the degree of color purity. The purer the color, the brighter the image is.

Sharpness: Set the resolution level of the image plane and the sharpness level of the image edge.

Noise Reduction: Decrease the noise and make the image more thorough. Increasing the value will make the noise reduction effect better but it will reduce the image resolution.

Defog: Activating this function and setting an appropriate value as needed in foggy, dusty, smoggy, or rainy environment to get clear images.

Backlight Compensation (BLC):

- Off: disables the backlight compensation function. It is the default mode.
- HWDR: WDR can adjust the camera to provide a better image when there are both very bright and very dark areas simultaneously in the field of the view by lowering the brightness of the bright area and increasing the brightness of the dark area. Recording will be stopped for a few seconds while the mode is changing from non-WDR to WDR mode.

● HLC: lowers the brightness of the entire image by suppressing the brightness of the image's bright area and reducing the size of the halo area.

● BLC: If enabled, the auto exposure will activate according to the scene so that the object

of the image in the darkest area will be seen clearly.

Antiflicker:

- Off: disables the anti-flicker function. This is used mostly in outdoor installations.
- 50Hz: reduces flicker in 50Hz lighting conditions.
- 60Hz: reduces flicker in 60Hz lighting conditions.

White Balance: Adjust the color temperature according to the environment automatically.

Day/Night Mode: Choose “Auto”, “Day”, “Night” or “Timing”.

Smart IR: Choose “Auto”, “Manual” or “OFF”. This function can effectively avoid image overexposure so as to make the image more realistic.

Exposure Mode: Choose “Auto” or “Manual”. If manual is chosen, the digital shutter speed can be adjusted.

Gain Limit: The higher the value is, the brighter the image is.

Frequency: 50Hz and 60Hz can be optional.

Infra-red Mode: Choose “Auto”, “ON” or “OFF”.

Image Mirror: Turn the current video image horizontally.

Image Flip: Turn the current video image vertically.

Focus Limit: Set the nearest distance of focus. Options: 1m, 1.5m, 2m, 3m, 5m and 10m.

Zoom Display: If enabled, you will see the zoom magnification in the live image.

Zoom Speed: Adjust zoom speed. The range is from 1 to 3. The larger the value is, the faster the zoom speed is.

Scan Speed: Adjust scan speed. The range is from 1 to 20.

Lens Initialization: After enabling it, the camera lens will restore to the factory default settings.

Set North:

- Choose a location by clicking the direction button in the live view interface. Then click “North” to save the setting.
- The horizontal angle will treat the north position as a reference; otherwise it will treat the horizontal origin as a reference to display the clockwise rotation angle of the dome.
- The vertical PTZ will treat its highest point as a reference (when the camera is parallel with the horizontal ground) to show the included angle between the camera and the horizontal ground.

Schedule Settings of Image Parameters:

Click the “Schedule” tab as shown below.

Camera Parameters	Schedule	
Schedule	Full Time	▼
Config File	Common	▼

Set full time schedule for common, auto mode and specified time schedule for day and night. Choose “Timing” in the drop-down box of schedule as shown below.

Schedule: Timing

Time Range: 0:00 4:00 8:00 12:00 16:00 20:00 24:00

Day Night

Save

Drag “” icons to set the time of day and night. Blue means day time and blank means night time. If the current mode of camera parameters is set to schedule, the image configuration mode will automatically switch between day and night according to the schedule.

3.2.2 Video / Audio Configuration

Go to **Image**→**Video / Audio** interface as shown below. In this interface, set the resolution, frame rate, bitrate type, video quality and so on subject to the actual network condition.

Index	Stream	Resolution	Frame	Bitrate Type	Bitrate(Kbps)	Video	I Frame	Video	Profile
1	Main stream	1920x1080	25	VBR	3072	Higher	50	H265	High Profile
2	Sub stream	1280x720	25	VBR	1024	Higher	50	H265	High Profile
3	Third stream	704x576	25	CBR	512	Higher	50	H265	High Profile

Send Snapshot: Main stream Size: (2560x1440)

☐ Video encode slice split

☐ Watermark (H264 , H265) Watermark content:

Save

Three video streams can be adjustable.

Resolution: The size of image.

Frame rate: The higher the frame rate, the video is smoother.

Bitrate type: CBR and VBR are optional. Bitrate is related to image quality. CBR means that no matter how much change is seen in the video scene, the compression bitrate will be kept constant. VBR means that the compression bitrate will be adjusted according to scene changes. For example, for scenes that do not have much movement, the bitrate will be kept at a lower value. This can help optimize the network bandwidth usage.

Bitrate: It can be adjusted when the mode is set to CBR. The higher the bitrate, the better the image quality will be.

Video Quality: It can be adjusted when the mode is set to VBR. The higher the image quality, the more bitrate will be required.

I Frame interval: It determines how many frames are allowed between a “group of pictures”. When a new scene begins in a video, until that scene ends, the entire group of frames (or pictures) can be considered as a group of pictures. If there is not much movement in the scene, setting the value higher than the frame rate is fine, potentially resulting in less bandwidth usage. However, if the value is set too high, and there is a high frequency of movement in the video, there is a risk of frame skipping.

Video Compression: MJPEG, H264+, H264, H265 or H265+ can be optional. MJPEG is not available for main stream. If H.265/H.265+is chosen, make sure the client system is able to decode H.265/H.265+. Compared to H.265, H.265+ saves more storage space with the same maximum bitrate in most scenes. Compared to H.264, H.265 reduces the transmission bitrate under the same resolution, frame rate and image quality.

Profile: For H.264. Baseline, main and high profiles are selectable.

Send Snapshot: Set the snapshot stream.

Video encode slice split: If this function is enabled, smooth image can be gotten even though using the low-performance PC.

Watermark: When playing back the local recorded video in the search interface, the watermark can be displayed. To enable it, check the watermark box and enter the watermark text.

Click the “Audio” tab to go to the interface as shown below.

Video

Audio

☒ Enable

Audio Encoding

G711A

Audio Type

LIN

LIN In Volume

75

Audio Out Volume

100

Save


Audio Encoding: G711A and G711U are selectable.

Audio Type: LIN or MIC is optional.

Note: only some models support audio input/output. If your PTZ camera doesn’t support this function, please skip the above-mentioned audio setup instruction.

3.2.3 OSD Configuration

Go to *Image* ➔ *OSD* interface as shown below.



The settings panel on the right includes the following options:

- Date Format:
- ☒ Show Timestamp
- Device Name:
- ☒ Show Device Name
- Device Status Language:
- ☒ Show Azimuth
- ☐ Show Run Status
- OSD Content1: ☐ Add One Line
- OSD Content2: ☐ Add One Line
- OSD Content3: ☐ Add One Line
- OSD Content4: ☐ Add One Line
-

Set time stamp, device name, device status language, OSD content and picture overlap here. After enabling the corresponding display and entering the content, drag them to change their position. Then click “Save” to save the settings.

Show Azimuth: Show the PTZ moving direction on the live view interface.

Show Run Status: Show the PTZ control status on the live view interface. For example, if the preset 2 is called, “PRE:002” will be shown on the live view interface.

Picture Overlay Settings:


Check “OSD Content1”, choose “Picture Overlay” and click “Browse” to select the overlap picture. Then click “Upload” to upload the overlap picture. The pixel of the image shall not exceed 200*200, or it cannot be uploaded.

3.2.4 Video Mask

Go to **Image**→**Video Mask** interface as shown below. A maximum of 8 zones can be set up (depending on models). Only some models support this function. If your PTZ camera doesn’t support it, please skip the following instructions.

To set up video mask:

1. Enable video mask.
2. Click direction buttons to change the area you want to mask.
3. Click “Draw Area” and then drag the mouse to draw the video mask area.
4. Click “Add” to add the mask area.



To delete mask area:

1. Select the mask area in the mask area list.
2. Click “Delete” to delete this mask area.

3.3 PTZ Configuration

3.3.1 PTZ and Password Setting

● PTZ Setting

Go to **Config** → **PTZ** → **Setting**. This will let you see the following submenu.

PTZ Settings	RS485	Others
Auto PTZ Flip	On	
Language	English	
Auto Logout Time	Off	
		Save

PTZ Settings	RS485	Others
PTZ ID	1	
Protocol	PELCO	
Baud-Rate	2400	
		Save

In this submenu, PTZ flip, PTZ flip, language, auto logout time can be set.

If your model supports RS485 interface, you may configure the communication setting for keyboard control.

● Password Setting


If the password is set, you must enter the password every time you go to the menu of the PTZ.

Go to **Config** → **PTZ** → **Setting** → **Others**. You can set the password of the PTZ menu.


- ② Enter the ID and preset name as needed. Then click “OK”.
- ③ Set the position of the preset by clicking the direction buttons. Then click “Save Position”. After that, click “Call” to call the preset.

● **Cruise Setup**

In this interface, by programming presets in cruise list in advance, the system will keep calling those presets at the set time in sequence when executing cruise command so that non-stop monitoring between multiple important positions can be achieved.



- ① Click “Create” to pop up a cruise creation box.




- ② Enter a cruise name and then click “Add preset” to add presets in sequence. This camera supports 8 cruises and 16 presets for each cruise. Set the preset and time.
- ③ Click “OK” to save the settings.

- ④ Click “Start” to run the added cruise. The camera will automatically keep running according to the cruise you set until new command is received.
- ⑤ Click “Stop” to stop running the cruise.

● **Group Setup**


8 cruises can be set in a group.



Click “Add Cruise” to add a cruise. Click “Edit Cruise” to change a cruise. After these cruises are added, click “Run” to run the cruises in order. Click “Stop” to stop running.

● **Trace Setup**


This function is used to memorize the operation to PTZ, zoom and focus so that repeating operation progress can be realized by running trace.



Click “Add” and then set the trace by clicking the direction/zoom/focus buttons. Each trace can record up to 180s. If the time exceeds 180s, the system will automatically save the operation data and return to the previous menu. In addition, 360 commands can be recorded for each trace at most. If exceeding 360 commands, the system will automatically save the first 360 commands and then exit the current menu. The recording time is related to the operating frequency. The more frequent the operation is, the shorter the memory time is. Click “Save” to save the settings. After that, select the trace and click “Run” to play the trace.


● Task Setup

By dividing 24 hours into several periods and appointing different commands for each period, the camera system will automatically execute the commands according to the set time if there is no operation.



- ① Click “Create” and then set the start time and the end time.
- ② Select the function and number. Then click “Add”.
- ③ After all tasks are added, click “OK” to save the settings.
- ④ The tasks will be automatically executed in chronological order by enabling “Run”.

● Alarm Setup



【Alarm Type】 : Set the alarm enter type to be Normally Opened (N.O.) or Normally Closed (N.C.) according to the sensor type.

【Alarm In】 : ON and OFF are optional.


【Alarm Trigger】: Call the preset/cruise/trace/random scanning/boundary scanning you need. When the first alarm input happens, the camera will automatically switch to this preset/cruise/trace/ random scanning/boundary scanning to monitor.

【Alarm Over】 :Call the preset/cruise/trace/random scanning/boundary scanning you need. When the alarm trigger is over, the camera will automatically switch to this preset/cruise/trace/random scanning/boundary scanning to monitor.

【Alarm Out】 : Select it ON. When alarm input occurs, the camera will output alarm information.

Note: If the dome is on the menu state on an alarm, any command is negative.

● **Home Position**



The setup steps are as follows:

- ① Check “Run” and select the preset which should be set in advance.
- ② Then select the wait time (range from 007s to 180s) and exit the menu.

When the stand-by time of the dome camera exceeds the wait time, the camera will automatically execute the command to monitor the selected preset.

3.4 Alarm Configuration

3.4.1 Motion Detection

Go to **Alarm**→**Motion Detection** to set motion detection alarm.

Detection Config	Area and Sensitivity	Schedule
☒ Enable		
Alarm Holding Time 20 Seconds		
Trigger Alarm Out		
☐ Alarm Out		
☒ Trigger SD Card Snapshot		
☒ Trigger SD Card Recording		
☐ Trigger Email		
☐ Trigger FTP		
Save		

1. Check “Enable” check box to activate motion based alarms. If unchecked, the camera will not send out any signals to trigger motion-based recording to the NVR or CMS, even if there is motion in the video.

Alarm Holding Time: it refers to the time that the alarm extends for after an alarm ends. For instance, if the alarm holding time is set to 20 seconds, once the camera detects a motion, it will go to alarm and would not detect any other motion in 20 seconds. If there is another motion detected during this period, it will be considered as continuous movement; otherwise it will be considered as a single motion.

Alarm Out: If selected, this would trigger an external relay output that is connected to the camera on detecting a motion based alarm.

Trigger Audio Alarm: If selected, the warning voice will be uttered on detecting a motion based alarm. (Please set the warning voice first. See [Audio Alarm](#) for details).

Note: Only some models support audio alarm function. If your device doesn’t support this function, please skip the instruction of “Trigger Audio Alarm”.


Trigger SD Card Snapshot: If selected, the system will capture images on motion detection and save the images on an SD card.

Trigger SD Card Recording: If selected, video will be recorded on an SD card on motion detection.

Trigger Email: If “Trigger Email” and “Attach Picture” are checked (email address must be set first in the Email configuration interface), the captured pictures and triggered event will be sent into those addresses.

Trigger FTP: If “Trigger FTP” is checked, the captured pictures will be sent into FTP server address. Please refer to FTP configuration chapter for more details.

2. Set motion detection area and sensitivity. Click the “Area and Sensitivity” tab to go to the interface as shown below.




Move the “Sensitivity” scroll bar to set the sensitivity. Higher sensitivity value means that motion will be triggered more easily.
Select “Add” and click “Draw”. Drag the mouse to draw the motion detection area; Select “Erase” and drag the mouse to clear motion detection area.
After that, click the “Save” to save the settings.

3. Set the schedule for motion detection. The schedule setup steps of the motion detection are the same as the schedule recording setup (See [Schedule Recording](#)).

3.4.2 Exception Alarm

● SD Card Full

1. Go to Config→Alarm→Exception Alarm→SD Card Full.



2. Click “Enable” and set the alarm holding time.
3. Set alarm trigger options. The setup steps are the same as motion detection. Please refer to motion detection chapter for details.

● SD Card Error

When there are some errors in writing SD card, the corresponding alarms will be triggered.

1. Go to **Config → Alarm → Exception Alarm → SD Card Error** as shown below.

The screenshot shows the 'SD Card Error' configuration page. At the top, there are four tabs: 'SD Card Full', 'SD Card Error' (which is selected and highlighted in dark grey), 'IP Address Collision', and 'Cable Disconnected'. Below the tabs, the page contains the following settings: an 'Enable' checkbox that is checked; an 'Alarm Holding Time' dropdown menu set to '20 Seconds'; a 'Trigger Alarm Out' section with an 'Alarm Out' checkbox that is unchecked; and two checkboxes at the bottom, 'Trigger Email' and 'Trigger FTP', both of which are unchecked.

2. Click “Enable” and set the alarm holding time.

3. Set alarm trigger options. Trigger alarm out, Email and FTP. The setup steps are the same as motion detection. Please refer to [motion detection](#) chapter for details.

● **IP Address Conflict**

1. Go to **Config → Alarm → Exception Alarm → IP Address Collision** as shown below.

The screenshot shows the 'IP Address Collision' configuration page. At the top, there are four tabs: 'SD Card Full', 'SD Card Error', 'IP Address Collision' (which is selected and highlighted in dark grey), and 'Cable Disconnected'. Below the tabs, the page contains the following settings: an 'Enable' checkbox that is checked; an 'Alarm Holding Time' dropdown menu set to '20 Seconds'; a 'Trigger Alarm Out' section with an 'Alarm Out' checkbox that is unchecked; and two checkboxes at the bottom, 'Trigger Email' and 'Trigger FTP', both of which are unchecked.

2. Click “Enable” and set the alarm holding time.

3. Trigger alarm out. When the IP address of the camera is in conflict with the IP address of other devices, the system will trigger the alarm out.

Note: This function is only available for some models.

● **Cable Disconnection**

1. Go to **Config → Alarm → Exception Alarm → Cable Disconnected** as shown below.

SD Card Full	SD Card Error	IP Address Collision	Cable Disconnected
☒ Enable			
Alarm Holding Time		20 Seconds	
Trigger Alarm Out			
☐ Alarm Out			

2. Click “Enable” and set the alarm holding time.

3. Trigger alarm out. When the camera is disconnected, the system will trigger the alarm out.

Note: This function is only available for some models.

3.4.3 Alarm Input

Only some models support this function. If your device doesn’t support it, please skip the following instructions.

Go to **Config**→**Alarm**→**Alarm In** interface as shown below.

Detection Config	Schedule
☒ Enable	
Alarm Type	NC
Alarm Holding Time	20 Seconds
Sensor Name	
Trigger Alarm Out	
☐ Alarm Out	
☐ Trigger SD Card Snapshot	
☐ Trigger SD Card Recording	
☐ Trigger Email	
☐ Trigger FTP	
Save	

To set sensor alarm (alarm in):

1. Set Sensor ID (available for the models with two or more alarm input interfaces).

2. Click “Enable” and set the alarm type, alarm holding time and sensor name.

3. Set alarm trigger options.

Alarm Out: If selected, this would trigger an external relay output that is connected to the camera when the sensor alarm is triggered (**This function is only available for the models with Alarm Out interface**).

Trigger Audio Alarm: If selected, the warning voice will be uttered when the sensor alarm is

triggered. (Please set the warning voice first. See [Audio Alarm](#) for details).

Note: Only some models support audio alarm function. If your device doesn't support this function, please skip the instruction of "Trigger Audio Alarm".

Trigger Light Alarm: If selected, the light of the camera will turn on or flash when the sensor alarm is triggered. (Please set the light mode, light flashing time and frequency first. See [Light Alarm](#) for details).

Note: Only some models support light alarm function. If your device doesn't support this function, please skip the instruction of "Trigger Light Alarm".

Trigger SD Snap: If selected, the system will capture images when the sensor alarm is triggered and save the images on an SD card.

Trigger SD Recording: If selected, video will be recorded on an SD card when the sensor alarm is triggered.

Trigger Email: If "Trigger Email" and "Attach Picture" are checked (email address must be set first in the Email configuration interface), the captured pictures and triggered event will be sent into those addresses.

Trigger FTP: If "Trigger FTP" and "Attach Picture" are checked, the captured pictures will be sent into FTP server address. Please refer to FTP configuration chapter for more details.

4. Apply settings to other sensors (if applicable).

5. Click "Save" to save the settings.

6. Set the schedule of the sensor alarm. The setup steps of the schedule are the same as the schedule recording setup. (See [Schedule Recording](#)).

3.4.4 Alarm Out

Only some models support this function. If your device doesn't support it, please skip the following instructions.

Go to *Config* → *Alarm* → *Alarm Out*.

Alarm Out Mode	Alarm Linkage
Alarm Out Name	alarmOut1
Alarm Holding Time	20 Seconds
Alarm Type	NC
Save	

Alarm Out Mode: Alarm linkage, manual operation, day/night switch linkage and timing are optional.

Alarm Linkage: Having selected this mode, select alarm out name, alarm holding time at the "Alarm Holding Time" pull down list box and alarm type.

Manual Operation: Having selected this mode, select the alarm type and click "Open" to trigger the alarm out immediately; click "Close" to stop alarm.

Alarm Out Mode	Manual Operation	▼
Alarm Type	NC	▼
Manual Operation	Open	Close
Save		

Day/Night Switch Linkage: Having selected this mode, select the alarm type and then choose to open or close alarm out when the camera switches to day mode or night mode.

Alarm Out Mode	Day/night switch linkage	▼
Alarm Type	NC	▼
Day	Close	▼
Night	Close	▼
Save		

Timing: Select the alarm type. Then click “Add” and drag the mouse on the timeline to set the schedule of alarm out; click “Erase” and drag the mouse on the timeline to erase the set time schedule. After this schedule is saved, the alarm out will be triggered in the specified time.

Alarm Out Mode	Timing	▼
Alarm Type	NC	▼
Time Range	☐ Erase ☒ Add 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 Manual Input	
Save		

3.4.5 Alarm Server

Go to **Alarm** → **Alarm Server** interface as shown below.

Set the server address, port, heartbeat and heartbeat interval. When an alarm occurs, the camera will transfer the alarm event to the alarm server. If an alarm server is not needed, there is no need to configure this section.

Server Address	0.0.0.0
Port	8010
Heartbeat	Disable ▼
Heartbeat interval	30 Second
OK	

3.4.6 Audio Alarm

Only some models support this function. If your device doesn't support this function, please skip the following instructions.

Go to **Alarm**→**Audio Alarm** interface as shown below.

Voice Configuration

Warning voice

English

Voice

You have entered the real-

Warning Times

5

times

Volume

14

Save

1. Select the warning voice. For some models, you can customize the voice. Choose “Customize”, click “Browse” or “Select File” to choose the audio file you want to upload and then enter the audio name. Finally, click “Upload” to upload the audio file. Note that the format of the audio file must meet the requirement (see Tips), or it will not be uploaded. After you upload the audio file, you can select the audio name from the audio list and click “Listen” to listen to it. Click “Delete” to delete the audio.

Voice Configuration

Warning voice

Customize

Voice

Warning Times

5

times

Volume

100

Upload Audio

Upload Path

Browse

Audio Name

Upload

Tips: audio format (WAV, 8000Hz, monophonic, 16bit, less than 300K)

Voice Record

Save Path

Browse

Audio Name

Record Audio

10

Start

Upload

Audio List

Listen

Delete

Save

You can also record your own voice in the above interface and then upload.

- Insert the microphone into your PC.
- Click “Browse” to choose the save path of the audio you want to record.

- Set the record audio volume and then click “Start” to start recording your voice.
- Click “Upload” to upload your customized voice.

Note: Only some models support voice record and you must log in the camera by the web browser with the plug-in, or voice record is not available.

2. Select the voice and then set the warning times and volume as needed.

Warning times: it ranges from 1 to 50.

3. Click “OK” to save the settings.

3.4.7 Light Alarm

Only some models support this function. If your device doesn’t support this function, please skip the following instructions.

Go to **Alarm** → **Light Alarm** interface as shown below.

Set the light mode, flashing time and frequency of the light.

Light Mode	Flashing	▼
Flashing Time	60	Second
Flashing Frequency	Low	▼
OK		

Light mode: choose “Flashing” or “Always on” as needed.

Flashing time: the flashing time ranges from 1 second to 60 seconds.

Flashing Frequency: three options- low, middle and high.

3.4.8 Smart Tracking

(Only some models support this function)

The tracking option is available for line crossing detection, region entrance and exiting and intrusion detection.

Smart Tracking: When people or vehicle cross the alarm line or intrude or exit the predefined area, the PTZ camera will automatically track them and the target image will be automatically zoomed in and centered on the screen until the target disappears from the screen. After that, the PTZ camera will return to the tracking start position (home position).

Config	
Tracking Mode	PTZ Auto Tracking Priority Manual PTZ Control Priority
Still time	☒ ☐ 0 (s)

Tracking Mode: PTZ Auto Tracking Priority or Manual PTZ Control Priority can be optional.

PTZ Tracking Priority: if this mode is selected, in smart tracking mode, you cannot control PTZ by clicking the buttons on the PTZ control panel in the live view interface.


Manual PTZ Control Priority: if this mode is selected, in smart tracking mode, you can control PTZ by clicking the buttons on the PTZ control panel in the live view interface and then the camera will immediately stop the tracking action. After you finish controlling PTZ for 5 seconds, the PTZ camera will return to the start tracking position and wait for the object to appear.

Still time: If it is enabled and the time is set, when the target stops or hides behind an obstacle, or the target tracking is complete and there is no target appearing in the detection area during the set time, the PTZ camera will return to the tracking start position after the set time expires. During this time, if there are targets moving, the PTZ will continue tracking. If it is not enabled, when the target stops or there is no target appearing in the detection area for 5 seconds, the PTZ camera will return to the start tracking position.

For example: At the stoplight, if a car is waiting for the red light for 30 seconds, and the still time is set as 20 seconds, the tracking will stop following; however, if the still time is set as 40 seconds, when the red light changes to green and the car starts to move, the PTZ will continue tracking this car.

How to perform smart tracking:

- 1. Click **Config** → **Alarm** → **Smart Tracking** to go to the smart tracking interface. Select the tracking mode and set the still time as needed.
- 2. Click **Config** → **Event**. Select the event as needed. For example intrusion, enable the intrusion detection, select detection target and then check “Trigger Track”. After that click “Save” to save the settings.
- 3. Set the alarm area and lock the PTZ.



Using the PTZ control buttons (area①) sets appropriate field of view and then draw the detection area and save the setting.


After that, click the “Lock” button to save the current PTZ position as the start tracking position (home position). Now, the “Lock” button changes its function to “Unlock”.

Note: a. Clicking the “Unlock” button suspends object tracking until you click the “Lock” button. If you want to change the start tracking position, you can click “Unlock” button

to enable PTZ control. After that, please remember to lock the PTZ, or object tracking will not take effect.

b. After the smart tracking is enabled and the home position is locked, preset 89 will be generated as the smart tracking home position by default. Please **DO NOT** delete preset 89, or the PTZ will not go back to the home position after finishing tracking.

4. Go back to the live view interface to view smart tracking.



3.5 Event Configuration

(Only some models support the following functions).

For more accuracy, here are some recommendations for installation.

- Cameras should be installed on stable surfaces, as vibrations can affect the accuracy of detection.
- Avoid pointing the camera at the reflective surfaces (like shiny floors, mirrors, glass, lake surfaces and so on).
- Avoid places that are narrow or have too much shadowing.
- Avoid scenario where the object's color is similar to the background color.
- At any time of day or night, please make sure the image of the camera is clear and with adequate and even light, avoiding overexposure or too much darkness on both sides.

Note: The following functions are only available when the PTZ camera stops moving.

3.5.1 Video Exception

Only some models support this function. If your camera doesn't support this function, please skip the following instructions.

This function can detect changes in the surveillance environment affected by the external factors.

To set exception detection:

Go to **Config → Event → Video Exception** interface as shown below.

Detection Config

Sensitivity

☒ Scene Change Detection

☒ Video Blur Detection

☒ Abnormal Color Detection

Alarm Holding Time

20 Seconds

Trigger Alarm Out

☐ Alarm Out

☐ Trigger SD Card Snapshot

☐ Trigger SD Card Recording

☐ Trigger Email

☐ Trigger FTP

Save

1. Enable the applicable detection that's desired.

Scene Change Detection: Alarms will be triggered if the scene of the monitor video has changed.

Video Blur Detection: Alarms will be triggered if the video becomes blurry.

Abnormal Color Detection: Alarms will be triggered if the image is abnormal because of color deviation.

- 2. Set the alarm holding time and alarm trigger options. The setup steps are the same as motion detection. Please refer to motion detection chapter for details.
- 3. Click “Save” button to save the settings.
- 4. Set the sensitivity of the exception detection. Click “Sensitivity” tab to go to the interface as shown below.

Detection ConfigurationSensitivity

Sensitivity

28

Save

Drag the slider to set the sensitivity value or directly enter the sensitivity value in the textbox. Click “Save” button to save the settings.

The sensitivity value of Scene Change Detection: The higher the value is, the more sensitive the system responds to the amplitude of the scene change.

The sensitivity value of Video Blur Detection: The higher the value is, the more sensitive the system responds to the blurriness of the image.

The sensitivity value of Abnormal Color Detection: The higher the value is, the more sensitive the system responds to the color shift of the image.

3.5.2 Line Crossing Detection

Line Crossing: Alarms will be triggered if the target crosses the pre-defined alarm lines. Go to *Config→Event→Line Crossing* interface as shown below.

Detection Config
Area
Schedule

☒ Enable

☐ Save Original Picture To SD Card

☐ Save Target Picture To SD Card

Detection target and sensitivity

Target
Sensitivity

☒ Human

100

☒ Motor Vehicle

100

☒ Motorcycle/Bicycle

100

Alarm Holding Time
20 Seconds

Trigger Alarm Out

☐ Alarm Out

☒ Trigger Track

☐ Trigger Audio Alarm

☐ Trigger Light Alarm

☐ Trigger SD Card Snapshot

☐ Trigger SD Card Recording

☐ Trigger Email

☐ Trigger FTP

Save

● Detection Configuration:

1. Enable line crossing detection and select the snapshot type and the detection target.

Save Original Picture to SD Card: If it is enabled, the detected original pictures will be captured and saved to the SD card when the targets cross the alarm line.

Save Target Picture to SD Card: If it is enabled, the detected target cutout pictures will be captured and saved to the SD card when the targets cross the alarm line.

Note: To save snapshots to the local PC, please enable “Local Smart Snapshot Storage” in the local config interface first. To save snapshots to the SD card, please install an SD card first.

Detection Target:

Human: Select it and then alarms will be triggered if someone crosses the pre-defined alarm lines.

Motor Vehicle: Select it and then alarms will be triggered if a vehicle with four or more wheels (eg. a car, bus or truck) crosses the pre-defined alarm lines.

Non-motor Vehicle (Motorcycle/bicycle): Select it and then alarms will be triggered if a vehicle with two wheels (eg. a motorcycle or bicycle) crosses the pre-defined alarm lines.

All of the three types of objects can be selected simultaneously. Please select the detection objects as needed. If no object/target is selected, alarms will not be triggered even if line

crossing detection is enabled.

- 2. Set the alarm holding time.
- 3. Set alarm trigger options.

Alarm Out: If selected, this would trigger an external relay output that is connected to the camera on detecting a target crossing the alarm line.

Trigger Audio Alarm: If selected, the warning voice will be uttered when the sensor alarm is triggered. (Please set the warning voice first. See [Audio Alarm](#) for details).

Note: Only some models support audio alarm function. If your device doesn't support this function, please skip the instruction of "Trigger Audio Alarm".

Trigger Light Alarm: If selected, the light of the camera will turn on or flash when the sensor alarm is triggered. (Please set the light mode, light flashing time and frequency first. See [Light Alarm](#) for details).

Note: Only some models support light alarm function. If your device doesn't support this function, please skip the instruction of "Trigger Light Alarm".

Trigger Track: if enabled, the PTZ camera will automatically track the target that crosses the alarm line and the target's image will be automatically zoomed in and centered on the screen until the target disappears on the screen. After that, the PTZ camera will return to the pre-defined detection area.

Trigger SD Card Snapshot: If selected, the system will capture images when a target crosses the alarm line and save the images on an SD card.

Trigger SD Card Recording: If selected, video will be recorded on an SD card when a target crosses the alarm line


Trigger Email: If "Trigger Email" and "Attach Picture" are checked (email address must be set first in the Email configuration interface), the captured pictures and triggered event will be sent into those addresses.

Trigger FTP: If "Trigger FTP" is checked, the captured pictures will be sent into FTP server address. Please refer to FTP configuration chapter for more details.

- 4. Click "Save" button to save the settings.

● **Area Configuration**

- 1. Click the "Area" tab to go to the interface as shown below.



- 2. Set the alarm line number and direction. Up to 4 lines can be added. Multiple lines cannot be added simultaneously.

Direction: A<->B, A->B and A<-B optional. This indicates the direction of someone or a vehicle crossing over the alarm line.

A<->B: Alarms will be triggered when someone or a vehicle crosses over the alarm line from B to A or from A to B.

A->B: Alarms will be triggered when someone or a vehicle crosses over the alarm line from A to B.

A<-B: Alarms will be triggered when someone or a vehicle crosses over the alarm line from B to A.

3. Set the detection area by clicking the buttons of area ① and then click “Lock” to lock the area.

Note: The PTZ will not be controlled if you click “Lock” here. Click “Unlock” and then click the buttons of area ① to move the PTZ camera. Clicking the “Unlock” button suspends object tracking until you click the “Lock” button.

4. Click the “Draw Area” button and then drag the mouse to draw a line in the image. Click the “Stop Draw” button to stop drawing. Click the “Clear” button to delete the lines. Click the “Save” button to save the settings.

● Schedule Configuration

Set the schedule of the line crossing alarm. The setup steps of the schedule are the same as the schedule recording setup (See [Schedule Recording](#)).

3.5.3 Region Intrusion

Region Intrusion: Alarms will be triggered if the target intrudes into the pre-defined areas.

Go to *Config* → *Event* → *Region Intrusion* interface as shown below.

Detection Config

Area

Schedule

☒ Enable

☐ Save Original Picture To SD Card

☐ Save Target Picture To SD Card

Detection target and sensitivity

Target

Sensitivity

☒ Human

☒ Motor Vehicle

☒ Non-motor Vehicle

50

50

50

Alarm Detection Time

20 Seconds

Trigger Alarm Out

☐ Alarm Out

☐ Trigger Track

☐ Trigger SD Card Snapshot

☐ Trigger SD Card Recording

☐ Trigger Email

☐ Trigger FTP

Save

- **Detection Configuration**

Enable region intrusion detection, select the snapshot type and the detection target and set the alarm holding time and alarm trigger options. The detection setup steps are the same as line crossing detection. Please refer to the detection configuration of line crossing detection for details.

- **Area Configuration**

1. Click the “Area” tab to go to the interface as shown below.

Detection Config Area Schedule

The screenshot shows the PTZ control interface. At the top are three tabs: "Detection Config", "Area", and "Schedule". The main area displays a live camera feed of a street intersection. A yellow polygon outlines a detection area on the sidewalk. To the right of the feed is a section labeled "Alarm Area" with a dropdown menu set to "1". Below this is a PTZ control panel containing a grid of icons for pan, tilt, and zoom movements, as well as preset positions represented by tree and person icons. A red circle with the number "1" highlights one of the preset icons. Below the icon grid is a slider bar with minus and plus signs. To the right of the slider is a "Lock" button and a status message in parentheses: "(The PTZ control is unavailable in locked status !)". At the bottom left are "Stop Draw" and "Clear" buttons, and at the bottom right is a "Save" button.

2. Set the alarm area number on the right side. Up to 4 alarm areas can be added.
3. Set the detection area by clicking the buttons of area ① and then click “Lock” to lock the area.

Note: The PTZ will not be controlled if you click “Lock” here. Click “Unlock” and then click the buttons of area ① to move the PTZ camera. Clicking the “Unlock” button suspends object tracking until you click the “Lock” button.

4. Click the “Draw Area” button and then click around the area where you want to set as the alarm area in the image on the left side (the alarm area should be a closed area). Click the “Stop Draw” button to stop drawing. Click the “Clear” button to delete the alarm area. Click the “Save” button to save the settings.

After that, the camera will automatically return to this detection area after auto human /vehicle tracking.

● Schedule Configuration

Set the schedule of the intrusion detection. The setup steps of the schedule are the same as schedule recording setup (See [Schedule Recording](#)).

3.5.4 Region Entrance

Region Entrance: Alarms will be triggered if the target enters the pre-defined areas.

1. Go to *Config → Event → Region Entrance* interface.
2. Enable region entrance detection and select the snapshot type and the detection target.
3. Set the area of region entrance detection..
4. Set the schedule of the region entrance detection.

The setup steps of the region entrance detection are the same as the region intrusion detection setup (See [Region Intrusion](#) for details).

3.5.5 Region Exiting

Region Exiting: Alarms will be triggered if the target exits from the pre-defined areas.

1. Go to *Config → Event → Region Exiting* interface.
2. Enable region exiting detection and select the snapshot type and the detection target.
3. Set the area of region exiting detection.
4. Set the schedule of the region exiting detection.

The setup steps of the region exiting detection are the same as the region intrusion detection setup (See [Region Intrusion](#) for details).

3.5.6 Target Counting

Only some models support this function.

This function is used to detect, track and count the number of people or vehicles crossing the set alarm line.

1. Go to *Config → Event → Target Counting by Line* as shown below.

Detection Config
Area
Schedule

☒ Enable

☐ Save Original Picture To SD Card

☐ Save Target Picture To SD Card

Detection target and sensitivity

Target	Sensitivity		Staying Threshold
☒ Human	<input type="range"/>	50	0
☒ Motor Vehicle	<input type="range"/>	50	0
☒ Non-motor Vehicle	<input type="range"/>	50	0

Counting Reset

Timing
Off

Manual
Reset

Alarm Holding Time
20 Seconds

Trigger Alarm Out

☐ Alarm Out

☐ Trigger SD Card Snapshot

☐ Trigger SD Card Recording

☐ Trigger Email

☐ Trigger FTP

Save

2. Enable target counting by line and select the snapshot type and the detection target.

Detection Target: Select the target to calculate. Human, motor vehicle and motorcycle/bicycle can be selected.

Staying Threshold: When the targets (human/vehicle) staying in the specified area exceed the threshold, alarms will be triggered.

Counting Reset: You can choose to reset the counting daily, weekly or monthly. The current number of people/cars/bikes counted will be cleared immediately when you click the “Reset” button.

3. Set the alarm trigger options. The setup steps are the same as motion detection. Please refer to motion detection chapter for details.

4. Set the alarm line. Click the “Area” tab to go to the interface as shown below.

Detection Config	Area	Schedule
 X1 Draw Area Clear		
2023/02/14 16:19:43 Alarm Line 1 Direction A->B ☒ Statistics		
OSD ☒ Entrance Entry ☒ Exit Exit ☒ Stay Stay Human human Car car Bike bike Under Threshold Welcome Over Threshold Please wait		
Save		

Set the alarm line number and direction. Only one alarm line can be added.

Direction: A->B and A<-B can be optional. The direction of the arrow is entrance.

Statistics: If enabled, you can see the statistical information in the live view interface. If disabled, the statistical information will not be displayed in the live view interface.

The statistical OSD information can be customized as needed.

Click the “Draw Area” button and then drag the mouse to draw a line in the image. Check “Statistics” and then move the red box to change the position of the statistical information displayed on the screen. Click the “Stop Draw” button to stop drawing. Click the “Clear” button to delete the lines.

Click the “Save” button to save the settings.

5. Set the schedule of the target counting. The setup steps of the schedule are the same as schedule recording setup (See [Schedule Recording](#)).

6. View the statistical information in the live view interface.




7. View the statistical information of target counting by line. Click “Statistics” to enter the following interface.

Target Counting by Line									
Report Type		Count Type		Count Time				Count	
Daily Report		Enter		2023		Year 2		Month 14	
						Day		Table	
Index	Count Time	Human	Motor Vehicle	Non-motor Vehicle					
9	2023-02-14 08:00:00 ~ 2023-02-14 08:59:59	0	0	0					
10	2023-02-14 09:00:00 ~ 2023-02-14 09:59:59	0	0	0					
11	2023-02-14 10:00:00 ~ 2023-02-14 10:59:59	5	311	8					
12	2023-02-14 11:00:00 ~ 2023-02-14 11:59:59	0	0	0					

Select the report type. Daily report, weekly report, monthly report and annual report are selectable.

Select the count type. Enter or leave can be optional.

Select the start time and then click “Count”. Then the counting result will display in the statistic result area. Click Table or Chart to display the result in different way.



3.5.7 Face Comparison

- Only some models support this function.
- The setting steps are as follows.
1. Go to *Config*→*Event*→*Face Comparison* interface.

Detection Config	Comparison and Linkage	Area	Advanced	Schedule	Face Database Management
State Working					
☒ Enable					
☐ Save Source Information To SD Card					
☐ Save Face Information To SD Card					
Trigger alarm condition All					
Alarm Holding Time 20 Seconds					
☒ Trigger SD Card Snapshot					
☒ Trigger SD Card Recording					
☐ Trigger Email					
☐ Trigger FTP					
Save					

2. Enable the face detection function.


Save Source Information to SD Card: if checked, the whole picture will be saved to the local PC or SD card when detecting a face.

Save Face Information to SD Card: if checked, the captured face picture will be saved to the local PC or SD card when detecting a face.


Note: To save images to the local PC, please enable the local smart snapshot storage first (**Config→System→Local Config**). To save images to the SD card, please install an SD card first.

3. Set alarm holding time and alarm trigger options.

4. Set alarm detection area. Click “Draw Area” and drag the border lines of the rectangle to modify its size. Move the rectangle to change its position. Click “Stop Draw” to stop drawing the area. Click “Clear” to clear the area. Then set the detectable face size by defining the maximum value and the minimum value (The default size range of a single face image occupies from 3% to 50% of the entire image).



5. Face database management: click “Face Database Management” tab. This will enter the following interface.



There are four ways to add face pictures.

① Adding face pictures one by one

Click to pop up an adding user box. Then click to select a face picture saved on the local PC. Please select the picture according to the specified format and size limit. After that, fill out the relevant information of the face picture and click “Entry” to add.


② Adding multiple face pictures at a time

Click and then add multiple face pictures once according to the prompted rules.

③ Add face pictures by using face album management tool

④ Add the captured picture in the live mode (See *Add captured face pictures to the face database*).

After adding face pictures, you can search them by name, gender, ID number and so on.



Click “Modify” to change people information and click “Delete” to delete this face picture.

6. Set face comparison trigger options. Click “Comparison and Linkage” to go to the following interface.

Detection Config	Comparison and Linkage	Area	Advanced	Schedule	Face Database Management
Similarity Threshold 75 %					
☐ Push Stranger Information					
☐ Deduplication Period 10 Seconds					
Alarm Trigger Mode Face Only					
Allow list Block list Visitor Stranger ☐ Alarm Out					
Save					

Similarity threshold: When the similarity of the captured face picture and the face picture added into the face database exceeds the similarity threshold, alarms will be triggered.

Push Stranger: Push the comparison alarm information of the stranger. After it is enabled, the comparison information of the stranger will be shown on the left comparison area of the live interface.

Deduplication Period: In the set period, delete the repeated comparison results.

Alarm Trigger Mode: Face only mode. When the captured face picture is matched successfully, alarms will be triggered.

Alarm Output: Select the list type and then checkmark alarm out. Then alarm output will be triggered when the captured face is matched successfully with the face image of the selected list.

7. Set the schedule of the face detection and comparison. The setup steps of the schedule are the same as schedule recording setup (See [Schedule Recording](#)).

8. Advanced configuration.

Detection Config	Comparison and Linkage	Area	Advanced	Schedule	Face Database Management
Application Scenes Security Monitoring					
Deduplication Period 30 Seconds					
Snapshot Number 3					
Proximity Priority Comparison Close					
Comparison in free time Open					
Save					

Application Scenes: “Access control”, “security monitoring” or “customize” can be selected.
Snapshot Interval: If 5 seconds is selected, the camera will capture the same target once every 5 seconds during its continuous tracking period.

Snapshot Number: If the snapshot number is enabled and set (eg. 3), the camera will capture the same target once every 5 seconds and it will capture this target 3 times at most during its continuous tracking period. If the snapshot number is disabled, the camera will capture the


same target once every 5 seconds until the target disappears in the detected area.

Proximity Priority Comparison: When several persons are in the recognition area at the same time, the person closer to the camera is recognized first.

Comparison in free time: When the processor is busy, the comparison of the current detected person will not be performed immediately (for example, there is not enough time for the processor to perform all comparisons, because so many people are detected at the same time). It will continue after the processor load is reduced.

● **Face Match View**


After all face comparison settings are set successfully, enter the live view interface. Click  to view the captured face pictures and face comparison information.



Area ①: captured face pictures; area ②: face comparison area


● **View the comparison details**

In area ②, click the compared face picture to bring up the following window. In this interface, you can view the detailed comparison information.



- **Add captured face pictures to the face database**

Click a captured picture in area ①. This will bring a face picture adding box.




Fill out the relevant information and click “Entry” to add this face picture.

3.6 Network Configuration

3.6.1 TCP/IPv4

Go to Config→Network→TCP/IP interface as shown below. There are two ways for network connection.



Use IP address (take IPv4 for example)-There are two options for IP setup: obtain an IP address automatically by DHCP and use the following IP address. Please choose one of the options as needed.

Test: Test the effectiveness of the IP address by clicking this button.

Use PPPoE-Click the “PPPoE Config” tab to go to the interface as shown below. Enable PPPoE and then enter the user name and password from your ISP.

IPv4	IPv6	PPPoE Config	IP Change Notification Config
☒ Enable			
User Name		xxxxxxx	
Password		•••••	
Save			

Either method of network connection can be used. If PPPoE is used to connect internet, the camera will get a dynamic WAN IP address. This IP address will change frequently. To be notified, the IP change notification function can be used.

Click “IP Change Notification Config” to go to the interface as shown below.

IPv4	IPv6	PPPoE Config	IP Change Notification Config
☐ Trigger Email			
☐ Trigger FTP			
Save			

Trigger Email: when the IP address of the device is changed, the new IP address will be sent to the email address that has been set up.

Trigger FTP: when the IP address of the device is changed, the new IP address will be sent to FTP server that has been set up.

3.6.2 Port

Go to **Config** → **Network** → **Port** interface as shown below.

HTTP Port	80	
HTTPS Port	443	
Data Port	9008	
RTSP Port	554	
Persistent connection Port	8080	☒ Enable
WebSocket Port	7681	
Save		

HTTP Port: The default HTTP port is 80. It can be changed to any port which is not occupied.

HTTPS Port: The default HTTPs port is 443. It can be changed to any port which is not occupied.

Data Port: The default data port is 9008. Please change it as necessary.

RTSP Port: The default port is 554. Please change it as necessary.

Persistent Connection Port: The port is used for a persistent connection of the third-party platform to push smart data, like face pictures.

WebSocket Port: Communication protocol port for plug-in free preview.

3.6.3 Server Configuration

This function is mainly used for connecting network video management system.

☒ Enable

Server Port

2009

Server Address

Device ID

1

Save


1. Check “Enable”.
2. Check the IP address and port of the transfer media server in the Panasonic NVMS. Then enable the auto report in the Panasonic NVMS when adding a new device. Next, enter the remaining information of the device in the Panasonic NVMS. After that, the system will automatically allot a device ID. Please check it in the Panasonic NVMS.
3. Enter the above-mentioned server address, server port and device ID in the corresponding boxes. Click “Save” to save the settings.

3.6.4 Onvif

The camera can be searched and connected to the third-party platform via ONVIF/RTSP protocol.

If “Activate Onvif User” is enabled in the device activation interface, the ONVIF user can be activated simultaneously. When you connect the camera through the ONVIF protocol in the third-party platform, you can use this onvif user to connect.

You can also add new users in the Onvif interface.



Note: when adding the device to the third-party platform with ONVIF/RTSP protocol, please use the onvif user in the above interface.

3.6.5 DDNS Configuration


If the camera is set up with a DHCP connection, DDNS should be set for the internet.

1. Go to **Config** → **Network** → **DDNS**.

The screenshot shows a 'DDNS Configuration' form. At the top, there is a checkbox labeled 'Enable' which is checked. Below it is a 'Server Type' dropdown menu with 'www.dyndns.com' selected. Underneath are three text input fields: 'User Name', 'Password', and 'Domain'. At the bottom right of the form is a 'Save' button.

2. Apply for a domain name. Take www.dvrddns.com for example.

Enter www.dvrddns.com in the IE address bar to visit its website. Then click "Registration".

NEW USER REGISTRATION	
USER NAME	XXXX
PASSWORD	••••• ?
PASSWORD CONFIRM	•••••
FIRST NAME	XXX
LAST NAME	XXX
SECURITY QUESTION.	My first phone number. ▾
ANSWER	XXXXXXXX
CONFIRM YOU'RE HUMAN	 New Captcha Enter the text you see above
Submit Reset	

Create domain name.

You must create a domain name to continue.

Domain name must start with (a-z, 0-9). Cannot end or start, but may contain a hyphen and is not case-sensitive.

After the domain name is successfully applied for, the domain name will be listed as below.

Search by Domain. Search		
Click a name to edit your domain settings.		
NAME	STATUS	DOMAIN
654321ABC	✓	654321abc.dvrddns.com
Last Update: <i>Not yet updated</i> IP Address: 210.21.229.138		
Create additional domain names		

3. Enter the username, password, domain you apply for in the DDNS configuration interface.
4. Click "Save" to save the settings.

3.6.6 SNMP

To get camera status, parameters and alarm information and remotely manage the camera, the SNMP function can be used. Before using SNMP, please install an SNMP management tool and set the parameters of the SNMP, such as SNMP port, trap address.

1. Go to **Config** → **Network** → **SNMP**.

SNMP v1/v2	
☐ Enable SNMPv1	
☐ Enable SNMPv2	
Read SNMP Community	
Write SNMP Community	
Trap Address	...
Trap Port	0
Trap community	
SNMP v3	
☐ Enable SNMPv3	
Read User Name	
Security Level	auth, priv
Authentication Algorithm	☒ MD5 ☐ SHA
Authentication Password	
Private-key Algorithm	☒ DES ☐ AES
Private-key Algorithm	
Write User Name	
Security Level	auth, priv
Authentication Algorithm	☒ MD5 ☐ SHA
Authentication Password	
Private-key Algorithm	☒ DES ☐ AES
Private-key Algorithm	
Other Settings	
SNMP Port	0

2. Check the corresponding version checkbox (Enable SNMPv1, Enable SNMPv2, Enable SNMPv3) according to the version of the SNMP software that will be used.

3. Set the values for “Read SNMP Community”, “Write SNMP Community”, “Trap Address”, “Trap Port” and so on. Please make sure the settings are the same as that of the SNMP software.

Note: Please use the different version in accordance with the security level you required. The higher the version is, the higher the level of the security is.

3.6.7 802.1X

IEEE802.X which is an access control protocol manages the device in connection with the local network by authentication. The setup steps are as follows:

☒ Enable
Protocol Type EAP_MD5
EAPOL Version 1
User Name test
Password •••••
Confirm Password •••••

To use this function, the camera shall be connected to a switch supporting 802.1x protocol. The switch can be reckoned as an authentication system to identify the device in a local network. If the camera connected to the network interface of the switch has passed the authentication of the switch, it can be accessed via the local network.

Protocol type and EAPOL version: Please use the default settings.

User name and password: The user name and password must be the same with the user name and password applied for and registered in the authentication server.

3.6.8 RTSP

Go to **Config** → **Network** → **RTSP**.

☒ Enable
Port 554
Address rtsp://IP or domain name:port/profile1
rtsp://IP or domain name:port/profile2
rtsp://IP or domain name:port/profile3
Multicast address
Main stream 239.0.0.0 50554 ☐ Automatic start
Sub stream 239.0.0.1 51554 ☐ Automatic start
Third stream 239.0.0.2 52554 ☐ Automatic start
Audio 239.0.0.3 53554 ☐ Automatic start
☐ Allow anonymous login (No username or password required)
Save

Select “Enable” to enable the RTSP function.

Port: Access port of the streaming media. The default number is 554.

RTSP Address: The RTSP address (unicast) format that can be used to play the stream in a media player.

Multicast Address

Main stream: The address format is

“rtsp://IP address: rtsp port/profile1?transportmode=mcast”.

Sub stream: The address format is

“rtsp://IP address: rtsp port/profile2?transportmode=mcast”.

Third stream: The address format is

“rtsp://IP address: rtsp port/profile3?transportmode=mcast”.

Audio: Having entered the main/sub stream in a VLC player, the video and audio will play automatically.

If “Allow anonymous login...” is checked, there is no need to enter the username and password to view the video.

If “auto start” is enabled, the multicast received data should be added into a VLC player to play the video.

Note:1. This camera support local play through a VLC player. Enter the RTSP address (unicast or multicast, eg. rtsp://192.168.0.10:554/profile1?transportmode=mcast) in a VLC player to realize the simultaneous play with the web client.

- 2. The IP address mentioned above cannot be the address of IPv6.
- 3. Avoid the use of the same multicast address in the same local network.
- 4. When playing the video through the multicast streams in a VLC player, please pay attention to the mode of the VLC player. If it is set to TCP mode, the video cannot be played.
- 5. If the coding format of the video of the main stream is MJPEG, the video may be disordered at some resolutions.

3.6.9 RTMP

You can access the third-party (like YouTube) to realize video live view through RTMP protocol.

Go to **Config** → **Network** → **RTMP**.

☒ Enable (Only supports H264)

Stream Type: ☒ Main stream ☐ Sub stream ☐ Third stream

Reconnect After Timeout Second

Server Address

Connection Status Not Connected Refresh

Save

Check “Enable”, select stream type, set the reconnection time after timeout and server address as needed.

Server address: Enter the server address allocated by the third party server.
After that, click “Save” to save the settings. Then click “Refresh” to view the connection status.

3.6.10 UPnP

If this function is enabled, the camera can be quickly accessed through the LAN.
Go to **Config** → **Network** → **UPnP**. Enable UPnP and then enter UPnP name.

☐ Enable

UPnP Name

3.6.11 E-mail

If you need to trigger Email when an alarm happens or IP address is changed, please set the Email here first.

Go to **Config** → **Network** → **Email**.

Sender	
Sender Address	xxx@126.com
User Name	☒ Anonymous Login
Password	
Server Address	smtp.126.com
Secure Connection	Unnecessary ▼
SMTP Port	25 Default
☐ Send Interval(S)	60 (10-3600)
Clear Test	
Recipient	
xxx@126.com	
Recipient Address	
Add Delete	
Save	

Sender Address: sender's e-mail address.

User name and password: sender's user name and password (you don't have to enter the username and password if "Anonymous Login" is enabled).

Server Address: The SMTP IP address or host name.

Select the secure connection type at the "Secure Connection" pull-down list according to what's required.

SMTP Port: The SMTP port.

Send Interval(S): The time interval of sending email. For example, if it is set to 60 seconds and multiple motion detection alarms are triggered within 60 seconds, they will be considered as only one alarm event and only one email will be sent. If one motion alarm event is triggered and then another motion detection alarm event is triggered after 60 seconds, two emails will be sent. When different alarms are triggered at the same time, multiple emails will be sent separately.

Click the "Test" button to test the connection of the account.

Recipient Address: receiver's e-mail address.

3.6.12 FTP

After an FTP server is set up, captured pictures from events will be uploaded to the FTP server.

1. Go to **Config** → **Network** → **FTP**.

Server Name	Server Address	Port	User Name	Upload Path
Add FTP Server Name test Server Address 192.168.1.3 Upload Path Example:/Dir/folder Port 21 User Name admin Password ***** ☐ Anonymous OK Cancel				

Add

Modify

Delete

Test

Save

2. Click “Add” to add the information of the FTP. After that, click “Save” to save the settings.

Server Name: The name of the FTP server.

Server Address: The IP address or domain name of the FTP.

Upload Path: The directory where files will be uploaded to.

Port: The port of the FTP server.

User Name and Password: The username and password that are used to login to the FTP server.

3. In the event setting interface (like intrusion, line crossing, etc.), trigger FTP as shown below.

☒ Trigger FTP	
Server Address ☒ 192.168.1.3 ☒ Attach Picture	
Save	

Rule of FTP storage path: /device MAC address/event type/date/time/

For example: a motion detection alarm occurs

FTP file path : \00-18-ae-a8-da-2a\MOTION\2021-01-09\14\

Event name table:

File Name	Event Type
IP	IP address change
MOTION	Motion Detection
SENSOR	Sensor Alarm
TRIPWIRE	Line Crossing Detection
PERIMETER	Region Intrusion Detection
AVD	Video Exception
VFD	Face Detection
AOIENTRY	Region Entrance
AOILEAVE	Region Exiting
PASSLINECOUNT	Target Counting by Line
SDFULL	SD Full
SDERROR	SD Error

TXT file content:

device name: xxx mac: device MAC address Event Type time:

For example:

device name: IPC mac: 00-18-ae-a8-da-2a MOTION time: 2021-03-16 12:20:07

3.6.13 HTTP POST

Go to **Config** → **Network** → **HTTP POST** interface.

Check “Enable”, select protocol type and then set the server address (IP address/domain name), server port and heartbeat interval.

☒ Enable	
Protocol Type	API
Server Address	. . .
Server Port	8082
Heartbeat interval	90 Second
Online State	Offline Refresh
Save	

Server address: the IP address/domain name of the third-party platform.

Server port: the server port of the third-party platform.

After the above parameters are set, click “Save” to save the settings. Then the camera will automatically connect the third-party platform. The online state can be viewed in the above interface. After the camera is successfully connected, it will send the alarm information (HTTP format) to the third-party platform once the smart alarm is triggered. The alarm information

includes target tracing coordinates, target features, the captured original/target image (like the captured face picture, motor vehicle picture) and so on.

3.6.14 HTTPS

HTTPS provides authentication of the web site and protects user privacy.
Go to **Config** → **Network** → **HTTPS** as shown below.

☒ Enable

☐ Disable HTTP port (Checking this option may cause no image displayed in Google/Firefox)

Certificate installed

C=US, ST=Some-State, O=embeddedsoftware

Delete

Attribute

Issued to: C=US, ST=Some-State, O=embeddedsoftware, H=IPC,
Issuer: C=US, ST=Some-State, O=embeddedsoftware, H=Root CA,
Validity date: 2021-03-19 03:18:30 ~ 2031-03-17 03:18:30

Save

There is a certificate installed by default as shown above. Enable this function and save it. Then the camera can be accessed by entering https://IP: https port via the web browser (eg. https://192.168.0.10:443).

A private certificate can be created if users don't want to use the default one. Click "Delete" to cancel the default certificate. Then the following interface will be displayed.

☒ Enable

☐ Disable HTTP port (Checking this option may cause no image displayed in Google/Firefox)

Installation type

☒ Have signed certificate, install directly

☐ Create a private certificate

☐ Create a certificate request

Install certificate

浏览... Install

Save

- * If there is a signed certificate, click "Browse" to select it and then click "Install" to install it.
- * Click "Create a private certificate" to enter the following creation interface.

☒ Enable

☐ Disable HTTP port (Checking this option may cause no image displayed in Google/Firefox)

Installation type

☐ Have signed certificate, install directly

☒ Create a private certificate

☐ Create a certificate request

Create a private certificate

Create

Save

Click "Create" to create a private certificate. Enter the country (only two letters available), domain (camera's IP address/domain), validity date, password, province/state, region and so on.

Then click “OK” to save the settings.

* Click “Create a certificate request” to enter the following interface.

☒ Enable

☐ Disable HTTP port (Checking this option may cause no image displayed in Google/Firefox!)

Installation type

☐ Have signed certificate, install directly

☐ Create a private certificate

☒ Create a certificate request

Create a certificate request

CreateDownloadDelete

Install Created Certificate

BrowseInstall

Save

Click “Create” to create the certificate request. Then download the certificate request and submit it to the trusted certificate authority for signature. After receiving the signed certificate, install the certificate to the device.

3.6.15 QoS

QoS (Quality of Service) function is used to provide different quality of services for different network applications. With the deficient bandwidth, the router or switch will sort the data streams and transfer them according to their priority to solve the network delay and network congestion by using this function.

Go to **Config** → **Network** → **QoS**.

Video/Audio DSCP	13
Alarm DSCP	35
Manager DSCP	53

Video/Audio DSCP: The range is from 0 to 63.

Alarm DSCP: The range is from 0 to 63.

Manager DSCP: The range is from 0 to 63.

Generally speaking, the larger the number is, the higher the priority is.

3.7 Security Configuration

3.7.1 User Configuration

Go to **Config** → **Security** → **User** interface as shown below.

Config Home » Security » User

AddModifyDeleteSecurity Question

Index	User Name	User Type
1	admin	Administrator

Add user:

1. Click the “Add” button to pop up the following textbox.

The screenshot shows a web-based configuration interface. On the left, a sidebar contains a table with an 'Add' button circled in red and an arrow pointing to the 'Add User' dialog box. The dialog box is titled 'Add User' and contains the following fields: 'User Name' (text input), 'Password' (text input), 'Level' (text input), 'Confirm Password' (text input), and 'User Type' (dropdown menu). Below these fields is a section titled 'Select All' with a list of checkboxes: 'Remote storage settings', 'Remote image settings', 'Remote PTZ control', 'Remote alarm server configuration', 'Remote intelligent event configuration', 'Remote network advanced configuration', and 'Remote security management'. At the bottom of the dialog are 'OK' and 'Cancel' buttons.

- 2. Enter user name in the “User Name” textbox.
- 3. Enter the password in the “Password” and “Confirm Password” textbox. Please set the password according to the requirement of the password security level (Go to **Config → Security → Security Management → Password Security** interface to set the security level).
- 4. Choose the user type and select the desired user permissions.
- 5. Click the “OK” button and then the newly added user will be displayed in the user list.

Modify user:

- 1. Select a user to modify password if necessary in the user configuration list box.
- 2. The “Edit user” dialog box pops up by clicking the “Modify” button.

Edit User

User Name

admin

Old Password

New Password

☒

Level

The password can be composed of numbers, special characters, upper or lower case letters.

Confirm Password

User Type

Administrator

☐ Select All

☒ Remote storage settings

☒ Remote image settings

☒ Remote PTZ control

☒ Remote alarm server configuration

☒ Remote intelligent event configuration

☒ Remote network advanced configuration

☒ Remote security management

OK

Cancel

3. Enter the old password of the user in the “Old Password” text box.
4. Enter the new password in the “New password” and “Confirm Password” text box.
5. Select the user permissions for advanced or normal user.
6. Click the “OK” button to save the settings.

Note: When the password level is set to “Strong”, the password cannot be set the same as the previous five.

Delete user:

1. Select the user to be deleted in the user configuration list box.
2. Click the “Delete” button to delete the user.

Note: The default administrator account cannot be deleted.

Safety Question Settings: set the questions and answers for admin so as to reset the password after you forget the password.

3.7.2 Online Video User

Go to **Config** → **Security** → **Online User** to view the user who is viewing the live video.

Index	Client Address	Port	User Name	User Type	
1	192.168.17.232	55760	admin	Administrator	Kick Out

An administrator user can kick out all the other users (including other administrators).

3.7.3 Block and Allow Lists

Go to **Config→Security→Block and Allow Lists** as shown below.

IP Address Filter Settings

☒ Enable address filtering

☒ Block the following address

☐ Allow the following address

Add

Delete

0.0.0.0

☒ IPv4

☐ IPv6

Save

The setup steps are as follows:

Check the “Enable address filtering” check box.

Select “Block/Allow the following address”, IPv4/IPv6 and then enter IP address in the address box and click the “Add” button.

3.7.4 Security Management

Go to **Config→Security→Security Management** as shown below.

Security Service

Password Security

Authentication

☒ Enable "locking once illegal login" function

☐ Trigger Email

Logout Time

300

Second

Save

In order to prevent against malicious password unlocking, “locking once illegal login” function can be enabled here. If this function is enabled, login failure after trying six times will make the login interface locked. The camera can be logged in again after a half hour or after the camera reboots.

Trigger Email: if enabled, e-mail will be sent when logging in/out or illegal login lock occurs.

● Password Security

Security Service

Password Security

Authentication

Password Level

Weak

Expiration Time

Never

Save

Please set the password level and expiration time as needed.

Password Level: Weak, Medium or Strong.

Weak level: Numbers, special characters, upper or lower case letters can be used. You can choose one of them or any combination of them when setting the password.

Medium Level: 8~16 characters, including at least two of the following categories: numbers, special characters, upper case letters and lower case letters.

Strong Level: 8~16 characters. Numbers, special characters, upper case letters and lower case letters must be included.

For your account security, it is recommended to set a strong password and change your password regularly.

HTTP Authentication: Basic or Token is selectable.

Security Service

Password Security

Authentication

HTTP Authentication

Basic

Save

3.8 Maintenance

3.8.1 Backup & Restore

Go to *Config* → *Maintenance* → *Backup & Restore*.

Import Setting

Path

Browse

Import Setting

Export Settings

Export Settings

Default Settings

Keep

☐ Network Config

☐ Security Configuration

☐ Image Configuration

Load Default

● **Import & Export Settings**

Configuration settings of the camera can be exported from a camera into another camera.

- 1. Click “Browse” to select the save path for import or export information on the PC.
- 2. Click the “Import Setting” or “Export Setting” button.

● **Default Settings**

Click the “Load Default” button to restore all system settings to the default factory settings except those you want to keep.

3.8.2 Reboot Device

Go to *Config → Maintenance → Reboot*.

Click the “Reboot” button to reboot the device.

Timed Reboot Setting:

If necessary, the camera can be set up to reboot on a time interval. Enable “Time Settings”, set the date and time and then click the “Save” button to save the settings.

3.8.3 Upgrade

Go to *Config → Maintenance → Upgrade*. In this interface, the camera firmware can be updated.

 Do not allow downgrading from the current version to the lower version.
Do not disconnect power during the upgrade.

Local upgrade

Path

Browse

Upgrade

- 1. Click the “Browse” button to select the save path of the upgrade file.
- 2. Click the “Upgrade” button to start upgrading the firmware.
- 3. Enter the correct password and then the device will restart automatically

Caution! Do not close the browser or disconnect the camera from the network during the upgrade.

3.8.4 Log

To query and export log

- 1. Go to *Config → Maintenance → Operation Log*.

Config Home » Maintenance » Operation Log							
Main Type	All logs		Sub Type	All logs			
Start Time	2023-02-14 00:00:00		End Time	2023-02-14 23:59:59		SearchExport	
Index	Time	Main Type	Sub Type	User Name	Login IP	Hostname	
1	2023-02-14 16:21:39	Alarm	PassLineCount Alarm				
2	2023-02-14 16:21:39	Operation	System config modify	admin	10.15.1.111		
3	2023-02-14 16:21:37	Operation	System config modify	admin	10.15.1.111		
4	2023-02-14 16:11:46	Operation	System config modify				

2. Select the main type, sub type, start and end time.
3. Click “Query” to view the operation log.
4. Click “Export” to export the operation log.

4 Playback

4.1 Image Search


Click Search to go to the interface as shown below. Images that are saved on the SD card can be found here.

Note: When using the plug-in free browser, the local images cannot be searched.



● Local Image Search

1. Choose “Picture”—“Local”.
2. Set time: Select date and choose the start and end time.
3. Click  to search the images.
4. Double click a file name in the list to view the captured photos as shown above.




Click  to return to the previous interface.

Note: When using the plug-in free browser, the local images cannot be searched.

● **SD Card Image Search**

1. Choose “Picture”—“SD Card”.



2. Set time: Select date and choose the start and end time.
3. Choose the alarm events at the bottom of the interface.
4. Click  to search the images.
5. Double click a file name in the list to view the captured photos.
- Click  to return to the previous interface.
- The descriptions of the buttons are shown as follows.


Icon	Description	Icon	Description
	Close: Select an image and click this button to close the image.		Close all: Click this button to close all images.
	Save: Click this button to select the path for saving the image on the PC.		Save all: Click this button to select the path for saving all pictures on the PC.
	Fit size: Click to fit the image on the screen.		Actual size: Click this button to display the actual size of the image.
	Zoom in: Click this button to digitally zoom in.		Zoom out: Click this button to digitally zoom out.
	Slide show play: Click this button to start the slide show mode.		Stop: Click this button to stop the slide show.
	Play speed: Play speed of the slide show.		

4.2 Video Search

4.2.1 Local Video Search

Click Search to go to the interface as shown below. Videos were recorded locally to the PC can be played in this interface.

Note: When using the plug-in free browser, the local videos cannot be searched.



1. Choose “Record”—“Local”.
2. Set search time: Select the date and choose the start and end time.
3. Click  to search the images.
4. Double click on a file name in the list to start playback.




Icon	Description	Icon	Description
	Play button. After pausing the video, click this button to continue playing.		Pause button
	Stop button		Speed down
	Speed up		Watermark display
	Enable / disable audio; drag the slider to adjust the volume after enabling audio.		

Note: When using the plug-in free browser, the local videos cannot be searched.


4.2.2 SD Card Video Search

Click Search to go to the interface as shown below. Videos that were recorded on the SD card can be played in this interface.

1. Choose “Record”—“SD Card”.
2. Set search time: Select the date and choose the start and end time.
3. Click  to search the images.



4. Select the alarm events at the bottom of the interface.
5. Select mix stream (video and audio stream) or video stream as needed.
6. Double click on a file name in the list to start playback.



Note: ⏮ and ⏭ cannot be displayed in the above interface via the plug-in free browser. Additionally, for plug-in free playback, playback mode switch (balanced/real-time/fluent mode) and downloading functions are not supported too. The time table can be shown in 24H/12H/2H/1H format by clicking the corresponding buttons.

Video clip and downloading

1. Search the video files according to the above mentioned steps.
2. Select the start time by clicking on the time table.
3. Click to set the start time and then this button turns blue ().
4. Select the end time by clicking on the time table. Then click to set the end time.
5. Click to download the video file in the PC.

Index	Process	Record	Start Time	End Time	Path	Operate
1	100%	Cut	2018-01-16 01:1...	2018-01-16 01:1...	Favorites	Open
Set up D:\Favorites Clear List Close						

Click “Set up” to set the storage directory of the video files.
Click “Open” to play the video.
Click “Clear List” to clear the downloading list.
Click “Close” to close the downloading window.

Set the start time and end time and click “Search” to view the face recognition result.

A photo of each recognized face is marked with a colored bar. The red color of the bar means no comparison result. Green color means there is a comparison result. White color means that the recognized face has not been compared with the face database. The most common reason for such a situation is that, the camera waits for the comparison operation when the “Comparison in free time” option is enabled. Clicking the picture marked with green color displays the following face comparison information.

6 Q & A

1. Q: I forget the password. How can I do?

A: The password for **admin** can be reset through “Edit Safety Question” function. Click “Forget Password” in the login window and then enter the corresponding answer of the selected question in the popup window. After you correctly answer all questions, you can reset the password for **admin**. If you forget the answer of the question, this way will be invalid, please contact your dealer for help.

B: The passwords of other users can be reset by **admin**.

2. Q: The devices can't connect through IE browser. Why?

- ① Network is not connected well. Please check the connection and make sure it is connected well.
- ② IP is not available. Reset the valid IP.
- ③ Web port number has been revised: contact administrator to get the correct port number.
- ④ Exclude the above reasons. Restore the default setting by Panasonic IP Manager Tool.

Note: The default IP: 192.168.0.10, mask number: 255.255.255.0


3. Q: Panasonic IP Manager Tool cannot search devices. How can I do?

It may be caused by the anti-virus software in your computer. Please exit it and try to search device again.

4. Q: IE cannot download ActiveX control. How can I do?

IE browser blocks ActiveX. Please do setup following below.

- ① Open IE browser. Click Tools-----Internet Options....



- ② Select Security-----Custom Level....Refer to Fig 4-1.
- ③ Enable all the sub options under “ActiveX controls and plug-ins”. Refer to Fig 4-2.




Fig 4-1




Fig 4-2

④ Then click OK to finish setup.

Other plug-ins or anti-virus blocks ActiveX. Please uninstall or close them.

5. Q: Why does the device fail to sound?

The audio input device is not connected. Please connect and try again.

The audio function is not enabled at the corresponding channel. Please check AUDIO item to enable this function.

6. Q: How to do when the device is unable to start normally when upgrading?

If the device is unable to start normally when upgrading, please rename the files suffixed with .tar as updatepack.tar and copy it to the root directory of SD card. Restart the device and then the device will upgrade automatically from the SD card. After finishing upgrading, the user can search the IP address of IP Cam in the Panasonic IP Manager Tool.

Appendix Preset Description

Call Preset	Call NO.90 Preset	Run trace 1
	Call NO.91 Preset	Run cruise 1
	Call NO.92 Preset	Run cruise 2
	Call NO.93 Preset	Run cruise 3
	Call NO.94 Preset	Run cruise 4
	Call NO.97 Preset	Enable random scan
	Call NO.99 Preset	Enable auto scan
Save Preset	Save NO. 92 Preset	Set the left scan endpoint
	Save NO. 93 Preset	Set the right scan endpoint