



Panasonic®

Operating Instructions Refrigerator

For Household Use

Model No.: **NR-TX461**



Contents

• Safety precautions.....	2
• Usage precautions.....	4
• Installation	6
• Parts identification	7
• Temperature control.....	7
• Temperature control (Fine adjustment mode).....	8
• Quick Ice/Freezing.....	8
• ECONAVI operation.....	9
• Usage tips.....	9
• How to make ice cubes with ice maker	11
• How to clean the refrigerator	11
• Troubleshooting	14
• Specifications	15

■ NON-CFC

This unit uses totally **NON-CFC MATERIALS** both for refrigerant (R600a) and for insulation (Cyclo-Pentane). So, this refrigerator does not damage the Earth's ozone layer.

Thank you for purchasing the Panasonic product.

- Please read these instructions carefully and follow safety precautions on page 2-5 before using this product.
- Please make sure the date and name of store of purchase are stamped in warranty card and keep it with this operating instructions.

PHI

ARAH1E202540
P0321-0
Printed in Vietnam

Safety precautions

Please be sure to follow these instructions.



WARNING

This sign means: It may lead to a serious injury or death.



These signs mean prohibited action.



This sign means required action.



This sign means the appliance must be earthed to prevent electric shock.



CAUTION

This sign means: It may result in injury or property damage.



iso-butane

Risk of fire / flammable materials



WARNING

Otherwise it may cause a fire, injury, electrical shock.

For power plug and cord:



- **Do not** plug or unplug with wet hands.
- **Do not** let the cord or plug be damaged.



- Disconnect power plug when cleaning.
- Plug into a wall outlet of the rated voltage on its own with the rated current and insert plug fully.
- Reserve one socket for the refrigerator only. Avoid connecting many appliances to the same socket and unroll through the length of cord.
- Remove dust periodically from the power plug.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- If you detect burning smell, disconnect the power plug and ventilate the kitchen.
- **Stop** using the refrigerator and unplug the unit immediately if there is an abnormality or failure. Abnormality and failure examples:
 - Power cord or plug is abnormally hot.
 - Power cord is deeply cut or deformed.
 - There is burning smell.
 - You can feel tingling electricity.

When recycling the product:



- Before taking the refrigerator to be recycled, please remove all the door opening seal to prevent locking a child in it.
- The warning labels mentioned above should be kept throughout the life of the refrigerator.
- The operating instructions should be handed over to any person who would use or handle the refrigerator whenever the refrigerator would be transferred to another location and delivered to a recycling plant.
- Regarding to local laws, Cyclo-Pentane is used for insulation of this refrigerator. When you throw away this unit, please discard it by proper method and do not dispose it by burning.

Otherwise it may
cause a fire, injury,
electrical shock.



WARNING

When using:



- **Do not** damage the cooling circuit (piping on the back).
- **Do not** touch the compressor and pipes, because of high temperature, that there is a risk of burn injury.
- **Do not** let any children hang onto the refrigerator's door, it may overturn to the kid.
- **Do not** place any water container on the top of the refrigerator in case the spilling water causes electrical shock or combustion.
- **Do not** locate multiple portable socket-outlets or portable supplies at the rear of the appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.



- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

In case of emergency:



R600a
iso-butane

- Maintenance work only be carried out at workshop by well-trained maintenance worker.



- **Do not** store explosive substances such as aerosol cans with a flammable propellant and chemicals or scientific specimens in the appliance.
- **Do not** use electrical appliances such as a deodorizer in the refrigerator. Leaked refrigerant may catch fire from a spark of the electrical contacts and may cause an explosion.
- **Do not** use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.



- **Do not** disassemble, repair or modify the refrigerator by yourself. If you want to repair the refrigerator, please consult your dealer or authorized service center.
- **Do not** use mechanical device or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

When installing:



- Fix the refrigerator to avoid danger due to unbalance.
- When positioning the appliance, ensure the supply cord is not trapped or damaged.



- Ensure that the refrigerator is plugged into an earthed mains socket.

Otherwise it may cause
injury, accidents.




CAUTION

When opening/closing the doors:



- While opening the refrigerator, be careful not to pinch other one's hand holding the door.
- Mind the gap between the doors. They may nip your hand while closing the door.



When storing food:



- **Do not** freeze glass bottles, that there is a risk of injury. (If the liquid in a glass bottle is frozen, then the bottle may break and you may be injured.)
- **Do not** add a high impact on glass trays. (Otherwise those glass trays may break and you may be injured.)



When moving the refrigerator:



- Hold the refrigerator tightly when transporting.
- Apply protective covering, etc. to floors with a fragile surface.

Usage precautions

When opening/closing the doors:

- **Do not** refrigerate items which are bigger than tray or shelf, as the door will not close completely causing leakage of cool air.
- **Do not** open refrigerator frequently or leave it open for long time in order to prevent water dripping inside and waste energy.
- Frequently check the door opening seal, it must be closed to the refrigerator's body completely.

When cleaning:

- **Do not** clean the refrigerator with chemical substance or liquid. It will cause damage and have corrosion on the surface.
- Clean the pan water evap located over the compressor at the back of the refrigerator every three months to prevent the odour generated from humidity.



Usage precautions

When using:

- When the plug is disconnected, leave it for 5 minutes before plugging again. If not, the compressor may not work.
- Adjust the temperature according to the actual operating condition for energy saving.
- The humidity inside the fresh case may condense so wipe it with a cloth periodically. Clean the fresh case once a month.
- If you will not be at home for several days and there are nothing refrigerated in the refrigerator, the plug should be disconnected for energy saving.
- The outside wall of refrigerator cabinet may sometimes get warm, especially just after installation. This is quite normal, and is due to the built-in Mullion Dryer Pipe which prevents sweating and radiates heat.
- When humidity is high, e.g. during rainy-season, condensation may appear on the surface of cabinet, especially around the door seal gasket. Wipe off the condensed water with a clean cloth.
- **Do not** keep the door open any longer than necessary, particularly in hot, humid weather.



When storing food:

- **Do not** place warm/hot foodstuff in the refrigerator.
- **Do not** overload the refrigerator. Gap must be provided between foodstuffs to maintain the cooling effect.
- Store fruits and vegetables in vegetable case, where trapped moisture helps preserve food quality for longer time periods.
- Drinking water, beverage bottles should be sealed to prevent odor contamination.
- Food stuff such as vegetables, fruits and fresh food should be wrapped or packed in box before freezing and refrigerating.
- Put the food such as meat or fish in the freezer if you want to store for an extended period.
- Cover juicy food with tight lids, plastic film or foil.
- Cool hot dishes in room temperature before placing them in your refrigerator.



SPECIAL FEATURE

1) ECONAVI

The microchip performing ECONAVI mode is integrated into the main control board. By detecting refrigerator's frequency of use (opening and closing of door), ECONAVI mode automatically operates to save energy.

2) INVERTER

In accordance with temperature change inside the compartment, the motor of compressor runs at different speed. When the temperature is stable, the motor runs at a lower speed (energy saving & lower noise). When powerful cooling is required, the motor runs at a higher speed.


Installation

The distance requested for installation

- The top of the refrigerator and the ceiling at least 30 cm.
- The back of the refrigerator and the wall at least 10 cm.
- The sides of the refrigerator and the walls at least 5 cm.

Area around the installed unit

- **Do not** locate the refrigerator in a humid place as rust may form and may cause electric leakage.
- **Do not** locate the refrigerator exposing to direct sunlight as the heat and sunlight will increase the temperature.
- **Do not** locate the refrigerator near heat source such as cooking stove or oven.
- **Do not** block the openings around the refrigerator.
- The refrigerator must be located in the place where there is good air circulation.
- In case of placing the refrigerator on an uneven surface, adjust the adjustable leg to make the refrigerator stands stably.
- In order to prevent the refrigerator from tipping due to earthquakes, permanently fix it by using belts, etc.



Moving or shifting

- When moving or shifting the refrigerator, remove ice cube tray, box ice tray, pan water evap etc. and check to be sure that there is no water in the refrigerator.

Power cord setting

- To bring power cord for use, pan water evap from left should be lifted up. Then bring the power cord out and then insert pan water evap into the block by pressing at both the sides.

LED lamp and grounding

- The refrigerator LED lamp, specially designed for this refrigerator, do not replace it by yourself. If you need replacement, please contact Panasonic Service Center.
- If there is no grounding wiring plug in refrigerator, it should be connected with grounding connection to prevent electrical hazard from electric leakage.


For safety, the ground connection should be done

(For a refrigerator with plug (2-pin plug) without any grounding wire)

The ground connection will allow prevention of danger resulted from electricity leakage.

The ground connection can be performed in 2 ways as follows:


1. In the case that the grounding receptacle having been prepared for the socket (plug socket), connect the ground wire to the screw used for ground connection at the bottom rear of the refrigerator (regarding the screw used for ground connection, please notice the ⚡ symbol) as shown in the illustration ①. And then connect the other end to the grounding receptacle.
2. In the case that the socket (plug socket) having not been provided with any grounding receptacle, connect the ground wire to the screw at the bottom of the refrigerator, (as regards the screw used for ground connection, please notice the ⚡ symbol). And then connect the other end to the ground rod as shown in the illustration ②.



Prohibited spots for ground connection

- Gas pipes and water supply pipes (dangers from electric shock or explosion).
- The ground wires of telephone cords and lightning rods (dangers from lightning).

Parts identification



Temperature control

The temperature can be adjusted for Min - Max levels. Press “Freezer” to adjust temperature in Freezer room and press “Fridge” to adjust temperature in Fridge room.

Button		[Fridge] (Fridge room)	[Freezer] (Freezer room)
Max	***■	Lower than "Med" by approx. 2 °C ~ 3 °C	Lower than "Med" by approx. 2 °C ~ 3 °C
Med	**■	Approximately 1 °C ~ 6 °C	Approximately -23 °C ~ -17 °C
Min	*■	Higher than "Med" by approx. 2 °C ~ 3 °C	Higher than "Med" by approx. 2 °C ~ 3 °C

Generally, use the refrigerator with the temperature set to “Med”.

Temperature control (Fine adjustment mode)

■ How to operate the “9 levels” mode

The refrigerator is specially designed for appropriate use, which can adjust the temperature level to detailed 9 levels with the following details.

To adjust the temperature for the Fridge room

- ① Set LED display to the “Min” position by press the [Fridge] button.
- ② Press and hold the [Fridge] button for about 10 seconds until the LED display returns to the “Min” position.
- ③ Use the [Fridge] button to set the required temperature mode, where level 1 is the minimum cooling mode and level 9 is the maximum cooling mode (as specified in the LED Display table).

To adjust the temperature for the Freezer room

Operate above ① ~ ③ steps with pressing “Freezer” button instead of “Fridge” button.

■ LED Display table

Cooling Level									
Levels		Maximum							
LED Display	1	2	3	4	5	6	7	8	9

Lighting

Blinking

Not lighting

■ To reset the setting “9 levels” mode

Repeat steps ① and ②, then the refrigerator returns to normal operation mode.


Remark

- The temperature control can vary depending on the environment and amount of food stored in the refrigerator.

Quick Ice/Freezing

When “Quick Ice/Freezing” is set, the refrigerator will reduce the temperature quickly for better performance of preserving food and speed of making ice.

■ How to operate the “Quick Ice/Freezing” mode



- Press the button “Freezer” until the light LED “Quick Ice/Freezing” turns on. “Quick Ice/Freezing” mode starts after about 10 seconds.

Light is on: Quick Ice/Freezing is operated
Light is off: Quick Ice/Freezing is not operated

Remark

- If you want to stop the operation immediately, press and hold the button “Freezer” until the light LED “Quick Ice/Freezing” turns off.
- The system will stop the operation automatically when it runs for 60 mins (as ambient temperature is below 19 °C) or 150 mins (as ambient temperature is above 19 °C) and return to normal mode (the light LED “Quick Ice/Freezing” turns off.)
- The light LED “Quick Ice/Freezing” flashing means that the defrosting system is now working. “Quick Ice/Freezing” mode will start right after the defrosting operation is finished.
- The Freezer temperature control will not operate during Quick Ice/Freezing mode as the compressor is already at maximum operating levels for the Quick Ice/Freezing mode.

ECONAVI Operation

The refrigerator detects the opening and closing of the refrigerator door to control operations automatically to ensure maximum energy saving.*1

■ ECONAVI operation

- The refrigerator learns the lifestyle patterns of your family from door opening and time periods of infrequent use to maximise energy efficiency.
- The refrigerator learns your lifestyle patterns from the previous 3 weeks of use and uses that data from the 4th week onwards.


■ Settings for enabling ECONAVI operation

- ECONAVI operation is automatically enabled when the temperature control for both the freezer and refrigerator compartment is set to “Med”.
- ECONAVI mode does not operate if the “Quick Ice/Freezing” mode is in operation.
- It is not possible to force to start of the ECONAVI mode.

Remark

*1 The effectiveness of the ECONAVI mode is dependent on the ambient temperature and the number of times the refrigerator door is opened and closed and the state in which food is stored.

Usage tips

Fridge room	“Processed food and drinks...” For regular storage of food and drinks or temporary storage of those to be served soon. 
Extra cool zone	“Dairy products...” For dairy products, etc. that perish easily but whose quality changes if frozen. 
Vegetable case	“Fruits and vegetables” A rather high humidity keeps fruits and vegetables fresh and juicy. 
AG Hygiene zone	“Fresh food...” For storage of fresh foods such as meat or fish to avoid the odors spread out the freezer compartment. 
Freezer room	“Dried or frozen foods...” For storage of food for an extended period. 



Storage using hermetically sealed containers is recommended!

To prevent the interior from being discolored!



- Cut citrus fruits
(→ The plastic will be discolored white.)


To prevent odors from spreading!




- Garlicky or other strong smelling vegetables
(→ Odors will spread to other nearby food.)

The position of the second tray from the top can be changed.

(1) Lift up the back of the tray and pull it forward.



(2) Insert the tray in the desired position by reversing the steps.



- Glass Trays are heavy. Please handle them with care so that they do not fall and cause any damage or injury.
- Glass Tray Cool Zone (the first tray from the top) cannot be put on the position of Glass Tray PC.


Using as the Extra Cool Zone

■ When you do not want to freeze food.

- This room is suitable for storing chilled food or dairy products.

[Example of food to store]

- Chilled food
- Fresh cream
- Yogurt
- Boiled noodle
- Cheese



- Depending on food, it may be frozen partly. Change the position of food or set the temperature setting of the refrigerator compartment to “Min”.


Attention

- If you feel that the refrigerator does not cool enough or it is too cold, increase or decrease its temperature by following steps on page 7.
- When storing meat, it should be stored by using tightly sealed containers to prevent strong smelling spreading to nearby drink. They should not be stored over 1 week.

Using as the Ag Hygiene Zone

■ When you want to extend the life of food by partially-freezing it.

- This room is suitable for storing fresh food such as meat or fish.
- Temperature can be set to either “Min”, “Med” or “Max” to fit the volume and type of food. (P. 7)



Three tips for freezing food and locking in the flavour...



1. Freeze thin and small items of food quickly!
2. Fully sealed
3. Do not refreeze


How to make ice cubes with ice maker

STEP

1. Fill water in the ice cube tray till the water level line.
2. Put ice cube tray inside Freezer room, wait until ice is made.
3. To remove ice cubes, suppress the frame with left hand and twist the dial ice cube tray clockwise with right hand. The ice cubes will drop into the box ice tray.

Remark:

- Don't pour water into ice box for ice-making, otherwise the box may crack.



How to clean the refrigerator

Clean the refrigerator immediately after it is stained!

Wipe off stains on the interior surfaces quickly before they harden. In particular, cooking oil may cause plastic to crack and citrus juice may cause the refrigerator to become discolored. When stains cannot be removed easily, wipe them with a cloth lightly soaked in neutral kitchen detergent. Then, wipe with a cloth lightly dipped in water.

Clean the detachable items occasionally...


Once a week for the ice twister. As a guide, remove the trays, door shelves, etc. and wash them by immersing them in lukewarm water every three months.

Clean the door gasket at least once a month.


Clean by wiping with a soft damp cloth. Petroleum gel has been applied to the door gasket on the hinge side of the unit, be careful not to wipe this off.



Rub the door surface with a soft damp cloth.



Point where petroleum gel was applied.




Notices

The "door gasket" is replaceable by an authorised service agent. If the door gasket comes off while cleaning, it can be pushed back into the groove.

Requests

Do not use the following items for cleaning. (Otherwise, the surface will be scratched.)




PC Glass Tray

Once every 3 months

■ Removing

Lift up the back of the tray and pull it forward. Once the protrusions of the tray are unhooked from the rails, tilt the tray and remove it.



■ Attaching

Push the tray until it reached the end lock.

Attention


- When removing the tray above the vegetable case, please pull out the vegetable case first and then follow to removing the tray as above details.
- In case of attaching the tray and it does not lock, make sure that you did not attach it the wrong tray.
- Trays are made of glass and heavy. Please handle them with care so that they do not fall and cause any damage or injury. For attaching trays, hold them with the protrusion side down and firmly insert.

Door Extra Cool Zone

Once every 3 months


■ Removing

Lift up the door Extra Cool Zone and slide it into the above slot until it reaches the end of the stopper. Then remove screws to take off the cover.



■ Attaching

Insert the door Extra Cool Zone into its slot and tightening screws. Then slide it out and pull the cover down.




- Be sure to grab the cover with upturned hand. Otherwise, your hand may accidentally hit the refrigerator.

Ag Hygiene Zone


Once every 3 months

■ Removing



Pull out the case as far as possible. With lifting up the front, pull it out at an angle with holding the flap above the case.

■ Attaching



With holding up the flap, lift the back of the case and install it along the rails inside.

Attention

- When pull or attach Ag Hygiene Zone, be sure to grab its handle with upturned hand. Please refer to the above illustration.
(Otherwise, FC cover case may accidentally hit your fingers.)

Door Shelf/Bottle Shelf

Once every 3 months

■ Removing

Tap the bottom of the small shelves upward or slide alternately the left and right of the big shelves upward, and raise them slowly. (Tightly attached)



■ Attaching


Place it on both supporters, and then press until it reaches the end of supporters.

Vegetable Case

Once every 3 months


■ Removing

- 1 Pull the case until it reaches the end of stopper.
- 2 Raise up the front of case a bit and then completely take out.



■ Attaching

- 1 Keep the lid on the vegetable case lifting until case is attached.
- 2 Raise it up and place case on both supporters.
- 3 Push the case until it reaches the end.



Troubleshooting

Before you call for service, please check the following items:

The refrigerator does not operate.

- Check that the plug and its socket are in good condition.
- Check if there is any problem on main fuse and electrical system of the house.
- Check by unplug and wait for 5 minutes before plugging it back in.

The refrigerator does not cool enough.

- Check to be sure that light in control panel is displayed at proper position.
- Check to see if the refrigerator is overloaded with stuff or there is any hot foodstuff refrigerated inside.
- Is the refrigerator exposed directly to sunlight or heat source?
- Is the refrigerator door completely closed?
- Is the refrigerator door opened frequently?

Dew, snow appear.

Outside

- When the ambient humidity is too high, the door gasket may have dew. This situation will be stopped if the air humidity decreases. Please wipe it up with dry cloth.

Inside

- Is the door closed firmly?
- Is the door being opened and closed too frequently?
- When too high weather humidity, long opening time or making too much ice, inside the freezer compartment may appear frozen snow. This is normal. Please wipe with dry and soft cloth.



The refrigerator generates noise.

- Check if the refrigerator is located on a stable floor or is installed properly.
- Check if there is any object in contact with the refrigerator.
- Cracking sound within caused by the parts adjusting temperature which is normal.
- After installation, the refrigerator may make loud noise. The noise will be less when the refrigerator has been cooled.
- There may be a whistling sound inside the refrigerator when opening and closing the door. This is caused by the air outside being drawn in through the pipe on the backside of the refrigerator to better balance the air circulation inside the unit.
- Check if evap pipe in contact with pan water evap.

Food becomes frozen.

- Do you put the food near cold air holes?
- Do you adjust the temperature control at "Max"? Adjust to "Min"?
- Do you put food in extra cool zone?

Troubleshooting

The inside is smelling.

- Do you store food with dry odor without wrapping it?

The surfaces of the refrigerator is hot.

- Because the refrigerator is equipped with the dew prevention and heat radiation tubes, the surfaces of the refrigerator get warmer when operating.
- The back and side plates may get warmer especially when starting up or if the door is frequently opened and closed.

The normal sounds of refrigerator.

- When the refrigerator starts operation, the sound like water flowing and boiling water is created. This is the sound of the cooling liquid.
- The noise is generated when the automatic defrost system operated.
- The dilatation of the details inside the refrigerator in the cooling process can cause sound "crack-crack".
- You may feel that the operation sound is larger because the compressor operates in high-speed under the following conditions: the refrigerator does not cool fully on the occasion such as using it for the first time, opening/closing the door too frequently, the surrounding temperature is high. The sound becomes more quiet after cooling fully.

Lamp does not turn on.

- Please contact Panasonic service center.

Specifications

Model No.		NR-TX461
Freezer Star Rating		
Gross Volume (L) (ISO 8561)	Total	405
	Freezer	295
	Refrigerator	110
Outside Dimensions Width x Depth x Height (mm)		686 x 694 x 1764
Net Weight (kg)		65
Refrigerant Type		R600a
Rated Voltage (V) Rated Frequency (Hz)		Refer to the rating label attached inside the cabinet.

Memo

Imported by:

Panasonic Manufacturing Philippines Corporation
Ortigas Avenue Extension, Taytay, Rizal

Contact Center:

E-mail: pmpc_csdci@ph.panasonic.com

Tel. No.: (02) 8706-7603

Text hotline:

Globe/TM Users: Panasonic<space>message to 21584703

Smart/Sun/Talk'NText Users: Panasonic<space>message to 225654703

Website: www.panasonic.com/ph

Panasonic Corporation

Website: <http://www.panasonic.com>

© Panasonic Appliances Vietnam Co., Ltd. 2021