

Model No.: S-1821PU\*\*\* S-2430PU\*\*\* S-3448PU\*\*\*

Installation Instruction

Required tools for Installation Works

- |  |                      |                   |
|--|----------------------|-------------------|
| 1 Phillips screw driver                    | 7 Pipe cutter        | 15 Torque wrench  |
| 2 Flathead screwdriver                     | 8 Reamer             | 18 Nm (1.8 kg/m)  |
| 3 Level gauge                              | 9 Knife              | 42 Nm (4.3 kg/m)  |
| 4 Electric drill, hole core drill (ø70 mm) | 10 Gas leak detector | 55 Nm (5.6 kg/m)  |
| 5 Hexagonal wrench (4 mm)                  | 11 Measuring tape    | 65 Nm (6.6 kg/m)  |
| 6 Spanner                                  | 12 Thermometer       | 16 Vacuum pump    |
|  | 13 Megohmmeter       | 17 Gauge manifold |
|  | 14 Millimeter        |                   |

Explanation of symbols displayed on the indoor unit or outdoor unit.

- WARNING**: This symbol shows that this equipment uses a flammable refrigerant. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.
- CAUTION**: This symbol shows that the Installation Manual should be read carefully.
- CAUTION**: This symbol shows that a service personnel should be handling this equipment with reference to the Installation Manual.
- CAUTION**: This symbol shows that there is information included in the Operation Manual and/or Installation Manual.

SAFETY PRECAUTIONS

- Read the following "SAFETY PRECAUTIONS" carefully before installation.
- Electrical work must be installed by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model to be installed.
- The caution items are related to safety. The important contents are related to safety. The important contents of each indication use it as below. Incorrect installation due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.

- WARNING**: This indication shows the possibility of causing death or serious injury.
- CAUTION**: This indication shows the possibility of causing injury or damage to properties only.

The items to be followed are classified by the symbols:

- Symbol with white background denotes item that is PROHIBITED.
- Symbol with dark background denotes item that must be carried out.

- Carry out test running to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

- WARNING**
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unit method or using incompatible material may cause product damage, burst and serious injury.
  - Do not install outdoor unit near handrail of veranda. When installing air-conditioner unit on veranda of a high rise building, child may climb up to outdoor unit and cross over the handrail causing an accident.
  - Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.
  - Do not tie up the power supply cord into a bundle by hand. Abnormal temperature rise on power supply cord may happen.
  - Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.
  - Do not sit or step on the unit, you may fall down accidentally.
  - Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing.
  - When installing or relocating air conditioner, do not let any substance other than the specified refrigerant, eg. air etc. mix into refrigeration cycle (piping). Mixing of air etc. will cause abnormal high pressure in refrigeration cycle and result in explosion, injury etc.
  - Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.
  - Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.
    - For R32 model, use new piping, flare nut and tools which is specified for R32 refrigerant. Using of existing (R22) piping, flare nut and tools may cause abnormally high pressure in the refrigerant cycle (piping), and possibly result in explosion and injury. For R32 and R410A, the same flare nut on the outdoor unit side and pipe can be used.
    - Since the working pressure for R32/R410A is higher than that of refrigerant R22 models, replacing conventional piping and flare nuts on the outdoor unit side are recommended.
    - If reuse piping is unavoidable, refer to instruction ③ REFRIGERANT INSTALLATION (IN CASE OF REUSING EXISTING REFRIGERANT PIPING) in outdoor unit installation manual.
    - Thickness for copper pipes used with R32 must be more than 0.6 mm. Never use copper pipes thinner than 0.6 mm. For copper pipe ø15.88 or more use copper pipe thickness 0.8 mm and above.
    - It is desirable that the amount of residual oil less than 40 mg/10 m.

- Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause water leakage, electrical shock or fire.
- For refrigeration system work, install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.
- Use the attached accessories parts and specified parts for installation. Otherwise, it will cause the set to fall, water leakage, fire or electrical shock.
- Install at a strong and firm location which is able to withstand weight of the set. If the strength is not enough or installation is not properly done, the set will drop and cause injury.
- For electrical work, follow the national regulation, legislation and this installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.
- Do not use joint cable for indoor / outdoor connection cable. Use the specified indoor/outdoor connection cable, refer to instruction ⑥ ELECTRICAL WIRING and connect tightly for indoor/outdoor connection. Clamp the cable so that no external force will have impact on the terminal. If connection or fixed cable is not perfect, it will cause heat up or fire at the connection.
- Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause fire or electrical shock.
- This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD), with sensitivity of 30mA at 0.1 sec or less. Otherwise, it may cause electrical shock and fire in case of equipment breakdown or insulation breakdown.
- During installation, install the refrigerant piping properly before running the compressor. Operation of compressor without fixing refrigeration piping and valves at opened position will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc.
- During pump down operation, stop the compressor before removing the refrigeration piping. Removal of refrigeration piping while compressor is operating and valves are opened will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc.
- Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare may break and cause refrigerant gas leakage.
- After completion of installation, confirm there is no leakage of refrigerant gas. It may generate toxic gas when the refrigerant contacts with fire.
- Ventilate if there is refrigerant gas leakage during operation. It may cause toxic gas when the refrigerant contacts with fire.
- Be aware that refrigerants may not contain an odour.

- CAUTION**
- Do not install the unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.
  - Prevent liquid or vapor from entering sumps or sewers since vapor is heavier than air and may form suffocating atmospheres.
  - Do not overcharge the unit, refer to gas charge specification in Outdoor Installation manual. Overcharge will cause over current and damage to compressor.
  - Do not release refrigerant during piping work for installation, re-installation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.
  - Do not install this appliance in a laundry room or other location where water may drip from the ceiling, etc.
  - Do not touch the sharp aluminium fin, sharp parts may cause injury.
  - Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.
  - Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this air conditioner may increase the risk of rupture and this may result in loss damage or injury and/or property.
  - Indoor outdoor connection cable. Use power supply cord 4 x 2.5 mm<sup>2</sup> (2.0 - 6.0HP) type designation 60245 IEC 57 or heavier cord.
  - Installation work. It may need two people to carry out the installation work.
  - Keep any required ventilation openings clear of obstruction.

PRECAUTION FOR USING R32 REFRIGERANT


- The basic installation work procedures are the same as conventional refrigerant (R410A, R22) models. However, pay careful attention to the following points:
  - Do not perform flare connection inside a building or dwelling or room, when joining the heat exchanger of indoor unit with interconnecting piping. Refrigerant connection inside a building or dwelling or room must be made by brazing or welding. Joint connection of indoor unit by flaring method can only be made at outdoor or at outside of a building or dwelling or room. Flare connection may cause gas leak and flammable atmosphere.
  - The appliance shall be stored, installed and operated in a well ventilated room with indoor floor area larger than A<sub>min</sub> (m<sup>2</sup>) (Refer to Check of Density Limit) and without any continuously operating ignition source. Keep away from open flames, any operating gas appliances or any operating electric heater. Else, it may explode and cause injury or death.
  - Refer to "PRECAUTION FOR USING R32 REFRIGERANT" in outdoor unit installation manual for other precautions that need to pay attention to.

Check of Density Limit

The refrigerant (R32), which is used in the air conditioner, is a flammable refrigerant. So the requirements for installation space of appliance are determined according to the refrigerant charge amount [m.] used in the appliance.

Regarding the refrigerant charge amount [m.] used in the appliance, refer to the installation instructions for the outdoor unit.

The minimum indoor floor space compared with the amount of refrigerant is roughly as follows:



[m.] kg	[A <sub>min</sub> ] m <sup>2</sup>
1.84	3.7
1.9	3.8
2.0	4.0
2.1	4.2
2.2	4.4
2.3	4.6
2.4	4.8

$$A_{min} = (m. / (2.5 \times (LFL)^{0.65} \times h_c)) \times SF$$

A<sub>min</sub> = Required minimum room area, in m<sup>2</sup>  
 m. = Refrigerant charge in appliance, in kg  
 LFL = Lower flammability limit (0.307 kg/m<sup>3</sup>)  
 h<sub>c</sub> = Installation height of the appliance is 2.2 m.  
 SF = Safety factor with a value of 0.75

\*\* The required minimum room area, A<sub>min</sub>, shall also be governed by the safety factor margin formula below:

$$A_{min} = m. / (SF \times LFL \times h_c)$$

The higher value shall be taken when determining the room area.


m. ≤ 1.84 : Can be installed  
 1.84 < m. ≤ 2.4 : Can be installed above "Density Limit Line"  
 \*1 Refer to table and the installation instructions of indoor unit when deciding "Density Limit Line".

ACCESSORIES PACKED IN THE INDOOR UNIT CONTAINER

Part Name	Figure	Qty	Remarks	Part Name	Figure	Qty	Remarks
Full-scale installation diagram		1	Printed on container box	Drain hose		1	
Washer		8	For suspension bolts	Hose band		1	For securing drain hose
Screw		4	For full-scale installation diagram	Clamper		4	For electrical wiring


1 SELECTING THE LOCATION FOR THE INDOOR UNIT

- Provide a check port on the piping side ceiling for repair and maintenance.
- Install the indoor unit once the following conditions are satisfied and after receiving the customer approval.
  - The indoor unit must be within a maintenance space.
  - The indoor unit must be free from any obstacles in path of the air inlet and outlet, and must allow spread of air throughout the room.



- If the height from the floor to ceiling exceeds three meters, air flow distribution deteriorates and the effect is decreased.
- WARNING**
- The installation position must be able to support a load four times the indoor unit weight.
  - The indoor unit must be away from heat and sources of steam, but avoiding installation near an entrance.
  - The indoor unit must allow easy draining.
  - The indoor unit must allow easy connection to the outdoor unit.
  - Place the indoor unit according to the height from the ceiling shown in the illustration below.
  - The indoor unit must be at least 3 m away from any noise-generating equipment. The electrical wiring must be shielded with a steel conduit.
  - If the power supply is subject to noise generation, add a suppressor.
  - Do not install the indoor unit in a laundry. Electric shocks may result.
  - Installation height for indoor unit shall be at least 2.2 m.

- Note**
- Thoroughly study the following installation locations
    - In such places as restaurants and kitchens, considerable amount of oil steam and flour adhere to the turbo fan, the fin of the heat exchanger and the drain pump, resulting in heat exchange reduction, spraying, dispersing of water droplets, drain pump malfunction, etc. In these cases, take the following actions:
      - Make sure that the ventilation fan for smoke-collecting hood on a cooking table has sufficient capacity so that it draws oily steam which should not flow into the suction of the air conditioner.
      - Make sure there is enough distance from the cooking room to install the air conditioner in such place where it may not suck in oily steam.



- Avoid installing the air conditioner in such circumstances where cutting oil mist or iron powder exist, especially in factories, etc.
- Avoid places where inflammable gas is generated, flows-in, contaminated, or leaked.
- Avoid places where sulphurous acid gas or corrosive gas can be generated.
- Avoid places near high frequency generators.

4 INDOOR UNIT DRAIN PIPING

- During Drain Set Piping, install as shown in the figure below.
  - Do not use accessory drain hose with 90° bending
- Drain piping must have down-slope (1/50 to 1/100); be sure not to provide up-and-down slope to prevent reversal flow.
- During drain piping connection, be careful not to exert extra force on the drain port at the indoor unit.
- The outside diameter of the drain connection at the indoor unit is 32 mm.
- Piping material:** Polyvinyl chloride pipe VP-25 and pipe fitting.
- Be sure to perform heat insulation on the drain piping. (Refer to ⑤ HEAT INSULATION section heat insulators for drain piping & drain pipe installation).

- BEFORE PERFORMING THE INSTALLATION OF DRAIN PIPING**
- Limitations of Raising the Drain Pipe Connection
    - The drain pipe can be raised to a maximum height of 850 mm from the bottom of the ceiling.
    - Do not attempt to raise it higher than 850 mm.
  - Limitations of Drain Pipe Connection
    - Do not install the drain pipe with an upward gradient from the drain port connection. This will cause the drain water to flow backward and leak when the unit is not operating.
    - Do not install an air bleeder as this may cause water to spray from the drain pipe outlet.
    - Do not provide U-trap or bell shaped trap in the middle of the drain pipe. Doing so will cause abnormal sound.

3 REFRIGERANT PIPING

- CONNECTING THE PIPING TO INDOOR**
- For connection joint of all models  
 Please make flare after inserting flare nut (locate at joint position of tube assembly) onto the copper pipe. (In case of using long piping)
- Additional Precautions For R32 Models when connecting by flaring at indoor side
- Ensure to do re-flaring of pipes before connecting to units to avoid leaking
  - Seal sufficiently the flare nut (both gas and liquid sides) with neutral cure (Alkoxy type) & ammonia-free silicone sealant with neutral cure the gas leak caused by freezing.
  - Use of silicon containing ammonia can lead to stress corrosion on the joint & can cause leakage.

- Brazing for piping.
    - Execute brazing before tightening the flare nut.
    - Brazing must be executed while blowing nitrogen gas. (This prevents generation of oxidized scale in copper pipe.)
  - When there is a lot of brazings for long piping, install a strainer midway of the piping. (The strainer is field supplied.)
  - Use clean copper pipe with inner wall surface free from mist and dust. Blow nitrogen gas or air to blow off dust in the pipe before connection.
  - Form the piping according to its routing. Avoid bending and bending back the same piping point more than three times. (This will result in hardening of the pipe).
  - After deforming the pipe, align centers of the union fitting of the indoor unit and the piping, and tighten them firmly with wrenches.
  - Connect pipe to the service valve or ball valve which is located below the outdoor unit.
  - After completing the piping connection, be sure to check if there is gas leakage in indoor / outdoor connection.
- Confirm the union (thin side) is always at lower direction after connecting piping.



**VACUUM DRYING**

After completing the piping connection, execute vacuum drying for the connecting piping and the indoor unit.

Flare nut fastening torque N(m) (kg/cm)	S-1821PU***	S-2430PU***	S-3448PU***
Liquid	ø6.35 (1/4)	ø9.52 (3/8)	ø12.7 (1/2)
Gas	ø12.70 (1/2)	ø15.88 (5/8)	ø18.90 (3/4)

2 INSTALLATION OF INDOOR UNIT

- This air conditioner uses a drain up motor. Horizontally install the unit using a level gauge.
- CEILING OPENING DIMENSIONS AND HANGING BOLT LOCATION**
- The paper model for installation expand or shrink according to temperature and humidity. Check on dimensions before use it.
- CAUTION** During the installation, care must be taken not to damage electric wires.
- The dimensions of the paper model for installation are the same as those of the ceiling opening dimensions.
  - Be sure to discuss the ceiling drilling work with the workers concerned.



- Make sure the drain pipe has downward gradient (1/100 or more; downward from drain port connection).
- 
- Limitations of Drain Hose Connection
    - 90° Bending: Do not bend downwards on less than 0°.
    - 0 - 45° Bending: Trap prohibited. Doing so will cause abnormal sound.
- DRAIN TEST**
- The air conditioner uses a drain up motor to drain water. Use the following procedure to test the drain up motor operation.
- Connect the main drain pipe to exterior and leave it provisionally until the test comes to an end.
  - Feed water to the flexible drain hose and check the piping for leakage.
  - Be sure to check the drain up motor for normal operating and noise when electric wiring is complete.
  - When the test is complete, connect the flexible drain hose to the drain port.
- 

5 HEAT INSULATION

- CAUTION** Be sure to perform heat insulation on the drain, liquid and gas piping. Imperfection in heat insulation work leads to water leakage.
- HEAT INSULATORS FOR REFRIGERANT TUBES**
- Selection of heat insulation materials for refrigerant tube. When using the heat insulation materials (field supply), kindly check for its sizes and performance.
    - Material for insulation material:** Polyethylene foam.
    - Heat transfer rate:** less than 0.051 W/m.K.
    - Material withstand temperature:** up to 110°C Max.
    - Must be easy to use, age resistance and not easily absorb moisture.
    - Be sure to match the below insulation material size with tube sizes.
- | Piping size, mm (in) | Thermal insulation size (I.D.) | Thermal insulation Thickness               |
|----------------------|--------------------------------|--|
| 6.35 (1/4")          | 8 - 10 mm                      | Insulation thickness must 10 mm or greater |
| 9.52 (3/8")          | 12 - 15 mm                     |  |
| 12.70 (1/2")         | 14 - 16 mm                     |  |
| 15.88 (5/8")         | 16 - 20 mm                     |  |


- Tapping the flare nuts
    - Wrap the white insulating tape around the flare nuts at the gas tube connections.
    - Cover up the tube connection with tube insulator (field supply).
  - Tapping the tubes
    - Refrigerant tubes (and electrical wiring if local permit) should be taped together with armoured tape in 1 bundle. Keep drain hose separate from refrigerant tube to prevent condensation.
    - Wrap the armoured tape from the bottom of the outdoor unit to the tubing where it enters the wall. Overlap half of each previous turn.
    - Clamp the tubing to the wall, using 1 clamp approx. per each meter apart.
- 

PRECAUTIONS IN HIGH HUMIDITY CIRCUMSTANCES

- This air-conditioner has been tested according to the "JIS Standard Conditions with Mist" and have been confirmed that there are no faults. However, if it is operated for a long time in high humid atmosphere (dew point temperature: more than 23°C), water droplets are liable to fall. In this case, add heat insulation material according to the following procedures.
- Heat insulation material to be prepared. Adiabatic glass wool with thickness 10 to 20 mm.
  - Stick the wool on all air-conditioners that are located in cooling atmosphere.
  - In addition to the normal heat insulation (thickness: more than 10 mm) refrigerant piping (gas piping: thick piping) and drain piping, add a further of 10 mm to 30 mm thickness material.

HEAT INSULATORS FOR DRAIN PIPING & DRAIN PIPE INSTALLATION

- Selection of heat insulation materials for drain piping and drain pipe. When using the heat insulation materials (Field Supply). Kindly use the same size and performance as refrigerant tubes. Check for its sizes as below table:



- After checking the drainage, fully wrap it with drain insulator (Field Supply) around the drain hose
- 

- WALL SEAL**
- When the outdoor unit is installed in a higher position than the indoor unit, install the trap so as not to instill rain water into the wall by transmitting in piping.
  - Stuff the space among piping, the electric wire, and the drain hose with "Putty" and seal the penetration wall hole. Make sure that rain water does not instill into the wall.
- 

Put the incision at the trap part of the heat insulator (for water drainage)

CONTINUE TO THE NEXT PAGE


# 6 ELECTRICAL WIRING

As to main power source and cable size of outdoor unit, read the installation manual attached to the outdoor unit.

- This air conditioner must be installed in accordance with national wiring regulations.
- Cables connected to indoor unit must be approved polychloroprene sheathed type 60245 IEC 57 or H05RN-F/H07RN-F or heavier.
- The units must be connected to the supply cables for fixed wiring by qualified technician. Circuit breaker must be incorporated in the fixed wiring in accordance with the national wiring regulations. The circuit breaker must be approved, suitable for the voltage and current ratings of equipment and have a contact separation by 3mm in all poles. When the supply cable is damaged, it must be replaced by qualified technician.
- Be sure to install a current leakage breaker, main switch and fuse to the main power supply, otherwise electric shocks may result.
- Be sure to connect the unit to secure earth connection. If the earthing work is not carried out properly, electric shocks may result.
- Wiring shall be connected securely by using specified cables and fix them securely so that external force of the cables may not transfer to the terminal connection section. Imperfect connection and fixing leads to fire, etc.


- Select a power source that is capable of supplying the current required by the air conditioner.
- Feed the power source to the unit via a distribution switch board designed for this purpose, the switch should disconnect all poles with a contact separation of at least 3 mm.
- Always ground the air conditioner with a grounding wire and screw to meet the LOCAL REGULATIONS.
- Be sure to connect the indoor/outdoor unit connection wires correctly to terminal board.
- Be sure to turn off the main power before installing and connecting the remote controller.

**Note** If momentarily turning on the power supply for both the indoor and outdoor units, do not turn the power off after at least 1 minute has passed. (For the system's automatic setting.) Turning off the power supply on the way may cause an abnormal operation.




## CONNECTING THE WIRES TO THE CONTROL BOX

- Remove the 2 pcs of mounting screws, remove the control box cover and then connect the wires by following the procedure given in the illustration.




## Indoor Unit Wiring




**CAUTION** When linking the outdoor units in a network, it is necessary to install the terminating resistance. The installation method of the terminating resistance is different according to the connecting procedure of the inter-unit control wiring in the link.

Set the terminating resistance on the indoor unit control PCB. The setting of the terminating resistance at shipment is OPEN side (inoperative). If the shoring socket is replaced as shown below, the terminating resistance is SHORT side (operative). Change the setting of the terminating resistance at the nearest indoor unit and farthest indoor unit from the integrated control system to SHORT side (operative). The setting of 3 or more terminating resistances to SHORT side (operative) is prohibited.



## WIRE STRIPPING AND CONNECTING REQUIREMENT




**Note:** Isolating Devices (Disconnecting means) should have minimum 3.0 mm contact gap. Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires for safety reasons. Earth lead wire shall be longer than other lead wires as shown in the figure for the electrical safety in case of the cord slipping out of anchorage.

# 7 INSTALLATION OF DECORATIVE PANEL


- Before installing the decorative panel, always remove the paper template.

The decorative panel has its installation direction. Confirm the direction by displaying the piping side.

- Removing the air intake grille.
  - Remove the 2 screws on the latch of the air intake grille. (Reattach the air intake grille after installation of the panel for cassette.)
  - Slide the air intake grille catches in the direction shown by the arrows (1) to open the grille.
- Remove the corner cover in 4 corner places. Pull hook of corner cover as direction (1), then remove it by sliding out in direction (2).




- Adjust between decorative panel fixing hole and indoor unit screw hole.
- Fix decorative panel with 4 screws with already fix at paper model for installation.



- Adhere the cosmetic panel and ceiling wall together and confirm no gap in between. Readjust indoor unit height, if there is a gap between ceiling wall and decorative panel although it has been fixed by screw. If there is no effect to the indoor unit level and drain piping etc., the adjustment of indoor unit height can be adjusted through the corner cover hole. Tighten the fixing nut of the indoor unit back firmly after adjustment has been made.
- Open the indoor control box cover by removing 2 pcs of mounting screws.
- Insert the wiring panel connector firmly to indoor PCB CN011 LM. Be cautious not to clamp the cord in between control board and control box cover.
- After completion, install the parts removed by following reverse procedure.

**WARNING** Be sure to hook the air inlet grill string, to prevent grill from falling and causing injury from it.

Refer to the Wireless Remote Controller Installation Manual for the details of wireless remote controller settings and Receptor Unit Installation.



## HOW TO ATTACH THE CORNER COVER

- Check that the safety cord from the corner cover is fastened to the panel for cassette pin, as shown in the figure below.
- Use the supplied screws to attach the corner cover to the panel for cassette.


# 8 TEST RUN

## Precautions

- Request that the customer be present when the test run is performed. At this time, explain the operation manual and have the customer perform the actual steps.
- Check that the 220 - 240 VAC power is not connected to the inter-unit control wiring connector terminal. If 220 - 240 VAC is accidentally applied, the indoor unit control PCB fuse will blow in order to protect the PCB. In this case, make the wiring correctly. Then disconnect the 2P connectors (OC) that are connected to the indoor unit control PCB, and replace them with 2P connectors (EMG).

**Note** For new product first time power on after installation, the system requires approximately 5 minutes for "System Auto Configuration Process". The system is not turn on or respond to remote controller immediately after power on.

## Test Run Procedure



## 1 Items to Check Before the Test Run

- Turn the wired remote power switch ON at least 5 hours in advance in order to energize.
- Fully open the closed valves on the liquid tubing and gas tubing sides.
- Check the wiring of indoor and outdoor unit.

## 2 Check the Wiring of Indoor & Outdoor Unit

- Separate the power supply and connection cable between outdoor and indoor unit

## 3 Address Setting


The displays of the earth, outdoor unit power supply wiring and earth leakage circuit breaker are omitted.

- System connection**
  - When turning on all indoor and outdoor units, the auto address will start. It takes maximum 10 minutes.
  - When the auto address setting is completed, wait at least 1 minute and 30 seconds. Then start the operation.


## 4 Checking the Indoor Unit Addresses

Use the wired remote controller to check the indoor unit address.


### CZ-RTCSB (High-spec wired remote controller)



### CZ-RTC4 (Timer remote controller)




### CZ-RTC6 (Wired remote controller)



## 5 Test Run Using the Remote Controller


### CZ-RTCSB (High-spec wired remote controller)

This mode places a heavy load on the machines. Therefore use it only when performing the test run.




### CZ-RTC4 (Timer remote controller)

This mode places a heavy load on the machines. Therefore use it only when performing the test run.





### CZ-RTC6 (Wired remote controller)

This mode places a heavy load on the machines. Therefore use it only when performing the test run.




**Note** The outdoor units will not operate for approximately 3 minutes after the power is turned ON and after operation is stopped.



## CZ-RTC6 series (Wired Remote Controller)

### Optional Parts

This mode places a heavy load on the machines. Therefore use it only when performing the test run.



**Note** The outdoor units will not operate for approximately 3 minutes after the power is turned ON and after operation is stopped.

# CARE AND CLEANING


**WARNING** For safety, be sure to turn the air conditioner off and also to disconnect the power before cleaning. Do not pour water on the indoor unit to clean it. This will damage the internal components and cause an electric shock hazard.

**Air intake and outlet side (Indoor unit)** Clean the air intake and outlet side of the indoor unit with a vacuum cleaner brush, or wipe them with a clean, soft cloth. If these parts are stained, use a clean cloth moistened with water. When cleaning the air outlet side, be careful not to force the vanes out of place.

**CAUTION** Never use solvents or harsh chemicals when cleaning the indoor unit. Do not wipe plastic parts using very hot water. Some metal edges and the fins are sharp and may cause injury if handled improperly; be especially careful when you clean these parts. The internal coil and other components of outdoor unit must be cleaned regularly. Consult your dealer or service center.

**Air filter** The air filter collects dust and other particles from the air and should be cleaned at regular intervals or when the filter indication (Filter) on the display of the remote controller (wired type) shows that the filter needs cleaning. If the filter gets blocked, the efficiency of the air conditioner drops greatly.

**After Cleaning** 1. After the air filter is cleaned, reinstall it in its original position. Be sure to reinstall in reverse order. 2. In the case of Timer Remote Controller) Press the Filter reset button. The (Filter) indicator on the display goes out.




**Note** The frequency with which the filter should be cleaned depends on the environment in which the unit is used. Clean the filter frequently for best performance in the area of dusty or oil spots regardless of filter status.

**-How to clean the filter-** 1. Remove the air filter from the air intake grille. 2. Use a vacuum cleaner to remove light dust. If there is sticky dust on the filter, wash the filter in lukewarm, soapy water, rinse it in clean water, and dry it. **-How to remove the filter-** 1. Use a screwdriver to remove the bolt screw on each side for the two latches. (Be sure to reattach the two bolt screws after cleaning.) 2. Slide the latches of the air intake grille in the direction of the inside to open the grille. 3. The air intake grille opens downward.

**CAUTION** When cleaning the air filter, never remove the safety strap. If it is necessary to remove it for servicing and maintenance inside, be sure to reinstall the safety strap securely (hook on the grille side) after the work.

When the filter has been removed, rotating parts (such as the fan), electrically charged areas, etc. will be exposed in the unit's opening. Bear in mind the dangers that these parts and areas pose, and proceed with the work carefully.



**CAUTION** Certain metal edges and the condenser fins are sharp and may cause injury if handled improperly; special care should be taken when you clean these parts. Periodically check the outdoor unit to see if the air outlet or air intake is clogged with dirt or soot. The internal coil and other components must also be cleaned periodically. Consult your dealer or service center.

**Care: After a prolonged idle period** Check the indoor and outdoor unit air intakes and outlets for blockage; if there is a blockage, remove it. **Care: Before a prolonged idle period** Operate the fan for half a day to dry out the inside. Disconnect the power supply and also turn off the circuit breaker. Clean the air filter and replace it in its original position. Outdoor unit internal components must be checked and cleaned periodically. Contact your local dealer for this service.

## CHECK THE FOLLOWING ITEMS WHEN INSTALLATION IS COMPLETE

- After completing work, be sure to measure and record trial run properties, and store measuring data, etc.
- Measuring items are room temperature, outside temperature, suction temperature, blow out temperature, wind velocity wind volume, voltage, current, presence of abnormal vibration and noise, operating pressure, piping temperature, compressive pressure, airtight pressure.
- As to the structure and appearance, check the following items.
  - Is circulation of air adequate?
  - Is there any leakage of refrigerant?
  - Are the terminal screws loosened?
  - Is draining smooth?
  - Is remote controller switch operated?
  - M3...69-98N\*cm (7-10kg\*cm)
  - Is heat insulation complete (refrigerant and drain piping)?
  - Is there any faulty wiring?
  - M4...157-196N\*cm (16-20kg\*cm)
  - M5...196-245N\*cm (20-25kg\*cm)

## HAND OVER

Teach the customer the operation and maintenance procedures, using the operation manual (air filter cleaning, temperature control, etc.).

## Optional Parts

Refer to Installation manual of optional parts (sold separately).

## As for work specifications of the outdoor unit, read the OUTDOOR UNIT INSTALLATION MANUAL attached to the outdoor unit.




# 6 PENDAWAIAN ELEKTRIK

Bagi sumber kuasa utama dan saiz kabel unit luaran, baca manual pemasangan yang dibekalkan bersama unit luaran.

- Penyaman udara ini mestilah dipasang mengikut peraturan pendawaian negara.
- Kabel yang bersambung dengan unit dalam mestilah jenis bersarung polikloroprena yang diluluskan 60245 IEC 57 atau H05RN-F/H07RN-F atau yang lebih berat.
- Unit ini mesti disambungkan kepada kabel bekalan untuk pendawaian kekal oleh jurutekan yang berkekeluargaan. Pemutus litar mesti dipasang dalam pendawaian kekal menurut peraturan pendawaian negara.
- Pemutus litar mestilah yang diluluskan, sesuai dengan voltan dan kadar arus peralatan serta pemisahan sambungan sebanyak 3mm dalam semua kutub.
- Apabila kabel bekalan rosak, ia mestilah diganti oleh jurutekan yang berkekeluargaan.
- Pastikan anda memasang pemutus bocoran arus, sesua utama dan fuis kepada bekalan kuasa utama, kerana jika tidak, kejutan elektrik mungkin berlaku.
- Pastikan anda menyambungkan unit ini kesambungan bumi selamat. Sekiranya kerja pembumian tidak dilakukan dengan betul, kejutan elektrik mungkin berlaku.
- Wayar mestilah disambungkan dengan selamat menggunakan kabel yang ditetapkan dan lakukan pendawaian dengan sempurna supaya daya luar kabel tidak akan dipindahkan ke bahagian sambungan terminal.
- Penyambungan dan pemasangan yang tidak sempurna boleh mengakibatkan kebakaran, dll.

- Pilih sumber kuasa yang berupaya membekalkan arus yang diperlukan oleh penyaman udara ini.
- Sambungkan punca kuasa dengan unit melalui papan suis pengalihan yang direka bentuk untuk tujuan ini. Suis hendaklah diputuskan sambungannya di semua kutub dengan pemisahan sambungan sekurang-kurangnya 3 mm.
- Sentiasa bumikan penyaman udara dengan dawai pembumian dan skru supaya mematuhi PERATURAN TEMPATAN.
- Pastikan anda menyambungkan wayar penyambungan unit dalam/luaran ke papan terminal.
- Pastikan anda mematkan kuasa utama sebelum memasang dan menyambungkan alat kawalan jauh.


**Nota** Jika anda ingin menghidupkan bekalan kuasa bagi kedua-dua unit dalam dan luaran sebentar, jangan matikan kuasa sehingga sekurang-kurangnya selepas 1 minit berlaku. (Unit tetapan automatik sistem.) Mematkan bekalan kuasa pada pertengahan operasi boleh menyebabkan operasi tidak normal.



**Nota** Untuk Bahagian Pilihan yang menghubungkan saiz pendawaian, rujuk kepada Manual Pemasangan Bahagian Pilihan.


### MENYAMBUNGKAN WAYAR KE KOTAK KAWALAN

- Keluarkan 2 skru pemasangan, buka penutup kotak kawalan, kemudian sambungkan wayar dengan mengikut prosedur yang diberikan di dalam gambarajah.





**AWAS** Pastikan skru terminal tidak longgar.

### PENDAWAIAN UNIT DALAMAN



**AWAS** Semasa menghubungkan unit luaran dalam rangkaian, rintangan penamatan hendaklah dipasang. Kaedah pemasangan rintangan penamatan adalah berbeza mengikut prosedur penyambungan pendawaian kawalan antara unit di dalam pautan.

Tetapan rintangan penamatan pada kawalan unit dalam PCB. Tetapan rintangan penamatan pada waktu penghantaran adalah pada bahagian OPEN (tidak beroperasi). Jika soket litar pintas digantikan seperti di bawah, rintangan penamatan adalah pada bahagian SHORT (beroperasi). Ubah tetapan rintangan penamatan pada unit dalam terkecik dan unit dalam terjah daripada sistem kawalan bersepadu kepada bahagian SHORT (beroperasi).



**KEPERLUAN PEMBUANGAN PEMBALUT WAYAR DAN PENYAMBUNGAN**

Pembuangan pembalut wayar

Penebat masuk sepenuhnya

Penebat terlebih masuk

Penebat tidak masuk sepenuhnya

TERIMA

DILARANG

DILARANG

Alat ini mesti dibumikan dengan betul.

**Nota:** Peranti Pengasing (Cara pemutusan sambungan) hendaklah mempunyai ruang sentuh sekurang-kurangnya 3.0 mm. Wayar Bumi hendaklah berwarna Kuning/Hijau (YG) dan lebih panjang daripada wayar AC yang lain untuk tujuan keselamatan.

- Wayar plumbum mesti hendaklah lebih panjang daripada wayar plumbum yang lain seperti yang ditunjukkan di dalam rajah bagi keselamatan elektrik sekiranya kord terkeluar dari tambatan.


# 7 PEMASANGAN PANEL HIASAN

Sebelum memasang panel hiasan, templat kertas mesti dikeluarkan dahulu.

- Penanggalan jerji pengambilan udara.
  - Tanggalan 2 skru pada selak jerji salur masuk udara. (Pasang semula jerji pengambilan udara selepas pemasangan panel untuk kaset.)
  - Gelongsorkan perangkap jerji pengambilan udara mengikut arah yang ditunjukkan oleh anak panah 1 untuk membuka jerji.
- Keluarkan penutup penjuror di 4 penjuror. Tarik cangkuk penutup penjuror pada arah 1, kemudian tangkalkannya dengan meluncur keluar pada arah 2.




**AWAS** Pasang panel hiasan dengan selamat. Udara sejuk boleh menyebabkan peluwapan = Titis air jatuh.




**AMARAN** Pastikan anda mencangkuk tali gril arus masuk udara untuk menghalang gril daripada terjatuh lalu menyebabkan kecederaan.

- Letakkan panel kosmetik bersama siling dan pastikan tiada ruang di antaranya. Laraskan semula ketetapan unit dalam dan jika terdapat ruang di antara siling dengan panel hiasan walaupun telah dipasang dengan skru. Jika tiada kesan pada aras unit dalam dan perpaian saliran, dan sebagainya, ketetapan unit dalam boleh dilaraskan melalui lubang penutup penjuror. Ketatkan kembali tali pemasangan unit dalam dengan rapi selepas dilaraskan semula.
- Buka penutup kotak kawalan dalam dengan menanggalkan dua skru pemasangan.
- Masukkan penyambung panel wayar dengan rapi ke ruang dalam PCB CN011 LM.
- Berhati-hati supaya tidak mengkipkan kord di antara papan kawalan dengan penutup papan kawalan.
- Selepas siap, pasanglah bahagian yang dikeluarkan dengan mengikut prosedur terbaik.



**AMARAN** Rujuk kepada Manual Pemasangan Alat Kawalan Jauh Wayarles untuk butiran tetapan alat Kawalan Jauh Wayarles dan Pemasangan Unit Penerima.



**CARA PEMASANGAN PENUTUP PENJURU**


- Periksa sama ada kord keselamatan pada penutup penjuror diletakkan pada panel untuk pin kaset, sebagaimana ditunjukkan di dalam rajah di bawah.
- Gunakan skru yang dibekalkan untuk memasang penutup penjuror pada panel untuk kaset.

# 8 JALANAN UJIAN


**Langkah berjaga-jaga**

- Pelanggan mestilah hadir bersama semasa jalanan ujian dijalankan.
- Pada waktu ini, terangkan manual operasi dan minta pelanggan melakukan langkah sebenar.
- Periksa sama ada kuasa 220-240 VAC tidak disambungkan dengan terminal penyambung pendawaian kawalan antara unit. Sekiranya kuasa 220-240 VAC digunakan secara tidak sengaja, fuis unit kawalan dalam PCB akan terputus untuk melindungi PCB. Dalam kes ini, pastikan pendawaian dipasang dengan betul.
- Kemudian putuskan pendawaian penyambung 2P (OC) yang disambungkan ke kawalan unit dalam PCB, dan gantikan ia dengan penyambung 2P (EMC).
- Sekiranya operasi tidak dapat dijalankan selepas menukar penyambung coklat, potong pelompot pada kawalan unit dalam PCB.
- (Sila pastikan bekalan kuasa OFF sebelum menjalankan kerja ini)

**Nota** Untuk produk baharu yang baru pertama kali dihidupkan, sistem memerlukan anggaran 5 minit untuk "Proses Konfigurasi Auto Sistem". Sistem tidak dihidupkan atau bertindak balas kepada alat kawalan jauh dengan segera selepas kuasa dihidupkan.



- Item untuk Diperiksa Sebelum Menjalankan Ujian Jalanan**
  - Hidupkan suis kuasa jauh berwayar kepada ON sekurang-kurangnya 5 jam lebih awal untuk memberikannya kuasa.
  - Buka sepenuhnya inip yang tertutup pada bahagian tiub cecair dan tiub gas.
  - Periksa wayar unit dalam dan luaran.
- Periksa Wayar Unit Dalam & Luaran**
- Pengesetan Alamat**




**Nota** Paparan bumi, wayar bekalan kuasa unit luaran dan pemutus litar bocor bumi akan hilang. **Sambungan sistem**

- Semasa menghidupkan semua unit dalam dan luaran, alamat auto akan bermula. Maksimum masa yang diambil adalah 10 minit.
- Apabila tetapan alamat auto telah selesai, tunggu sekurang-kurangnya 1 minit dan 30 saat. Kemudian, mulakan operasi.

**4 Memeriksa Alamat Unit Dalam**

Gunakan alat kawalan jauh berwayar untuk memeriksa alamat unit dalam.



**CR-RTCSB (Alat kawalan jauh berwayar spesifikasi tinggi)**

- Tekan dan tahan butang dan butang selama 4 saat atau lebih (mod tetapan mudah).
- Alamat yang dipaparkan pada unit dalam adalah bersambung dengan alat kawalan jauh berwayar. (Alamat unit dalam yang disambungkan dengan kawalan jauh sahaja yang boleh diperiksa).
- Tekan butang sekali lagi untuk kembali kepada mod kawalan jauh berwayar.

**CR-RTC4 (Alat kawalan jauh pemasa)**

- Teruskan menekan butang dan secara serentak untuk 4 saat atau lebih. Skrin "Maintenance func" muncul pada paparan LCD.
- Tekan butang atau untuk melihat setiap menu. Pilih "Simple settings" pada paparan LCD dan tekan butang.
- Skrin "Simple settings" muncul pada paparan LCD. Pilih "Unit no." dengan menekan butang atau untuk perubahan. \* Paparan awal adalah "ALL". Kipas unit dalam hanya beroperasi pada unit dalam tertentu.
- Tekan butang dan pilih "YES" untuk memulakan semula.

**5 Jalanan Ujian Menggunakan Alat Kawalan Jauh**

**CR-RTCSB (Alat kawalan jauh berwayar spesifikasi tinggi)**

- Teruskan menekan butang dan secara serentak untuk 4 saat atau lebih. Skrin "Maintenance func" muncul pada paparan LCD.
- Tekan butang atau untuk melihat setiap menu. Jika anda ingin melihat skrin seterusnya serta-meria, tekan butang atau. Pilih "4. Test run" pada paparan LCD dan tekan butang.
- Ubah paparan daripada "OFF" kepada "ON" dengan menekan butang atau. Kemudian tekan butang.
- Tekan butang "TEST" akan dipaparkan di paparan LCD.
- Tekan butang, Jalanan ujian akan dimulakan. Skrin mod tetapan jalanan ujian muncul di paparan LCD.
  - Jalanan ujian boleh dijalankan dengan menggunakan mod operasi HEAT, COOL atau FAN.
  - Suhu tidak boleh dilaraskan apabila dalam mod jalanan ujian.
  - Jika operasi pembetulan tidak boleh dijalankan, kod akan dipaparkan pada paparan LCD kawalan jauh. (Berkenaan dengan kandungan penggera, periksa Arahkan Operasi.)
- Selepas jalanan ujian selesai, tekan butang sekali lagi. Tekan butang "OFF" di Langkah (2).
  - Untuk mengelakkan jalanan ujian berterusan, alat kawalan jauh ini mempunyai fungsi pemasa yang membatalkan jalanan ujian selepas 60 minit.

**Nota**


- Unit luaran tidak akan beroperasi untuk anggaran 3 minit selepas kuasa dihidupkan kepada ON dan selepas kuasa dimatikan.

**CR-RTC4 (Alat kawalan jauh pemasa)**

- Tekan butang alat kawalan jauh berwayar selama 4 saat atau lebih. Kemudian tekan butang "TEST" muncul pada paparan LCD semasa jalanan ujian sedang berjalan.
  - Jalanan ujian boleh dijalankan dengan menggunakan mod operasi HEAT, COOL atau FAN.
  - Suhu tidak boleh dilaraskan sewaktu berada dalam mod jalanan.
  - Sekiranya operasi betul tidak dapat dijalankan, kod akan dipaparkan pada paparan LCD kawalan jauh berwayar. (Berkenaan dengan kandungan penggera, periksa Arahkan Operasi.)
- Selepas jalanan ujian selesai, tekan butang sekali lagi. Tekan butang "TEST" yang hilang di paparan LCD.
  - Untuk mengelakkan jalanan ujian berterusan, alat kawalan jauh berwayar ini mempunyai fungsi pemasa yang membatalkan jalanan ujian selepas 60 minit.

**Nota**

- Unit luaran tidak akan beroperasi untuk anggaran 3 minit selepas kuasa dihidupkan kepada ON dan selepas kuasa dimatikan.



**Penapis udara**

Penapis udara akan mengumpul debu dan partikel lain dari udara dan hendaklah dibersihkan secara kerap atau apabila penunjuk penapis pada paparan alat kawalan jauh (enis berwayar) menunjukkan penapis perlu dibersihkan. Jika penapis tersumbat, kecekapan penyaman udara akan menurun dengan banyak.

**Selepas Pembersihan**

- Selepas penapis udara dibersihkan, pasang semula dalam kedudukannya yang asal. Pastikan untuk memasang semula dalam urutan songsang.
- (Bagi Alat Kawalan Jauh Pemasa) Tekan butang tetap semua Penapis. Penunjuk (Penapis) pada paparan terpadam.

**Nota**

- Kekurangan untuk membersihkan penapis bergantung pada persekitaran di tempat unit digunakan.
- Bersihkan selalu penapis untuk mendapatkan prestasi yang terbaik di kawasan yang berdebu atau mempunyai tompokan berminyak tanpa mengira status penapis.
- Carilah penapis yang sesuai untuk membersihkan penapis.
- Keluarkan penapis udara dari jerji pengambilan udara.
- Gunakan pembersih hampagas untuk mengeluarkan debu ringan. Jika terdapat debu melekit pada penapis, basuh penapis dengan air sabun yang suam, biasanya dalam air bersih dan keringkannya.
- Carilah penapis yang sesuai untuk membersihkan penapis.
- Gunakan pemutar skru untuk menanggalkan skru bolt di setiap sisi kedua-dua selak. (Pastikan anda memasang semula skru bolt selepas memberskannya.)
- Gelongsorkan jerji pengambilan udara dari arah dalam untuk membuka jerji.
- Jerji pengambilan udara terbuka ke bawah.


- Semasa membersihkan penapis udara, jangan sesekali menanggalkan tali keselamatan. Sekiranya perlu untuk menanggalkan bagi tujuan servis atau penyelenggaraan di dalam, sila pastikan untuk memasang semula tali keselamatan dengan rapi (dicangkuk pada sebelah jerji) selepas kerja-kerja servis dan penyelenggaraan.
- Apabila penapis telah ditanggalkan, bahagian pemutar (seperti kipas, kawalan bercahaya dan lain-lain akan terdedah kepada bahagian pembuangan unit. Sentiasa beringat kepada bahaya yang diakibatkan oleh bahagian dan elektronik ini serta lakukan kerja dengan berhati-hati
- Tolak bahagian penapis udara yang ditandakan dengan anak panah dan tarik ke arah atas. Penapis udara akan dibebaskan.

**Penjagaan: Selepas tempoh tidak digunakan yang berpanjangan**

Jika pengambilan udara dan salur keluar pada unit dalam dan luaran tersumbat, keluarannya.

**Penjagaan: Sebelum tempoh tidak digunakan yang berpanjangan**

- Jalankan kipas selama setengah hari untuk mengeringkan bahagian dalam.
- Putuskan bekalan kuasa dan juga matikan pemutus litar.
- Bersihkan penapis udara dan letakkannya semula pada kedudukan asal.
- Komponen dalam unit luaran mesti diperiksa dan dibersihkan dari semasa ke semasa. Sila hubungi pengedar setempat atau untuk mendapatkan servis ini.



**PERIKSA PERKARA-PERKARA BERIKUT APABILA PEMASANGAN SELESAI**

- Selepas menyalakan kerja, pastikan anda menyukat dan merekodkan sila-silat jalanan ujian, dan simpan data penyukat, dll.
- Jalankan kipas selama setengah hari untuk mengeringkan bahagian dalam.
- Putuskan bekalan kuasa dan juga matikan pemutus litar.
- Bersihkan penapis udara dan letakkannya semula pada kedudukan asal.
- Komponen dalam unit luaran mesti diperiksa dan dibersihkan dari semasa ke semasa. Sila hubungi pengedar setempat atau untuk mendapatkan servis ini.

**Penyerahan**

- Ajaran prosedur operasi dan penyelenggaraan kepada pelanggan, dengan menggunakan manual operasi (pembersihan penapis udara, kawalan suhu, dll.)
- Rujuk manual pemasangan bahagian pilihan (dijual berasingan).

**Bagi spesifikasi kerja unit luaran, baca MANUAL PEMASANGAN UNIT LUARAN yang dibekalkan bersama unit luaran.**

**B.MALAYSIA**  
Teks Inggeris adalah arahan asal.

Bahasa-bahasa lain adalah terjemahan bagi arahan asal.

型號： S-1821PU\*\*\* S-2430PU\*\*\* S-3448PU\*\*\*

安裝說明

注意 R32 冷媒 此空調節能機包含 R32 冷媒劑並利用 R32 冷媒劑進行操作。須由具備資質的人員對此產品進行安裝或檢修。

安裝時所需的工具 1 菲力螺絲起子 7 剪管器 15 扭力扳手 2 一字螺絲起子 8 擷孔器 18 Nmm (1.8 kgfcm) 3 水平儀 9 刀 42 Nmm (4.3 kgfcm) 4 電鑽、空心鑽 (直徑 870 mm) 10 漏氣偵測器 55 Nmm (5.6 kgfcm) 5 六角板手 (4 mm) 11 膠尺 65 Nmm (6.6 kgfcm) 6 扳子 12 溫度計 16 真空表 13 高阻表 17 真空管 14 萬用電表

安全措施

- 安裝之前請詳細閱讀此“安全指南”。 電氣工作必須由具備資質的人員進行。 請務必使用有正確額定電壓的插頭與主電路。 請務必遵照所述注意事項，因為其重要內容與您的安全息息相關。各符號的意義如下。忽視指示造成安裝不當，可能會導致受傷或損壞，其嚴重程度如下所示。

警告 此符號表示可能導致死亡或重傷。 注意 此符號表示可能只導致受傷或機件損壞。

應遵照的注意事項乃依以下符號分類： 白色底的符號表示被禁止的項目。 深色底的符號表示必須進行的項目。

- 安裝後進行運轉測試以確保一切正常操作。接著，依照使用說明書向使用者解釋操作，照顧和保養之方法。請提醒使用者妥善保存使用說明書以供將來參考之用。

警告

- 除非按照這指南，否則切勿使用工具加速除霜過程或進行清理。任何不適當的方法或使用不適當的材料可能導致產品損壞、破裂或嚴重損害。 不要將室外機安裝在靠近陽臺的扶手。當在高樓的陽臺安裝空調調節機時，必須注意小孩可能會爬上室外機並爬出扶手，繼而導致意外發生。 勿使用非指定電纜、改裝電纜、接駁電纜或延長電纜作為電源電纜。勿與其他電器共用一個插頭。接觸不良、絕緣不良或電線超額將會導致觸電或火災。 切勿用帶子將電源電纜繫成一捆。電源電纜可能會異常升溫。 切勿將您的手指或其他物體插入本機，高速轉動的風扇可能會導致損傷。 切勿坐或踩踏在本機上以免意外摔跤。 將塑膠袋 (包裝材料) 遠離小孩，它可能會粘附在鼻子和嘴巴導致窒息。 當安裝或重新安裝空調調節機時，除指定冷媒劑外，勿讓任何物體、例如空氣管等，混入製冷循環系統 (導管)。空氣管等的加入將會導致製冷循環系統出現異常高壓並導致爆炸、受傷等等。 切勿切割或燃燒，因為本設備已加壓。切勿讓本設備接觸高溫、明火或任何其他火源。否則，可能發生爆炸，導致受傷或死亡。 切勿切割或更換指定型號以外的冷媒劑。這可能會導致產品損壞、破裂、損傷等等。

- 關於 R32 型號，請使用為 R32 冷媒劑設計的新管道、擷口螺絲母和工具。使用現有的 (R22) 導管、擷口螺絲母及工具可能會導致 (導管) 冷媒洩漏出現等異常高壓。這可能會造成爆炸和受傷。對於 R32 和 R410A，可使用同樣的室外機擷口螺絲母和導管。 由於 R32/R410A 的工作壓力高於冷媒劑 R22 運行的工作壓力，因此建議更換室外機時的安裝規程和擷口螺絲母。 如果不可避免地要重複使用管道，請參閱說明書 ③ 冷媒劑的安裝 (在重新使用現有冷媒劑配置的情況下) 在室外機安裝手冊中。 與 R32 一起使用的銅管的厚度必須大於 0.6 mm，切勿使用小於 0.6 mm 的銅管。銅管 φ 15.88 或以上，請使用 0.8 mm 或以上的銅管。 殘油的數量最好低於 40 mg/10 m。

- 僱用授權代理人或專人代為安裝。如果用戶自行安裝不正確，將會引起漏電、觸電或火患。 製冷系統作業時，應嚴格按照本安裝說明進行安裝。安裝不得法將會引起漏電、觸電或火患。 安裝時請使用所列之附送或指定之配件。否則這將導致本機掉漆、漏水、火災或觸電。 安裝于堅固和牢固足以支撐空調調節機之重量的位置。如果堅固度不足或安裝不得法，空調調節機將會掉下和致傷人。 應遵循國家法規、法律及本安裝說明手冊進行電氣作業。一定要使用獨立電路有單一出口。若電路容量不夠或電線安裝出錯，會導致觸電或火患。 勿使用接駁電纜為室內/室外連接電纜。使用特定的室內/室外連接電纜，請參閱符號 ⑥ 電纜佈線，並緊緊地把室內/室外連接起來。火災電纜，使電力對漏子無效。若漏電和安裝不安，會導致接駁處發熱或產生火患。 電纜排列須妥當安排，以避免暴露控制板蓋。如果控制板蓋沒有完全地蓋好，它可能會導致火患或觸電。 強力建議為此設備安裝漏電斷路器 (ELCB) 或殘餘電流裝置 (RCD)。否則，當設備故障或絕緣故障等情況發生時可能會導致觸電或火患。 進行安裝時，請在啟動壓縮機前妥善地安裝冷媒劑導管。在沒有安裝冷媒劑導管和將開關設置於開放位置的情況下操作壓縮機將會導致空氣被吸入、製冷循環系統出現異常高壓並導致爆炸、受傷等等。 在進行抽氣操作時，請在拆除冷媒劑導管之前關閉壓縮機。在壓縮機正在操作和在開放狀態的情況下拆除冷媒劑導管將會導致空氣被吸入、製冷循環系統出現異常高壓並導致爆炸、受傷等等。 根據所設定的方法使用扭力扳手鎖緊接頭螺絲母。如果將接頭螺絲母鎖得太緊，經過一段時間後，接頭螺絲母可能會爆裂和導致冷媒氣洩漏。 安裝完畢後，請確認沒有冷媒氣洩漏。冷媒劑一旦和火接觸可能會產生有毒氣體。 若在操作期間發生冷媒氣洩漏，請立刻進行通風。冷媒劑一旦和火接觸可能會產生有毒氣體。 應意識到冷媒劑不得有氣味。

注意

- 勿將空調調節機安裝于易燃氣體可能滲漏之處。氣體滲漏和積存于空調調節機周圍可能會引起火患。 防止液體或蒸氣進入污水坑或下水道，因為蒸氣比空氣重，可能形成窒息氣氛。 請勿防止設備過熱，請參閱《室外安裝手冊》中的空氣規格。過熱會導致電流超額並損壞壓縮機。 進行驗收工作、重新安裝和維修冷媒劑時不要取出冷媒劑。 小心處理液體製冷劑，它可能會導致凍傷。 請勿安裝本裝置於洗衣房或其他有水自天花板等滴落之處。 切勿觸摸尖銳的鋸齒刀片以免受到尖銳部件傷害。 依照安裝說明書安裝排水管。排水管若安裝不當，水瀉可能會弄濕房間和損壞家具。 選擇容易進行維修工作的安裝位置。 此空調節能機安裝、檢修或維修不當可能增加破裂的風險，因而可能導致損壞、損壞或受傷和/或財物損失。 室內外連接電纜。 請使用 4 x 2.5 mm² (2.0 ~ 6.0HP) 類型標明為 60245 IEC 57 或更重的電纜為電源電纜。 安裝工作。 安裝工作可能動用兩人。 確保所有通風口保持暢通無阻。

使用 R32 冷媒劑注意事項

- 基本安裝步驟如同常規冷媒劑 (R410A, R22) 型號。 但是，務必注意以下幾點： 當將室內機之熱交換器與連接配管相連接時，切勿在建築物、住宅或空間內進行擴口連接。必須通過接駁或接駁來完成建築物、住宅或空間內的冷媒劑管連接。只能在室外或者建築物、住宅或空間之外以擴口方式進行室內機與接駁連接。擴口連接可能導致漏氣和易燃性氣體。 本設備應僅存、安裝并工作於通風良好的空間內，室內面積應大於 Amin (m²) (參見密度極限檢查) 並且不存在任何連續操作的點火源。遠離明火、任何工作中的燃氣設備或任何工作中的電熱器。否則，可能發生爆炸，導致受傷或死亡。 有關其他注意事項，請參閱室外機安裝手冊中的“使用 R32 冷媒劑的注意事項”。

檢查密度極限

空調中使用的冷媒劑 (R32) 是一種易燃冷媒劑。因此，設備的安裝空間要求是根據冷媒劑充注量 [m] 在設備中使用。關於冷媒劑充注量 [m]，請參閱室外機的安装說明。與冷媒劑量相比，最小的室內佔地面積大致如下：





Table with columns [m] kg and [Amin] m². It provides specific values for different refrigerant charge amounts and corresponding minimum indoor area requirements.

室內機是包裝中所附的配件

Table listing components included in the indoor unit packaging, such as Drainage Pipe, Pipe Band, and Clamps, with their respective quantities and descriptions.

選擇室內機的位置


- 在管道側天花板上提供一個檢查端口，以進行維修和保養。 滿足以下情況並獲得客戶許可之後，即可安裝室內機。 1. 室內機必須位於開放空間內。 2. 室內機的入風口與出風口之間不得存在任何障礙物，且必須能夠在整個房間內流通空氣。



- 如果從地板到天花板的高度超過三米，氣流分佈會變差，效果會降低。 警告


- 3. 安裝位置必須能夠承受四倍於室內機重量的負載。 4. 室內機必須遠離熱源與蒸氣來源，但請避免安裝於入口處附近。 5. 室內機必須易於排水。 6. 室內機必須允許鬆弛連接到室外機。 7. 根據下列所示天花板的高度放置室內機。 8. 室內機必須距離任何產生雜訊的設備至少 3 m 遠。電線必須用鋼管屏蔽。 9. 如果電線容易產生噪音，請添加一個隔音劑。 10. 請勿在洗衣房內安裝室內機，否則可能造成電擊的危險。 11. 室內機的安裝高度應至少為 2.2 m。

- 備註 仔細研究以下安裝位置 1. 在飯店和廚房等場所，調冷風扇、熱交換器的翅片和排水泵上附著了大量的油蒸氣和麵粉，導致熱交換減少，噴霧、水瀉分散，排水氣味等等。 在這種情況下，請執行以下操作： 確定材料種上集煙罩的通風風扇將油蒸氣排出，而不至由空調機吸入。 請在與廚房之間有足夠距離的位置安裝空調機，以免吸入油蒸氣。




- 2. 避免在有切削油霧或麵粉的環境中安裝空調機，特別是在例如工廠之類的地方。 3. 避免安裝在會產生、流通、洩漏可燃氣或者受其污染的位置。 4. 離開會產生硫磺氣體或腐蝕性氣體的地方。 5. 離開高頻發生器附近的地方。

室內機排水管



- 排水管必須有下降 (1/50 至 1/100)；確保不要提供上下坡以防止逆流。 連接排水管時，請注意不要在室內機的排水口上施加額外的力量。 室內機上排水管的外徑為 32 毫米。 管壁材質：聚氯乙烯管 VP-25 和管道及配件。 確保對排水管進行隔熱。(請參閱用於排水管和排水管安裝的 ⑤ 隔熱部分隔熱層)。

冷媒劑配管








- 1. 銅管管道。 a. 先銅管，然後扭緊銅口螺絲。 b. 必須在吹送空氣時進行銅管。 (這可防止在銅管中產生氧化皮)。 2. 如果長管道的材料很多，則在管道的中間安裝一個通網。(通網是外部提供的)。 3. 使用清潔的銅管，其內壁表面要無雜和灰塵。連接前，用氮氣或空氣吹去管道中的灰塵。 4. 根據管道的走向鋪設管道。避免將管道的同一點彎曲和折曲超過三次。(這會導致管道硬化)。 5. 改變彎曲形狀後，中心對齊室內機和管道的接頭，並用手將其牢固鎖緊。 6. 將管道連接到室外機下方的維修閥或球閥。 7. 完成管線連接後，請務必檢查室內及室外連接是否有氣體外洩。








真空乾燥

Table showing the required torque for the refrigerant pipe connections. It lists the torque values for different pipe sizes and materials.

室內機的安裝



隔熱層



# 6 電線

**關於室外機的主電源和電纜尺寸，請閱讀室外機附帶的安裝手冊。**

**警告**

- 本空調器必須按照國家接線規定進行安裝。
- 應接到室內機的電纜必須經過許可的聚氯乙稀護套 60245 IEC 57 或 H05RN-F / H07RN-F 或更重。
- 必須由合格的技術人員將設備連接到電源電纜以進行固定佈線。斷路器必須按照國家接線規定安裝在固定接線中。斷路器必須經過許可，並用適合設備的額定電壓和電流，而且所有電極之間的間隔距離均為 3mm。當電源電纜損壞時，必須由合格的技術人員更換。
- 應保在主電源上安裝漏電斷路器、主開關和保險絲，否則可能導致觸電。
- 本裝置必須連接安全接地。如果接地工作不正確，可能會導致觸電。
- 應使用指定的電纜牢固地連接接線並牢固地固定，以使電纜的外力不會傳達到端子連接部分。不當連接和固定會導致火災等意外發生。

1. 選擇一種能夠提供空調所需電流的供電。






2. 透過專用的配電板使裝置通電，而且開關的所有電極必須相隔至少 3 mm。

3. 務必使用接地線和斷路器將空調器接地，以符合當地法規的要求。




4. 確保將室內/室外機連接線正確連接到端子上。

5. 安裝及連接遙控器之前，請務必關閉主電源。

**備註** 如果需要暫時開啟室內機與室外機的電源，請至少等待 1 分鐘之後才關閉電源。(用於系統的自動設定) 在途中關閉電源可能會導致異常操作。



# 7 裝飾面板的安裝




# 8 測試執行

**注意事項**

- 要求客戶在執行試運轉時在場。
- 此時，解操作手冊並讓客戶執行實際步驟。
- 檢查 220-240 V 交流電壓源是否正確連接到內機組控制接線板端子上。
  - 如果意外施加 220-240 V 交流電壓，室內機控制電路板保險絲將熔斷以保護電路板。在這種情況下，請正確接線。
  - 然後關閉連接到室內機控制電路板的 2P 連接器 (OC)，並更換為 2P 連接器 (EMC)。
  - 如果更換線路連接器後仍無法運行，請切斷室內機控制電路板上的跳線。
  - (請務必在執行此操作之前關閉電源。)

**備註** 新產品安裝後第一次供電，系統大約需要 5 分鐘的“系統自動配置流程”。供電後，系統沒有立即開機或對遙控器做出響應。



**① 試運轉前需要檢查的項目**

- 至少提前 5 小時打開有線遙控器電源開關通電。
- 完全打開或體管氣管側開關的門門。
- 檢查室內和室外機接線。

**② 檢查室內和室外機接線**

- 將室外機和室內機之間的電源和連接電纜分開








**③ 地址設置**

**位址**

地線、室外機電源接線和通地線漏電斷路器的顯示省略。

**系統連接**

- 打開所有室內機和室外機時，自動尋址將啟動。最多需要 10 分鐘。
- 自動尋址設置完成後，請至少等待 1 分 30 秒，然後開始操作。



# 保養和清潔

**警告**

- 出於安全理由，清潔前請務必關閉空調並斷開電源。
- 請勿將水倒在室內機上進行清潔。這會損壞內部部件並導致觸電危險。

**避免與出風側 (室內機)**

請使用吸塵器清潔室內機的進風側和出風側，或用乾淨的軟布擦拭。

如果這些部件正在運行，請使用蘸水的干淨布料擦拭。清潔出風側時，注意不要將葉片移出原位置。

**注意**

- 清潔室內機時，切勿使用溶劑或刺激性化學品。請勿使用非常熱的水擦拭塑膠部件。
- 某些金屬邊緣和薄片非常鋒利。如果處理不當可能會造成傷害。清潔這些部件時要格外小心。
- 室外機的内部線圈和其他部件必須定期清潔。請諮詢經銷商或服務中心。

**空氣過濾器**

空氣過濾器收集空氣中的灰塵和其他顆粒，應定期清潔或當遙控器 (有模型) 顯示屏上的過濾器符號 ( ) 顯示過濾器需要清潔時進行清潔。如果過濾器堵塞，空調的效率會大大下降。

週期 6 個月

**清潔後**

- 空氣過濾器清潔後，將其重新安裝到原來的位置。請務必以相反的順序重新安裝。
- [定時遙控器的情況]

按下過濾器重設按鈕 ( ) 顯示屏上的 (過濾器) 指示燈熄滅。

