

Petunjuk Pengoperasian

IDENTIFIKASI BAGIAN

1	Fabric dial	Tombol kain
2	Handle	Pemegang
3	Soleplate	Tapak setrika
4	Button notch	Tombol tutik
5	Cover shell	Kelompeng penutup
6	Pilot lamp	Lampu pilot

CARA PENGUNAAN

1. Setel tombol kain ke jenis kain yang dinginkan.
2. Pastikan voltase pada setrika sesuai dengan tegangan listrik setempat. Biarkan setrika memanaskan selama 2 menit atas tumitnya sebelum menyentrika.
3. Lampu pilot menyala setelah setrika diaktifkan dan padam saat setrika dipanaskan sampai suhu yang dipilih oleh tombol kain. Lampu akan tetap padam selama setrika berada pada suhu yang dipilih, dan ketika suhu menurun termostat akan mulai bekerja dan lampu akan menyala kembali. Termostat membuat lampu pilot otomatis menyesuaikan dengan suhu yang berbeda-beda sebagai dipilih oleh tombol kain.
4. Mulai menyentrika kain serial sintetis pada suhu rendah dan kemudian bila suhu naik, setrika kain serial wol, katun dan linen.
5. Setrika memanas lebih cepat daripada mendingin. Berikan waktu setrika menjadi panas apabila mengubah dari suhu rendah ke suhu tinggi. Sebaliknya tunggu beberapa saat ketika mengubah ke setel lebih dingin.

PERHATIAN

1. Jangan sekali-kali meninggalkan setrika ini tanpa ditunggu ketika sedang dihubungkan dengan listrik.
2. Jangan menggunakan setrika dengan kabel dalam kondisi kusut. Kabel listrik mungkin rusak.
3. Jika kabel listrik rusak, maka harus diganti oleh agen servis kami atau orang yang memenuhi syarat untuk terhindar dari bahaya.
4. Setrika harus digunakan dan diletakkan pada permukaan yang stabil.
5. Ketika meletakkan setrika pada dudukannya, pastikan dudukan diletakkan pada permukaan yang stabil.
6. Jangan menggunakan setrika jika alat ini pernah jatuh, menunjukkan kerusakan atau bocor.
7. Alat ini tidak boleh digunakan oleh orang (termasuk anak-anak) dengan cacat fisik, indra atau kecacatan mental atau kurang pengalaman dan pengetahuan, kecuali mereka telah diberikan pengawasan penggunaan atau instruksi mengenai penggunaan alat oleh orang yang bertanggungjawab atas keselamatan mereka.
8. Anak-anak harus diawasi untuk memastikan bahwa mereka tidak bermain-main dengan alat ini.

Operating Instructions

PARTS IDENTIFICATION



HOW TO USE

1. Set fabric dial at the desired fabric marking.
2. Make sure the voltage indicated on the iron meets your local voltage. Allow the iron to heat up for 2 minutes on heel rest before ironing.
3. The pilot lamp glows when the iron is switched on, and goes off when the iron is heated up to the temperature selected by the fabric dial. The lamp will remain off as long as the iron keeps the selected temperature and as the temperature decreases the thermostat will start working and the lamp will glow again. The thermostat makes the pilot lamp adjust automatically to the varying temperature as being selected by the fabric dial.
4. First iron chemical synthetic fabric at low temperature and then as the temperature rises, iron wool, cotton and linen accordingly.
5. The iron heats up more quickly than it cools. Allow time for the iron to heat up when changing from a low temperature to a high one. Conversely wait a while when changing to cooler setting.

CAUTION

1. Do not leave the iron unattended while it is connected to the outlet.
2. Do not use the iron with the cord in tangled condition. The supply cord might be damaged soon.
3. If the supply cord is damaged, it must be replaced by our service agent or a similarly qualified person in order to avoid hazards.
4. The iron must be used and rested on a stable surface.
5. When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
6. The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with the appliance.