

## **FZ-G1A Series BIOS update Procedure**

This utility updates the BIOS of Toughbook FZ-G1 series to **V1.00L20**  
Please read this document carefully before using the utility.

### **1 Model names to be updated**

Confirm your computer is one of the following models.  
The model name is located on the bottom of your computer.

Target models : FZ-G1A\*\*[A-E,H-R,Z]\*\*\*

File name of packaged program	Current BIOS ver.	New BIOS ver.
bios_g1_1_r150002.exe	V1.00L17/L18/L19	V1.00L20

### **2 CAUTION:**

- Log on to Windows as an administrator.
- Connect the AC adaptor and the battery pack, do not remove them until BIOS update is complete.
- Back up important data to other media or an external hard disk before BIOS update.

### **3 Procedure**

#### **3.1 Confirm the BIOS version**

- (1) Execute PC Information Viewer.

Windows 8

Right-click the blank area on start screen.

Click "All apps" on the taskbar at bottom.

Click "PC Information Viewer" in "Panasonic" menu.

Windows 7

Click [Start] - [All Programs] - [Panasonic] - [PC Information Viewer]  
- [PC Information Viewer]

- (2) Select the [Setup] tab. Check the BIOS version from item of BIOS.  
(3) Confirm the BIOS version is same as 'Current BIOS version' in the table above.

#### **3.2 Preparing the BIOS update program**

- (1) Turn on the computer and log on to Windows as an administrator.  
(2) Execute "bios\_g1\_1\_r150002.exe".  
(3) Click [Yes] at the User Access Control screen when this screen is displayed.  
(4) Read the license agreement carefully, and click [Yes].

- (5) The screen to specify the destination location appears. The default location is “c:\biosup”. Specify your location and click [OK]. (You usually don’t need to change the location.)
- (6) Wait until the destination folder is displayed.

### **3.3 Execute the BIOS update program**

- (1) Execute “WBG11V100L20.exe” in the destination folder.
- (2) Click [Yes] at the User Access Control screen when this screen is displayed.
- (3) Click [OK] at the BIOS Update for Panasonic PC.
- (4) The screen of “Before you proceed” appears. Check notes carefully, and click [Yes].
- (5) Automatically, Windows will shut down and the BIOS update program will run. Wait until Windows startup again.
- (6) Confirm the BIOS version is updated to ‘New BIOS version’ in the table above in PC Information Viewer. (Refer to procedure 3.1)