

Residential Air Conditioners (RAC)

2.4 The Comfort of Cool Air for Every Occasion

# Pre-Cool Your Home.

Have the option to cool your rooms before arriving home.



 25.0 °C ON



Living Room




 20.0 °C ON




Bedroom

## Activate Pre-Cool.




### STEP 1

Select an air conditioner.



### STEP 2




Toggle "OFF" to "ON".



### STEP 3

The air conditioner is activated.

## Adjusting Temperature.



Tap "+" or "-" to increase temperature by 0.5°C.  
Toggle "●" to switch temperature quickly.