



4.2 Add New Units to Groups

Adding New Air Conditioner Units (Built-In).




STEP 1

Tap the “+” icon.




STEP 2

Choose “Air Conditioner”.




STEP 3

Choose “Built-in wireless module”.



STEP 4


Prepare your air-conditioner remote controller and a pin.



STEP 5

a) Point the remote controller towards the air-conditioner and press the “Wi-Fi” button once to hear a “BEEP” sound.


b) When the light “Wi-Fi” on the air conditioner starts blinking then tap “Next”.
*Can be white or blue light depending on your model.



STEP 6

Select LED is OFF/blinking or Click here to connect without entering password.

If choose LED is OFF/blinking, refer Step 7.1A-7.1C of page 129.
If choose Connect without password, refer Step 7.2A of page 129 & 7.2B of page 130.




STEP 7.1A

a) Do not point your remote controller at the unit.


b) Take your remote controller and press “Wi-Fi” and hold for 5 seconds until you see “1” then press up/down to “2”.

c) Now point remote controller at the unit and press ‘SET’ to hear a beep sound.



STEP 7.1B

Tap “Join” when prompt Panasonic Comfort Cloud wants to join Network.



STEP 7.1C

The unit will connect to the same wireless connection that your mobile phone is connected to, enter your wireless connection password and tap “OK”. Proceed to step 8 at page 130.




STEP 7.2A

Press the WPS button on router and then tap “Next”.

4.2 Add New Units to Groups

Adding New Air Conditioner Units (Built-In) continues...




STEP 7.2B

- a) Do not point your remote controller at the unit.
- b) Take your remote control and press “” and HOLD for 5 seconds until you see “1”.
- c) Now point remote controller at the unit and press “SET” to hear a beep sound. Proceed to Step 8.




STEP 8

Connection is successful when the Wireless LAN LED is ON, then tap “Next”.
*Permanent blue light and not blinking means “ON”.




STEP 11

- a) Do not point your remote control at the unit.
- b) Take your remote control and press “” and HOLD for 5 seconds until you see “1” and then press up/down to “3”.
- c) Now point remote control at unit and press “SET” to hear a beep sound.




STEP 12

Wait for a while.




STEP 9

Searching for air-conditioner.




STEP 10

Select the air conditioner then tap “Register”.



STEP 13

Key-in Password and tap “Register”.



STEP 14

Set air conditioner name then tap “Register”.



STEP 15

Air Conditioner has been registered.