


4.4 New Account Registration, Change Router Settings & Device Password

Change Router Settings.




STEP 1

Tap the “☰” on the top right-hand corner of your screen.




STEP 2

Tap “Owner” to see the drop-down options and select “Change router settings”.



STEP 3

After checking it is the correct device, then tap “Start”.




STEP 4

Make sure all 3 green lights are “ON” on your device then tap “Next”.


* FOLLOW THE STEPS LISTED IN THE APP TO CONTINUE.
* For Built-In, follow the steps listed in the model to continue.

Change Device Password.




STEP 1

Tap the “☰” on the top right-hand corner of your screen.



STEP 2

Tap “Owner” to see the drop-down options and select “Change password”.



STEP 3

Key in old password then enter New password then tap “Register”.

* ONCE DEVICE PASSWORD IS CHANGED. ALL USERS BESIDES ADMIN NEED TO RECONNECT.