
4.2 Add New Units to Groups

Add New Air Conditioner Units to the Groups.

How to register new air conditioner units to existing groups.
















Add New Air Conditioner Units (External Adaptor).








STEP 1

Tap the "+" icon.




STEP 4

Tap "Start".

STEP 2

Choose "Air Conditioner".




STEP 5

Tap "Next".

Make sure POWER LED is ON and then tap "Next".

STEP 3

Choose "External Wireless Adaptor".




STEP 6

Reset the network adaptor with a pin.

120

4.2 Add New Units to Groups

Add New Air Conditioner Units (External Adaptor) continues...




STEP 7 Tap "Next".

७७७ □□□□ 🕏

STEP 10

Press the WPS

button on router




Choose "LED is OFF".

adaptor for 5 seconds.

2. Release the "SETUP" button when both STATUS LED


and LINK LED start to blink.



STEP 9


Choose to connect using WPS or AP.

**AP mode can only use with (Android 5.0 & IOS 11.0) and above.




STEP 11

Press "SETUP" continuously until "STATUS LED and LINK LED" start to blink simultaneously and then release setup button immediately.




STEP 12

Tap "Next". Go to Step 13.




STEP 10

Press "SETUP" continuously until "STATUS LED" becomes orange and then release setup button immediately.



STEP 13

When "POWER LED" and "LINK LED" are ON, means the device has successfully connected to the wireless network, tap "Next".



STEP 11

Device password

STEP 14

Key in Device ID

and password

then tap


"Register".

Tap "Next".



STEP 12

The device will connect to the same wireless connection that your mobile phone is connected to, enter your wireless connection password and tap "OK". Go to Step 13.



STEP 15

Set air conditioner name then tap "Register".
"POWER LED", "STATUS
LED" and "LINK LED" will be ON once registration is completed.

and tap "Next".

122 123