

Residential Air Conditioners (RAC)

2.4 The Comfort of Cool Air for Every Occasion

Pre-Cool Your Home.

Have the option to cool your rooms before arriving home.



Depart from any location: Turn on air conditioner

Arrive to a cool and comfortable home



 25.0 °C ON



Living Room




 20.0 °C ON



Bedroom

Activate Pre-Cool.



STEP 1

Select an air conditioner.



STEP 2

Toggle "OFF" to "ON".



STEP 3

The air conditioner is activated.

Adjusting Temperature.



Tap "+" or "-" to increase temperature by 0.5°C.
Toggle "●" to switch temperature quickly.