



3.4 Comfort Cooling for Every Occasion

# Pre-Cool Your Workspaces.

The moment your staff or customers walk in, they can enjoy cool and comfortable air by pre-cooling these spaces before your arrival.




Room 101




Office space

## Activate Pre-Cool.



**STEP 1**

Select an air conditioner.



**STEP 2**


Toggle "OFF" to "ON".



**STEP 3**


The air conditioner is activated.

## Adjust temperature.




**STEP 1**

Tap "+" or "-" to increase temperature by 0.5°C. Toggle "●" to switch temperature quickly.



**STEP 2**



**STEP 3**