
2.9 Ventilation for Cleaner Air

Ventilator Features.

Adjust ventilation speed while checking dust and carbon dioxide (CO₂) levels.

Adjust Ventilation Speed and Check Dust (PM2.5) and Carbon Dioxide (CO₂) Levels.





STEP 1

Tap the highlighted region to access different operation modes.



STEP 2

Select "Manual" mode.



STEP 3

Toggle "<" or ">"
to adjust your
ventilation speed.



Check the PM2.5 levels in your space.



Check the Carbon Dioxide (CO₂) levels in your space.

62