


Panasonic[®]

Operation Instruction

Model: VL-VC3530BX

Door Station



Content

1. Including Items	1
2. Important Information	2
3. External View of Equipment	8
4. Product Wiring Diagram	8
5. Installation Diagram	9
6. Technical Parameters	10
7. Production Introductions	10



Thank you for purchasing this product.

- Read these instructions carefully for optimum performance and safety before use.
- Keep this manual for future reference.

Printed in China

1. Including items

The following items are included in addition to the door station.

Part	Name	Count
	Bracket.	1
	2 wire connector: AWG24, for power port.	1
	Screw driver.	1
	Screw: Fix the bracket to the installation Position.	2
	Screw: Fix the door station to the bracket.	1

2. Important Information

2.1 Important safety information

To prevent severe injury or loss of life or property, and to ensure proper and safe operation of your product, read this section carefully before using the product.

WARNING

Preventing fire, electric shock, and short circuits.

- Leave installation work to the dealer. Installation work requires technical knowledge and experience. Electrical connection work should be performed by certified personnel only. Failure to observe this may cause fire, electric shock, injury, or damage to the product. Consult the dealer.
- Do not place objects on the power cables. Install the product where no one can step or trip on the power cables.
- Do not allow the power cables to be excessively pulled, bent or placed under heavy objects.
- Make sure all connections from the power outlet to the power supply unit are secure.
- Never touch the power supply unit and power cables with wet hands.
- Do not disassemble or modify the product. Refer servicing to an authorized service centre when service is required. Disassembling the product or manipulating the product in a way not described in the documentation may expose you to dangerous voltages and other risks.
- Do not touch the product or the power supply unit during an electrical storm. There may be a remote risk of electric shock from lightning.

- Never install wiring during a lightning storm.
- Do not connect non-specified devices.
- When opening holes in walls for installation or wiring, or when securing the power cable, make sure you do not damage existing wiring and duct work.
- Do not make any wiring connections when the power outlet is turned on.
- Do not install the product and power supply unit in the following places:
 - Places where the product and power supply unit may be splashed with water or chemicals.
 - Places where there is a high concentration of dust or high humidity.
- Do not push any objects through the openings of the product.
- If any of the following conditions occur, disconnect the Ethernet (LAN) cable from the product, disconnect the power supply unit from the power outlet, and then refer servicing to an authorized service centre.
 - The product emits smoke, an abnormal smell or makes unusual noise.
 - The power cables are damaged or frayed.
 - Metal objects have been dropped inside the product.
- When existing wires are used, it is possible that they contain AC voltage. Contact an authorized service centre.

CAUTION

Please note the following two things to prevent the equipment from being destroyed.

- (1) Use Standard PoE (IEEE 802.3af compliant); or
- (2) Use the dedicated Panasonic Power Supply Unit (VL-PC3400BX or VL-PC3430BX).

Preventing accidents, injuries, and property damage.

- Do not use the product in unstable areas or areas prone to strong vibrations. This may cause the product to fall, resulting in damage to the product or injury.
- Always connect power cables to the appropriate connection terminals. Incorrectly connecting the power cables may damage the power supply unit.
- Insert the power cables firmly all the way into the terminals. If the cables are not inserted all the way, heat may be generated.
- If the wiring passes outdoors, use a conduit and a surge protector.
- If the wiring passes underground, use a conduit, and do not make any connections underground.
- Install the product securely adhering to the instructions in this document to prevent it from falling off the wall. Avoid installing onto low-strength walls, such as gypsum board, ALC (autoclaved lightweight concrete), concrete block, or veneer (less than 18 mm thick) walls.
- Do not put your ear(s) near the speaker, as loud sounds emitted from the speaker may cause hearing impairment.
- To prevent serious injuries due to the product unexpectedly falling, the product with a wall mount feature must be installed at a height of 2m or lower.

2.2 Important Safety information

When using this product, basic safety precautions should always be followed to reduce the risk of fire, electric shock, or personal injury.

Use only the power supply unit indicated in this document.

SAVE THESE INSTRUCTIONS

2.3 Privacy and rights of portrait

When installing or using the product, please take into consideration the rights of others with regard to privacy and rights of portrait.

- It is generally said that "privacy" means the ability of an individual or group to stop information about themselves from becoming known to people other than those whom they choose to give the information. "Rights of portrait" means the right to be safe from having your own image taken and used indiscriminately without consent.
- Please observe the legal regulations (data protection, video surveillance) in your country during use.

2.4 Data Security

In order to use the system safely and correctly, the data security guidelines (listed below) must be observed. Failure to do so may result in the following.

- Loss, leakage, falsification or theft of user information.
- Unauthorized or illegal use of the system by a third party.
- Interference or suspension of service caused by a third party.

What is user information?

User information is defined as the following types of information.

- Information stored in the product.
 - System event information.
 - System and device settings.
- Information stored on the computer that is used by the setup tool.
 - Resident names and room numbers.
 - System and device settings.

Data security guidelines

- Observe proper management of passwords.
 - Passwords can be used to program the system, open doors, etc. Select passwords that are difficult to guess, change them regularly, and keep them secret. Assign a unique password to each device.

- You will never receive enquires about passwords from Panasonic.
- Protect user information when sending the product to be repaired, or when handing it over to a third party.
 - Use the product's reset function to initialise the product before when sending the product to be repaired or handing it over to a third party.
 - Note that user information may be deleted or initialized when the product is repaired.
 - Refer all repairs to a trusted Panasonic service centre.
- Protect user information stored on the computer used to configure the system.
 - When user information is stored on a computer, the confidentiality of that information becomes the responsibility of the installer. Take precautions to prevent the unauthorised use of the computer and the setup tool used for performing system configuration or maintenance.
 - Connect the computer to the network only when performing system configuration or maintenance, and disconnect the computer from the network as soon as the work is complete.
 - Use a secure network that is protected by a firewall, etc.
 - To prevent the leaking of personal information, enable a screen saver for the computer that uses a password.
 - Before disposing of the computer, ensure that data cannot be retrieved from it by formatting the hard disk and/or rendering it physically unusable.
- Protect user information when disposing of the product.
 - Use the product's reset function to initialise the product before disposing of the product.

2.5 Disclaimer

- Recorded data may be altered or deleted as a result of incorrect operations, exposure to static electricity, accidents, malfunction, repairs or other operations. To the maximum extent permitted by applicable law, Panasonic assumes no liability for any direct or indirect damages resulting from the loss or alteration of recorded data.
- To the maximum extent permitted by applicable law, Panasonic assumes no responsibility for injuries or property damage resulting from failures arising out of improper installation or operation inconsistent with this document.
- To the maximum extent permitted by applicable law, Panasonic will not be held responsible for any damage or loss due to non-performance or delay in performance, error or failure of network and/or any products.


2.6 Other Important Information

- Before attempting to connect or operate this product, please read the nameplate on the bottom or rear of the product.
- When you leave the product unused for a long period of time, unplug it from the power outlet.
- If you stop using this product, remove it from the walls to prevent it from falling off.
- When power fails, this product cannot be used.
- Panasonic may not be liable for damages due to external factors such as power failures.


2.7 General Information

- In the event of problems, you should contact your equipment supplier in the first instance.
- After removing the product and any included items from the packaging, store, dispose, or recycle the packaging as necessary. Note that certain types of packaging may be a suffocation or choking hazard.

3. External View of Equipment




4. Product Wiring Diagram



Port	Description
Net Port	Connect to the LAN, Support PoE.
Gnd & P+	Power Port, 12 to 27V DC.

5. Installation Diagram



1. Fix the bracket on the 86(3" x 3") back box with the screws.
2. Fit the device on the bracket with the screws after the wiring is completed.
3. Device installation completed.

CAUTION

- The door station shall not be installed in the sun exposure, rain, high temperature, snow/frost, too much dust or strong magnetic field environment.
- The door station camera shall avoid direct sunlight to prevent poor image quality.
- When the door station is installed, it is recommended that the camera be about 145cm from the ground.
- The lighting at night shall be taken into account during the installation of the door station.
- The door station shall not be installed in the place where the background noise is more than 70dB.

6. Technical Parameters

Parameters	Value
Dimensions	150 x 90 x 12.5mm
Weight	140g
Operating voltage	12 to 27VDC
Operating power consumption	2.65W
Standby power consumption	1.0W
Operating temperature	-20°C to 55°C
IP Rating	IP30

7. Production Introductions

7.1 Video Intercom

The visitor can press the call button directly on the Door Station, and the Door Station will start ring and call the Room Monitor for video intercom. If there is no answer, the visitor can leave a message to the Room Monitor by pressing the call button after the leave message prompt played on the Door Station.

Note, For the function of the leave message on the Door Station, the Room Monitor should support the leave message function.

7.2 Video Monitor

The user can view the video of the Door Station on the Room Monitor in the Video Monitor function.

7.3 Removal Alert

If the device is removed from the install place, an alert sound will be played. And this alert will be sent to the manager software at the same time.

7.4 Connect Status

The user can press the call button and hold for about 5 seconds, a prompt will be played to show if the device is connect to the manager software.

7.5 System Set

The user can set the parameters via the web. Open the web browser and input the "http://IP address" (the default IP address is 192.168.1.57) and press enter, the login page will be showed, input the user name and passwords (default user name & passwords is "admin" and "666666"), the parameter set page will be showed.

The user can also reset the device to factory mode, change the server mode and IP address of the voice playback on the device with the following steps:


1. Press and hold the call button and click the removal button 3 times quickly, then a beep sound played and the device is enter the system set function.
2. In the system set function, the user can click the call button to switch the sub function, include reset to factory mode, change the server mode and IP address of the voice playback.
3. When switch to the reset faction mode function, the user can long press the call button for more than 5 seconds to reset the device to factory mode.
4. When switch to the change the server mode function, the user can long press the call button for more than 5 seconds to change the device to local server mode or cloud server mode.
5. When switch to the IP address of the voice playback, the device will play a voice to show the IP address of the device.
6. After the IP address of the voice playback function, the user can click the call button to exit the system set function.
7. The device can exits the system set function after the user press the removal button. Or the device will exits the system set function automatically when no operation on the device for more than 15 seconds.

Panasonic®

Hướng dẫn lắp đặt và vận hành

Mã hiệu : VL-VC3530BX

Điện thoại gọi cửa – Bộ phận gọi cửa



Nội dung :

1. Các phụ kiện đi kèm	1
2. Thông tin quan trọng	2
3. Mặt ngoài của thiết bị	8
4. Sơ đồ nối dây thiết bị	8
5. Sơ đồ lắp đặt	9
6. Các thông số kỹ thuật	10
7. Giới thiệu về sản phẩm	10

Cảm ơn quý khách đã mua sản phẩm này. Xin vui lòng.



- Đọc kỹ các hướng dẫn này để đạt hiệu quả tối ưu và an toàn trước khi sử dụng.

- Hãy giữ cuốn hướng dẫn lắp đặt và sử dụng này để tham khảo trong tương lai.

In tại Trung Quốc

1. Các phụ kiện đi kèm

Các phụ kiện sau đây được đi kèm bộ phận gắn cửa

Mục	Miêu tả	Số lượng
	Đế.	1
	Đầu nối 2 dây: AWG24, dành cho cổng nguồn.	1
	Cái vặn vít.	1
	Cố định bằng treo vào vị trí lắp đặt.	2
	Cố định nút vào đế.	1

2. Thông tin quan trọng

2.1 Thông tin an toàn quan trọng

Để tránh thương tích nghiêm trọng, tử vong hoặc hư hỏng tài sản, vui lòng đọc kỹ mục này trước khi sử dụng sản phẩm để đảm bảo sản phẩm hoạt động chính xác và an toàn.

CẢNH BÁO

Để phòng tránh hỏa hoạn, điện giật và đoản mạch.

- Hãy để đại lý bán hàng thực hiện công việc lắp đặt sản phẩm. Công việc này đòi hỏi người làm phải có kiến thức về kỹ thuật và kinh nghiệm. Công tác đấu điện phải do kỹ thuật viên có tay nghề thực hiện. Nếu không cẩn thận có thể gây ra hỏa hoạn, điện giật, thương tích hoặc hư hỏng sản phẩm. Hãy liên hệ đại lý bán hàng.
- Không đặt các vật trên dây cáp điện. Lắp đặt sản phẩm ở nơi không ai có thể bước hoặc giẫm lên dây cáp điện.
- Không để dây cáp điện bị kéo quá mức, thông gió hoặc đặt dưới vật nặng.
- Đảm bảo tất cả các kết nối từ ổ cắm điện đến bộ cấp nguồn đều được an toàn.
- Không chạm vào bộ cấp nguồn và dây cáp điện bằng tay ướt.
- Không sử dụng bộ cấp nguồn để lắp đặt ngoài trời (chỉ sử dụng trong nhà).
- Không tháo dỡ hoặc điều chỉnh sản phẩm. Khi cần sửa chữa, vui lòng liên hệ trung tâm bảo hành ủy quyền. Tháo dỡ hoặc thao tác sản phẩm không đúng theo mô tả trong tài liệu này có thể gặp nguy hiểm do điện áp cao và các nguy hiểm khác.
- Không chạm vào sản phẩm hoặc bộ cấp điện khi có giông bão. Người dùng có thể bị điện giật do sét.
- Không đấu dây khi có giông bão.
- Không đấu nối các thiết bị không đúng tiêu chuẩn.

- Khi đục lỗ trên tường để lắp đặt hoặc đi dây hoặc cố định dây nguồn, cần chú ý không làm hỏng đường dây và ống dẫn cũ.
- Không đấu nối dây khi bật ổ cắm điện.
- Không lắp sản phẩm và bộ cấp điện trong những trường hợp sau:
 - Vị trí có nước hoặc các chất hóa học có thể bắn vào bộ cấp điện và sản phẩm.
 - Nơi có nhiều bụi bẩn hoặc độ ẩm cao.
- Không đặt bất cứ đồ vật nào vào khe hở của sản phẩm.
- Ngắt kết nối dây cáp Ethernet (LAN) ra khỏi sản phẩm, rút nguồn điện của bộ cấp điện ra khỏi ổ cắm điện, sau đó tham khảo trung tâm bảo hành ủy quyền nếu xảy ra một trong số các trường hợp sau.
 - Xuất hiện khói, mùi lạ hoặc âm thanh bất thường.
 - Các dây nguồn bị hư hỏng hoặc bị tróc vỏ bọc.
 - Vật bằng kim loại rơi vào bên trong sản phẩm.
- Nếu sử dụng dây có sẵn, dây đó có thể chứa điện áp AC. Liên hệ với trung tâm bảo hành ủy quyền.

THẬN TRỌNG

Hãy lưu ý hai điều sau đây để ngăn chặn thiết bị khỏi bị phá hủy.

- (1) Sử dụng PoE tiêu chuẩn (tuân thủ IEEE 802.3af); hoặc.
- (2) Sử dụng Bộ nguồn chuyên dụng của Panasonic (VL-PC3400BX hoặc VL-PC3430BX).

Phòng tránh tai nạn, thương tích và hư hỏng tài sản.

- Không sử dụng sản phẩm ở những khu vực có rung động mạnh hoặc bất ổn. Vì có thể làm rơi sản phẩm, dẫn đến hư hỏng hoặc gây thương tích.
- Luôn kết nối cáp nguồn với các thiết bị đầu cuối tương thích. Kết nối cáp nguồn không chính xác có thể làm hỏng bộ cấp nguồn.

- Cắm chắc chắn tất cả các cáp nguồn vào các thiết bị đầu cuối. Nếu các dây cáp không được cắm hết, có thể sinh ra nhiệt.
- Nếu đi dây ở ngoài trời, sử dụng ống dẫn và thiết bị chống sét.
- Nếu đi dây ngầm, sử dụng ống dẫn và không thực hiện các mối nối khi đi dây ngầm.
- Lắp đặt thiết bị chắc chắn theo các hướng dẫn trong tài liệu này, tránh để thiết bị rơi khỏi tường. Tránh lắp thiết bị lên tường có tải trọng thấp, như vách thạch cao, bê tông xốp, gạch xi măng rỗng hoặc bột gỗ ép (độ dày nhỏ hơn 18 mm).
- Không được để tai gần loa do âm lượng lớn phát ra từ loa có thể làm giảm thính lực.
- Để tránh thương tích nghiêm trọng do rơi sản phẩm, phải lắp sản phẩm có tính năng treo tường ở thấp hơn hoặc ở độ cao 2 m.

2.2 Một số hướng dẫn an toàn quan trọng

Để giảm nguy cơ xảy ra hỏa hoạn, điện giật hoặc thương tích, cần phải tuân theo các cảnh báo an toàn cơ bản khi sử dụng sản phẩm.

Chỉ sử dụng bộ cấp điện theo chỉ dẫn trong tài liệu này.

CẤT GIỮ CÁC HƯỚNG DẪN NÀY

2.3 Quyền riêng tư và sử dụng hình ảnh cá nhân

Khi lắp đặt hoặc sử dụng sản phẩm, vui lòng xem xét vấn đề quyền riêng tư và sử dụng hình ảnh cá nhân.

- "Quyền riêng tư" có nghĩa là quyền của một cá nhân hoặc một nhóm người nào đó không cho phép người khác biết các thông tin cá nhân của họ, ngoại trừ những người mà họ muốn.
- "Quyền sử dụng hình ảnh cá nhân" có nghĩa là quyền không cho phép chụp và sử dụng hình ảnh cá nhân mà chưa được sự đồng ý của cá nhân đó.
- Hãy tuân thủ các quy định pháp luật (bảo vệ dữ liệu, giám sát video) tại quốc gia của bạn trong quá trình sử dụng.

2.4 Bảo mật dữ liệu

Phải tuân theo các hướng dẫn về bảo mật dữ liệu (liệt kê bên dưới) để sử dụng hệ thống an toàn và chuẩn xác. Không làm vậy có thể dẫn đến các nguy cơ sau.

- Mất mát, rò rỉ, xuyên tạc, đánh cắp thông tin người dùng.
- Bên thứ ba không được ủy quyền sử dụng hệ thống trái phép.
- Bên thứ ba cản trở hoặc làm gián đoạn dịch vụ.

Thông tin người dùng là gì?

Thông tin người dùng là các thông tin sau.

- Thông tin lưu trữ trong sản phẩm.
 - Thông tin sự kiện hệ thống.
 - Tin nhắn và hình ảnh camera.
 - Tên chủ căn hộ và số phòng.
 - Các cài đặt hệ thống và thiết bị.
- Thông tin lưu trữ tại máy tính dùng làm công cụ cài đặt.
 - Tên chủ căn hộ và số phòng.
 - Các cài đặt hệ thống và thiết bị.

Hướng dẫn bảo mật dữ liệu

- Quản lý mật khẩu đúng cách.
 - Mật khẩu dùng để lập trình hệ thống, mở cửa, v.v. Chọn mật khẩu khó đoán, thay đổi mật khẩu thường xuyên và bảo mật mật khẩu. Đặt mật khẩu riêng biệt cho mỗi thiết bị.
 - Bạn sẽ không bao giờ nhận được yêu cầu về mật khẩu từ Panasonic.
- Cẩn trọng khi nhập hoặc lưu thông tin liên lạc bằng hệ thống.
 - Đảm bảo nhập đúng mọi thông tin khi cấu hình địa chỉ email, số phòng hoặc các thông tin liên lạc khác. Thông tin không đúng có thể khiến thông tin người dùng bị tiết lộ tới người nhận không chủ đích.

- Bảo vệ thông tin người dùng khi mang sản phẩm đi sửa chữa hoặc đưa cho bên thứ ba.
 - Sử dụng chức năng cài đặt lại của sản phẩm để khởi tạo sản phẩm trước khi gửi sản phẩm đi sửa chữa hoặc đưa cho bên thứ ba.
 - Lưu ý rằng thông tin người dùng có thể bị xóa hoặc khởi tạo khi sửa chữa sản phẩm.
 - Tham khảo các cách sửa chữa ở trung tâm bảo hành uy tín của Panasonic.
- Bảo vệ thông tin người dùng được lưu trữ trong máy vi tính dùng để cấu hình hệ thống.
 - Khi thông tin người dùng được lưu trữ trên máy vi tính, việc bảo mật thông tin đó là trách nhiệm của người cài đặt. Phòng ngừa các hành động sử dụng trái phép máy vi tính và công cụ thiết lập để cấu hình hoặc bảo dưỡng hệ thống.
 - Chỉ kết nối máy vi tính với mạng khi thực hiện cấu hình hoặc bảo dưỡng hệ thống, ngắt kết nối mạng cho máy vi tính ngay khi hoàn thành công việc.
 - Sử dụng mạng bảo mật có tường lửa, v.v bảo vệ.
 - Để tránh rò rỉ thông tin cá nhân, bật màn hình chờ cho máy tính sử dụng mật khẩu.
 - Trước khi thải bỏ máy vi tính, đảm bảo không thể truy hồi dữ liệu bằng cách định dạng lại ổ cứng và/hoặc vô hiệu hóa thiết bị.
- Bảo vệ thông tin người dùng khi thải bỏ sản phẩm.
 - Sử dụng chức năng cài đặt lại của sản phẩm để khởi tạo sản phẩm trước khi thải bỏ.

2.5 Miễn trừ

- Dữ liệu được ghi có thể bị thay đổi hoặc xóa do vận hành không đúng cách, phơi nhiễm tĩnh điện, tai nạn, hỏng hóc, sửa chữa hoặc các vận hành khác. Trong phạm vi cho phép của pháp luật hiện hành, Panasonic không chịu bất cứ trách nhiệm nào đối với những tổn thất trực tiếp hoặc gián tiếp do mất hoặc điều chỉnh dữ liệu ghi được.

- Trong phạm vi cho phép của pháp luật hiện hành, Panasonic không chịu trách nhiệm đối với các hư hỏng hoặc mất mát do không tài sản do lắp đặt hoặc vận hành không đúng với tài liệu này.
- Trong phạm vi cho phép của pháp luật hiện hành, Panasonic không chịu trách nhiệm đối với các hư hỏng hoặc mất mát do không thể thực hiện hoặc trì hoãn thực hiện, lỗi mạng và/hoặc bất kỳ sản phẩm nào.


2.6 Thông tin quan trọng khác

- Trước khi kết nối hoặc vận hành sản phẩm này, vui lòng đọc nhãn thông tin ở đáy hoặc phía sau sản phẩm.
- Nếu không sử dụng sản phẩm trong một thời gian dài, hãy rút phích cắm ra khỏi ổ cắm điện.
- Nếu không sử dụng sản phẩm, hãy tháo sản phẩm ra khỏi tường, tránh để sản phẩm tự rơi.
- Không thể sử dụng thiết bị này khi mất điện.
- Panasonic không chịu trách nhiệm cho các hỏng hóc phát sinh từ các yếu tố bên ngoài như mất điện.


2.7 Thông tin chung

- Trong trường hợp có sự cố, trước hết bạn nên liên lạc với nhà phân phối thiết bị.
- Sau khi lấy sản phẩm hoặc các bộ phận đi kèm ra khỏi bao bì, hãy tích trữ, thái bỏ hoặc tái chế bao bì, nếu cần. Chú ý các loại bao bì có thể gây ra rủi ro hóc nghẹn hoặc nghẹt thở.

3. Mặt ngoài của thiết bị




4. Sơ đồ nối dây thiết bị



Cổng	Mô tả
Net Port	Kết nối mạng Lan, nguồn PoE.
Gnd & P+	Cổng nguồn, 12 tới 27V DC.

5. Sơ đồ lắp đặt



- 1. Cố định đế trên hộp 86(3" x 3") sau hộp với ốc vít.
- 2. Đặt thiết bị vừa với đế bằng ốc vít sau khi nối dây.
- 3. Sau đó lắp đặt đã hoàn thành.

THẬN TRỌNG

- Không được lắp đặt bộ phận gắn cửa ở nơi tiếp xúc với ánh nắng mặt trời, mưa, nhiệt độ cao, tuyết / sương mù, quá nhiều bụi hoặc môi trường từ trường mạnh.
- Camera của bộ phận gắn cửa phải tránh ánh nắng trực tiếp để tránh chất lượng hình ảnh kém.
- Khi lắp đặt bộ phận gắn cửa, nên để camera cách mặt đất khoảng 145cm.
- Việc chiếu sáng vào ban đêm phải được tính đến trong quá trình lắp đặt bộ phận gắn cửa.
- Không được lắp đặt bộ phận gắn cửa ở nơi có tiếng ồn xung quanh hơn 70dB.

6. Các thông số kỹ thuật

Thông số	Giá trị
Kích cỡ	150 x 90 x 12.5mm
Khối lượng	140g
Điện áp hoạt động	12 to 27VDC
Điện năng vận hành tiêu thụ	2.65W
Mức tiêu thụ điện ở chế độ chờ	1.0W
Nhiệt độ hoạt động	-20°C to 55°C
Cấp độ chống thấm nước và chống bụi	IP30

7. Giới thiệu về sản phẩm

7.1 Bộ phận gắn cửa gọi tới màn hình căn hộ

Khách truy cập trực tiếp nhấn nút gọi trên bộ phận gắn cửa biệt thự/ căn hộ để gọi màn hình căn hộ tương ứng để giao tiếp video, mở khóa và các thao tác khác. Khi màn hình căn hộ thực hiện thao tác mở khóa, bộ phận gắn cửa sẽ phát ra âm thanh bíp có nghĩa là cửa đã được mở.

Khi màn hình căn hộ được gọi, nếu màn hình căn hộ không được trả lời, bộ phận gắn cửa sẽ đưa ra lời nhắc bằng giọng nói "Vui lòng nhấn phím để để lại tin nhắn" 25 giây sau khi đổ chuông và khách có thể nhấn phím gọi để để lại tin nhắn. tại thời điểm này. Chủ nhà có thể xem thông tin tin nhắn từ khách trên màn hình căn hộ.

Lưu ý: Đối với chức năng khách gọi màn hình căn hộ để lại tin nhắn, màn hình căn hộ đã gọi bắt buộc phải có chức năng để lại tin nhắn.

7.2 Theo dõi video

Người dùng có thể xem lại video của chuông cửa trên màn hình bằng chức năng theo dõi video.

7.3. Cảnh báo chống trộm

Nếu thiết bị bị tháo khỏi chỗ lắp đặt, một tiếng chuông thông báo sẽ được bật lên. Và thông báo này cũng được gửi tới phần mềm quản lý cùng lúc.

7.4. Trạng thái kết nối

Người dùng có thể nhấn nút gọi và giữ khoảng 5 giây, 1 thông báo sẽ được hiển thị thiết bị đó có kết nối tới phần mềm quản lý hay không.

7.5 Chức năng cài đặt thông số

Người dùng có thể cài đặt thông qua trang web của thiết bị. Mở trình duyệt và nhập địa chỉ "http:// địa chỉ IP" (địa chỉ mặc định là 192.168.1.57) và ấn vào, trang web đăng nhập sẽ hiện lên, nhập tên đăng nhập và mật khẩu (mặc định là 'admin' và '6666666').

Người dùng có thể cài đặt thiết bị về chế độ nhà máy, đổi chế độ server và địa chỉ IP theo những bước sau:

1. Nhấn và giữ nút gọi và ấn nút gỡ bỏ 3 lần nhanh liên tục, sau đó 1 tiếng bíp và thiết bị vào chế độ cài đặt.
2. Trong chế độ này, người dùng có thể ấn vào nút gọi để chuyển vào chức năng con, bao gồm cài đặt chế độ nhà máy, đổi chế độ server và địa chỉ IP của thiết bị.
3. Khi chuyển sang cài đặt lại chế độ nhà máy, người dùng có thể nhấn nút gọi dài hơn 5 giây.
4. Khi chuyển sang cài đặt lại chế độ nhà máy, người dùng có thể nhấn nút gọi dài hơn 5 giây để đổi chế độ cài đặt server là cục bộ hay đám mây.
5. Sau khi đổi IP của thiết bị thành công, người dùng sẽ nghe lại địa chỉ IP của thiết bị.
6. Sau khi đổi IP của thiết bị thành công, người dùng có thể ấn nút gọi để thoát khỏi chế độ này.
7. Thiết bị có thể thoát khỏi chức năng cài đặt sau khi người dùng ấn nút gỡ bỏ. Hoặc thiết bị sẽ tự động thoát nếu không có hành động gì sau 15 giây.