


MOUNT



LUMIX S PRO
16-35mm F4
S-R1635

LUMIX S PRO
24-70mm F2.8
S-E2470

LUMIX S PRO
70-200mm F2.8 O.I.S.
S-E70200

LUMIX S PRO
70-200mm F4 O.I.S.
S-R70200

LUMIX S
14-28mm F4-5.6 MACRO
S-R1428

LUMIX S
20-60mm F3.5-5.6
S-R2060

LUMIX S
24-105mm F4 MACRO O.I.S.
S-R24105

LUMIX S
28-200mm F4-7.1 MACRO O.I.S.
S-R28200

LUMIX S
70-300mm F4.5-5.6 MACRO O.I.S.
S-R70300

LUMIX S PRO
50mm F1.4
S-X50

LUMIX S
18mm F1.8
S-S18

LUMIX S
24mm F1.8
S-S24

LUMIX S
35mm F1.8
S-S35


LUMIX S
50mm F1.8
S-S50

LUMIX S
85mm F1.8
S-S85


LUMIX S
100mm F2.8 MACRO
S-E100

Leica / SIGMA Lenses
L-Mount Alliance : www.l-mount.com


Standard Accessories




DC-S1H




DC-S1R




DC-S1




DC-S5M2X




DC-S5M2




DC-S5




External Flash
DMW-FL580L




External Flash
DMW-FL360L




External Flash
DMW-FL200L




LED Video Light
VW-LED1




XLR Microphone Adaptor
DMW-XLR1




Stereo Shotgun Microphone
DMW-MS2




Stereo Microphone
VW-VMS10




Upgrade Software Key
DMW-SFU2
(DC-S1, S5M2)




Eyecup
(DC-S1H, S1R, S1)




Eyecup
DMW-EC6
(DC-S1H, S1R, S1)




Shutter Remote
Control
DMW-RS2




Tripod Grip
DMW-SHGR1
(DC-S5M2X, S5M2, S5)




Tripod Grip
DMW-SHGR2
(DC-S5M2X, S5M2, S5)




Shoulder Strap
DMW-SSTG9




BNC Conversion
Cable
(DC-S1H)




Cable Holder
(DC-S1H, S1R, S1)




HDMI Cable
(HDMI TypeA)*3




4KTV / HDTV




Blu-ray Disc™
Player




Personal Computer



External SSD
(DC-S5M2X)




External Monitor




External Recorder

1.4x Teleconverter
DMW-STC14
Attachable to the S-E70200 and the S-R70200


2x Teleconverter
DMW-STC20
Attachable to the S-E70200 and the S-R70200




Battery Grip
DMW-BGS1
(DC-S1H,
S1R, S1)




Battery Grip
DMW-BGS5
(DC-S5M2X,
S5M2, S5)




Battery Grip
DMW-BG1
(DC-S5M2X,
S5M2, S5)




Battery Pack
DMW-BLJ31
(DC-S1H,
S1R, S1)




Battery Pack
DMW-BLK22
(DC-S5M2X,
S5M2, S5)




Battery Charger
DMW-BTC14
(DC-S1H, S1R, S1)




Battery Charger
DMW-BTC15
(DC-S5M2X, S5M2, S5)



AC Adaptor
DMW-AC10*1



DC Coupler
DMW-DCC16*1
(DC-S1H, S1R, S1)



DC Coupler
DMW-DCC17*1
(DC-S5M2X, S5M2, S5)

Battery Pack

Battery Charger AC Adaptor

AC Mains Lead
(DC-S1H, S1R, S1)

USB Connection Cable [C-C]
(DC-S1H, S1R, S1)

USB Connection Cable [A-C]

Bundled Software [Download]

- LUMIX Tether
- SILKYPIX® Developer Studio SE
- LUMIX Webcam Software [Beta]
- PHOTOfunSTUDIO 10.1 PE [DC-S1H, S1R, S1, S5]
- LoiLoScope Trial Version [DC-S1H, S1R, S1, S5]

The cards that can be used for recording vary depending on the motion pictures bit rate* and format type.

	72Mbps or less	200Mbps or less	400Mbps or less	600Mbps or less	800Mbps or more	ProRes 5.8K / C4K S&Q with ALL-Intra
SD Card	Class 10	✓				
	UHS Speed Class 1 or higher	✓				
	Video Speed Class 10 or higher	✓				
	UHS Speed Class 3		✓			
	Video Speed Class 30 or higher		✓	✓		
XQD Memory Card / CFexpress Card [Type B]	Video Speed Class 60 or higher	✓	✓	✓		
	Video Speed Class 90 or higher	✓	✓	✓	✓	
	External SSD	✓	✓	✓	✓	✓

*Recording and deleting occur at the same time during Loop Recording, so you will need a card with a writing speed equivalent to double the bitrate of the recording quality used for recording.

*1 The AC Adaptor DMW-AC10 requires the DC coupler DMW-DCC16 / DCC17. The DC coupler DMW-DCC16 / DCC17 requires the AC Adaptor DMW-AC10. *2 DC-S1R and S1 must be updated to firmware version 1.3 or later. *3 To output motion pictures with 4K or higher, use an HDMI cable that has the HDMI logo on it, and that is described as "4K Compatible". For DC-S1H, S1R, S1, S5M2X, and S5M2, a Premium High Speed HDMI cable (Type A - Type A plug) is compatible. For DC-S5, a High Speed HDMI micro cable (Type D - Type A plug) is compatible. •The L-Mount Logo mark is a trademark or registered trademark of Leica Camera AG. •The SDXC/SDHC Memory Card can be used only if their logos are indicated on the equipment or in the operation manual. It cannot be used with equipment that supports only the SD Memory Card. •XQD is a trademark of Sony Corporation. •The CFexpress Ver2.0 Type B is a trademark licensed by the CompactFlash Association. •USB Type-C™ and USB-C™ are trademarks of USB Implementers Forum. •Confirm the operation information of compatible lenses at Customer Support <http://panasonic.jp/support/global/cs/dsc> [English]. •Batteries made by other companies which have been certified by Panasonic may be used with these units, but we offer no guarantee as to the quality, performance or safety of such batteries. •Exercise care when purchasing batteries. Many fake or imitation batteries have been found among those sold at unusually low prices and those which customers cannot check for themselves before purchasing. •Please confirm the latest information about batteries on the following website. <http://panasonic.jp/support/global/cs/info/battery.html> [English].