


Guideline for Installation -

- Installation of the Refrigerator should be **avoided at location subjected to heat or direct sunlight.**
- Installation of the Refrigerator should be **avoided at poorly ventilated locations.**
- Installation of the Refrigerator should be **avoided where the surface is instable & slanted.**
- Installation of the refrigerator should be at locations not allowing the power plug to be cleansed properly(Dust accumulation may cause a fire)
- Installation of the Refrigerator should be at **Gap of 10 cm or more at the back** of the refrigerator, **5 cm or more both left and right side** and **30 cm or more above** of the refrigerator.
- Fix the Adjustable leg of the refrigerator such that it reaches the floor to stabilize the refrigerator.
- After the refrigerator is set up allow it to cool its interiors for 4 Hrs. and **around 24 Hrs.** during summers and then start storing the items.



*For Service engineer reference



*For Service engineer reference