

Guideline for KNOB setting -


- During Summers, keep the Freezer setting at NORMAL and Refrigerator setting at 4 or 5.
- During monsoon, keep the Freezer setting at NORMAL and Refrigerator setting at 3 or 4.
- During winters, keep the Freezer setting at MAX and Refrigerator setting at 3 .
- For Humidity control of Vegetable Box –

1)To raise the humidity ,move the CAP shutter to Left.



*For Service engineer reference

2)To Lower the humidity ,move the Cap shutter to right.



*For Service engineer reference