


Elenco serie TV Panasonic compatibili con l'app **Digital Concert Hall**



OLED	LCD		PDP
JZ2000	JX940	GX942	ZT60
JZ1500	JX800	GX830	VT60
JZ1000	HX940	GX810	GT60
HZ2000	HX900	FX780	ST60
HZ1500	HX830	FX740	VT50
HZ1000	HX810	FX700	GT50
HZ980	HX700	FX633	ST50
GZ2000	HX600	FX623	UT50
GZ1500	HX580	FX613	XT50
GZ1000		FX550	
GZ960		FS503	
GZ950		EX780	
FZ950		EX703	
FZ800		EX633	
EZ1000		EX613	
EZ950		EX603	
		ES513	
		ES403	
		DX900	
		DX800	
		DX780	
		DX730	
		DXE720	
		DXM710	
		DX700	
		DX653	
		DX600	
		DS503	
		DS500	
		DS400	
		CZ950	
		CX800	
		CX750	

		CX740	
		CXW704	
		CX700	
		CXE720	
		CXM710	
		CX680	
		CS630	
		CS620	
		CS610	
		CS600	
		CS520	
		CS510	
		CS500	
		CSW504	
		CSW514	
		CSW524	
		CR850	
		CR730	
		CR433	
		CRW434	
		CXW414	
		CXW404	
		C320	
		AX900	
		AX800	
		AX630	
		AS800	
		AS750	
		AS740	
		AS650	
		ASM651	
		ASE650	
		AS640	
		AS600	
		AS520	
		AS500	
		WT600	
		WT60	
		DT60	
		FT60	
		EW5	
		EW6	
		BL6	
		ETW60	
		ET60	
		E6	

		WT50	
		DT50	
		ET50	
		ET5	
		E5	
		EWT5	