


ENGLISH

Panasonic®

Basic Operating Instructions Digital Camera

Model No. **DMC-SZ3**

Please read these instructions carefully before using this product, and save this manual for future use.




More detailed instructions on the operation of this camera are contained in "Operating Instructions for advanced features (PDF format)" in the supplied CD-ROM. Install it on your PC to read it.

-If you see this symbol-

Information on Disposal in other Countries outside the European Union

This symbol is only valid in the European Union. If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.



Panasonic Corporation

Web Site: <http://panasonic.net>

© Panasonic Corporation 2013

GN

VQT4S05
F 1212SM0

Limited Warranty (ONLY FOR AUSTRALIA)

Panasonic Warranty

- The product is warranted for 12 months from the date of purchase. Subject to the conditions of this warranty, Panasonic or its Authorized Service Centre will perform necessary service on the product without charge for parts or labour. In the opinion of Panasonic, the product is found to be faulty within the warranty period.
- Authorized Service Centres for Panasonic products purchased in Australia are sold by Panasonic Australia or its Authorized Distributors. Panasonic products purchased in Australia are sold by Panasonic Australia or its Authorized Distributors. Warranty cover only applies to service carried out by a Panasonic Authorized Service Centre and only if valid proof of purchase is presented when warranty services are requested.
- Recommendations (as noted in the operating instructions) under normal use and reasonable care (in the opinion of Panasonic), the warranty covers normal domestic use only and does not cover damage, breakdown, failure, deterioration, loss of data, abuse, mismanagement of customer content, misuse, supply problems, thunderstorm activity, reinstallation by insects or vermin, tampering or repair by unauthorised persons (including unauthorised business or rental use of the product, exposure to abnormally corrosive conditions or any foreign object or matter having entered the product).
- This warranty does not cover the following items unless the fault or defect existed at the time of purchase:
 - (a) DVD, Blu-ray or Recordable Discs
 - (b) Cabinet Parts
 - (c) SD cards or USB devices
 - (d) User replaceable Batteries
 - (e) DTV reception issues caused by TV Aerial / Cabling / Wall sockets)
- Some products may be supplied with Ethernet connection hardware. The warranty is limited on such products and will not cover:
 - (a) Network connections for the selected peripherals
 - (b) Access fees and/or charges incurred for internet connection
 - (c) The use of incompatible software or software not specifically stipulated in the product operations manual, connection to the internet or any other device.
- To purchase Panasonic, Customer Care Centres on 132600 or visit our website referred to below and use the Service Centre Locator for the name/address of the nearest Authorized Service Centre.
 - Information stored on Hard Disk Drive, USB stick or SD card
 - Receipt as a proof of purchase date. Please note that freight and insurance to and / or from your nearest Authorized Service Centre must be arranged by you.
 - The warranty does not cover the following products: the major metropolitan areas of Australia or the normal operating areas of the nearest Authorized Service Centres:
 - Perth, Adelaide, Darwin, Brisbane, Cairns, Gold Coast, Mackay, Melbourne, Newcastle, Sydney, Townsville
 - Perth, Adelaide, Darwin, Brisbane, Cairns, Gold Coast, Mackay, Melbourne, Newcastle, Sydney, Townsville
- The warranty does not cover the following items unless the fault or defect existed at the time of purchase, de-installation or re-installation of a product, including costs related to the mounting, de-mounting or re-mounting of any screen, and any other ancillary activities, delivery, handling, freight, transportation or insurance of the product, or any other ancillary activities, delivery, handling, freight, transportation or insurance of the product, or any other ancillary activities, delivery, handling, freight, transportation or insurance of the product, occurring by reason of, during, associated with, or related to such installation, de-installation, re-installation or transport.

Panasonic Authorized Service Centres are located in major metropolitan areas and most regional centres of Australia. For a list of service centres, please visit our website or contact our Customer Care Centre on 132600 or visit our website and use the Service Centre Locator. This warranty, Panasonic products come with consumer guarantees that extend to the product and elect to have a refund or to have the product repaired or if you wish you may elect to keep the goods and if the product fails to be of acceptable quality and the failure does not amount to a major failure. If there is a major failure in regard to the product which cannot be remedied then you must notify us within a reasonable period of time. If you wish to exercise your rights under the Australian Consumer Law, you must notify us within a reasonable period of time from receiving notice from you.

THIS WARRANTY CARD AND THE PURCHASE DOCKET (OR SIMILAR PROOF OF PURCHASE) SHOULD BE RETAINED BY THE CUSTOMER AT ALL TIMES

If you require assistance regarding warranty conditions or any other enquiries, please visit the **Panasonic Australia** website www.panasonic.com.au or contact by phone on **132 600** **If phoning in, please ensure you have your operating instructions available.**

Panasonic Australia Pty, Limited

ACN001592 197 ABN93001897187
1 Innovation Road, Macquarie Park, NSW 2113

PRO-G14-F11 Issue# 4.0 01-01-2011

Accessories

Check that all the accessories are supplied before using the camera. Product numbers correct as of January 2013. These may be subject to change.

Battery Pack (DMW-BCL7E)

USB Connection Cable (K1HY08YY0031)

Hand Strap (VFC4297)

CD-ROM (VFF-1135)

• Software

– PHOTOHUNTERSTUDIO 9.0 LE (Windows 8/7/Vista/XP)


– LoloScope 30 day full trial version (Windows 8/7/Vista/XP)

(This will only install a shortcut to the trial version download site.)

• Operating instructions for advanced features

• Consult the dealer or Panasonic if you lose the supplied accessories. (You can purchase the accessories separately.)

Preparations




Charging time

Approx. 150 min

Recording


• **Set the date and time before using the camera.**



Number of recordable pictures

Approx. 250 pictures

Playback



Specifications

Specifications are subject to change without notice.

Digital Camera: Information for your safety

Power Source:	DC 5 V
Power Consumption:	1.1 W (When recording) 0.6 W (When playing back)

Camera effective pixels	16,100,000 pixels
Image sensor	1/2.33" CCD, total pixel number 16,600,000 pixels, Primary colour filter
Lens	Optical 10x zoom, f=4.5 mm to 45 mm (35 mm film camera equivalent: 28 mm to 250 mm)/F3.1 (Wide) to F5.9 (Tele)
Image stabiliser	Optical method
Focus range	5 cm (Wide)/1.5 m (Tele) to ∞ (9 × is 2 m to ∞)
Shutter system	Normal/ Intelligent auto/ Motion picture
Shutter speed	Scene Mode
Exposure (AE)	There may be differences in the above settings.
Metering mode	Electronic shutter+ Mechanical shutter
LCD monitor	8 seconds to 1/1600th of a second (Starry Sky) Mode: 15 seconds, 30 seconds, 60 seconds Auto (Programme AE)
Microphone	Multiple
Speaker	2.7" TFT LCD (4:3) (Approx. 230,000 dots) (field of view ratio about 100%)
Recording media	Monaural
Recording file format	Monaural
Still Picture	Built-in Memory (Approx. 90 MB)/SD Memory Card/SDHC Memory Card/SDXC Memory Card
Motion pictures	JPEG (based on "Design rule for Camera File system", based on "Exif 2.3" standard)/DPOF corresponding
Interface	"QuickTime Motion JPEG" (motion pictures with audio)
Digital	"USB 2.0" (High Speed)
Analogue video	NTSC/PAL Composite (Switched by menu)
Audio	Audio line output (monaural)
Terminal	Audio line output (monaural)
Dimensions (excluding the projecting parts)	Dedicated Jack (8 pin) Approx. 94.8 mm (W) × 55.8 mm (H) × 21.9 mm (D)
Mass	Approx. 126 g (with card and battery) Approx. 111 g (excluding card and battery)
Operating temperature	0 °C to 40 °C
Operating humidity	10%RH to 80%RH

AC Adaptor (Panasonic VSK0776):

Information for your safety

Input:	~ 110 V to 240 V, 50/60 Hz, 0.2 A
Output:	--- 5 V, 800 mA

Battery Pack (lithium-ion) (Panasonic DMW-BCL7E):

Information for your safety

Voltage/capacity:	3.6 V/690 mAh
--------------------------	---------------