
LUMIX

S Series System Chart



^{*1} The AC Adaptor DMW-AC10 requires the DC coupler DMW-DCC16. The DC coupler DMW-DCC16 requires the AC Adaptor DMW-AC10. *2 "SDXC/SDHC Memory Card compatible with UHS Speed Class 3 [U3]" must be used when recording 4K video, 4K PHOTO, 6K PHOTO and High Speed Video in camera. *3 For [4K] video output, use an HDMI cable that has the HDMI logo on it, and that is described as "4K compatible". *The L-Mount Logo mark is a trademark or registered trademark of Leica Camera AG. *The SDXC/SDHC Memory Card can be used only if their logos are indicated on the equipment or in the operation manual. It cannot be used with equipment that supports only the SD Memory Card. *XDD is a trademark of Sony Corporation. *Confirm the operation information of compatible lenses at Customer Support http://panasonic.jp/support/global/cs/dsc [English]. **Batteries make be possible that the semantial batteries in the semantial batteries. **Exercise care when purchasing batteries. **Amy fake or unchasing batteries