


Panasonic®

Operating Instructions

Digital Wireless Stereo Earphones

Model No. **RP-BTS50**

 **Bluetooth®**



Manufactured by:
Panasonic Corporation
Kadoma, Osaka, Japan
Importer for Europe:
Panasonic Marketing Europe GmbH
Panasonic Testing Centre
Winsbergring 11, 22525 Hamburg, Germany



E

SQW0575

Dear customer

Thank you for purchasing this product. Please read these instructions carefully before using this product, and save this manual for future use.

Table of contents

Before use

Accessories	2
(Important) About water resistance.....	2
Part names	3

Preparation

Charging	3
Turning the power on/off	3
Connecting a Bluetooth® device	4
How to wear the earphones.....	4

Operation

Listening to music.....	5
Making a phone call.....	5
Useful functions	6

Other

Restoring to the factory settings	7
Copyright, etc.	7
Maintenance	7
Safety precautions.....	8
About Bluetooth®	9
Specifications	9
Troubleshooting guide	10
To remove the battery when disposing of this unit.....	11

Accessories

Please check and identify the supplied accessories.

- 1 USB charging cord
- 1 Carrying case
- 1 Earpieces set (L, S)

For the United Kingdom and Ireland customers

Sales and Support Information

Customer Communications Centre

- For customers within the U.K.:
0344 844 3899
- For customers within Ireland:
01289 8333
- Monday - Friday 9:00am - 5:00pm (Excluding public holidays).
- For further support on your product, please visit our website:
www.panasonic.co.uk

Direct Sales at Panasonic U.K.

- Order accessory and consumable items for your product with ease and confidence by phoning our Customer Communications Centre -
Monday - Friday 9:00am - 5:00pm (Excluding public holidays).
- Or go on line through our Internet Accessory ordering application at www.pas-europe.com
- Most major credit and debit cards accepted.
- All enquiries transactions and distribution facilities are provided directly by Panasonic U.K.
- It couldn't be simpler!
- Also available through our Internet is direct shopping for a wide range of finished products. Take a browse on our website for further details.

(Important) About water resistance

- Specifications for this unit are equivalent of IPX5 of IEC 60529.

■ About the IPX5 (liquid ingress protection level against water jet)

This unit is compatible to operate after water jet from nozzles approximately 12.5 L/min of room temperature tap water from every direction approximately 3 m from this unit for 3 minutes. Supplied USB charging cord is not water resistant.


Water resistance is not guaranteed under all conditions.

■ Cautions for using around water


Conform to following. Improper use may result in a malfunction.

- Securely close the USB lid.
- Do not open or close the USB lid with wet hands or when water droplets are on this unit. Doing so may cause malfunction such as terminal rusting with the water droplets.
- Do not connect and use a USB charging cord.
- Do not pour soap water or detergent, or immerse in water.
- Remove any hair, lint, sand, dust, etc., that may be attached to the rubber seal on the USB lid before closing.
- Leaving the device with water droplets in a cold region may result to malfunction such as the USB lid stuck closed.
- The sound may become smaller or distorted when water is accumulated in the earphones or microphone of this unit. Wipe this unit with dry soft cloth.
- When water enters inside this unit, stop using this unit, and contact the nearest Dealer or Service Centre. Malfunction due to exposure to water by improper handling by the customer will not be covered by the warranty. Supplied USB charging cord is not water resistant.


Part names



Right earphone



Remote controller



- ① Right earphone
- ② USB lid
- ③ Earpiece
- ④ Left earphone
- ⑤ Cord adjuster
- ⑥ Clip
- ⑦ Remote controller
- ⑧ LED illumination
- ⑨ LED indicator light*
 - The number of blinks or colour notifies the status of the unit. (* hereafter referred to as "LED")
- ⑩ Charging terminal (DC IN)
 - Open the USB lid and connect the USB charging cord (supplied) to this terminal when charging. (See "Charging")
- ⑪ Microphone
- ⑫ Volume +/Next
- ⑬ Power/Pairing/Play/Pause/Call ⓪
- ⑭ Volume -/Previous

■ Note

- Do not use any other USB charging cords except the supplied one.
- When using the unit, do not cover the right housing with the palm of your hand. The Bluetooth® connection may be blocked.

The product illustrations may differ from the actual product.


Charging

The rechargeable battery (installed in the unit) is not charged initially. Charge the battery before using the unit.

1 Connect this unit to a computer using the USB charging cord

- Within approximately 3 seconds after the connection is established, the LED on the right earphone will light in red.
- The LED lights in red when charging is in progress. When charging is completed, the LED will go out.
- Charging will take approximately 1.5 hours from empty state to fully charged. (Quick charging time for 70 minutes operation: Approx. 15 minutes)

Right earphone



■ Note


- The Bluetooth® feature cannot be used when this unit is connected to a computer using the USB charging cord.
- Charge in a room temperature between 10 °C and 35 °C. Outside of this range of temperatures, charging may stop.
- The power cannot be turned on while charging.
- Do not use any other USB charging cords except the supplied one.

Caution: Use only the supplied USB charging cord when connecting to a computer.

Turning the power on/off

1 Press and hold ⓪ for approximately 3 seconds

- A beep will sound and the LED on the right earphone will blink.



To turn the power off

- Press and hold ⓪ for approximately 3 seconds. A beep will sound and the power will be turned off.

■ Note

- When the unit is not operated for approximately 5 minutes, the power will automatically turn off. (See "Auto power off" (→ P. 6))

Connecting a Bluetooth® device

To establish a wireless connection, register the unit with Bluetooth® compatible devices.

Preparation on the Bluetooth® device

- Turn on the power, and enable the Bluetooth® feature.
- Place the device within 1 m from the unit.
- Check the device operation in its operation instructions, as required.

Power on for the first time

1 Turn on the unit

- The unit will start searching for the Bluetooth® device to connect to, and the LED on the right earphone will blink in blue and red alternately. (Only one operation after purchase)

2 When the unit ("RP-BTS50") is detected by the Bluetooth® device, select it

- The MAC address (e.g., 6C:5A:B5:B3:1D:0F) may be displayed before the device name is displayed.
- If prompted for a passkey, input "0000 (four zeros)".
- If the Bluetooth® profile selection screen appears, select the "A2DP" profile. If "A2DP" is not supported or if you want to just use phone calls, select the "HSP" or "HFP" profile. (For details on profiles, see "Listening to music" and "Making a phone call" (→ P. 5))

3 Check the connection with the Bluetooth® device on the unit

- First the LED on the right earphone lights in blue and repeats on and off. When the connection is established, blinking pattern will change.

Connection after the second time

<Connect the same Bluetooth® device>

When the unit is turned on, it will search for the previously setup Bluetooth® device and automatically start connecting to it. First the LED on the right earphone lights in blue and repeats on and off. When the connection is established, blinking pattern will change.

<Connect a different Bluetooth® device>


Disable the Bluetooth® feature on the previously connected device. Check that the unit is turned off. Press and hold **⏻** for approximately 5 seconds. A beep will sound. The unit will start searching for other Bluetooth® device. The LED on the right earphone will blink in blue and red alternately. Continue steps **2** and **3**.

■ Note

- If connection to a device is not established within approximately 5 minutes, the unit will be turned off. Start from step **1** again.
- 2 or more Bluetooth® devices cannot be connected to the unit at the same time.
- You can pair up to 8 devices with this unit. If a 9th device is paired, the device with the oldest connection will be replaced. To use it, pair it again.

How to wear the earphones

Check the sides (L and R), then wear the earphones from behind your neck and hook over both ears, and bend the clip to adjust. Move the cord adjuster towards the back of your head.



Adjusting the clips for your ears

Follow the steps below for the first time to ensure the most comfortable and secure fit.

1 Expand the clip by bending the clip away from the earphone



2 Place the earphone on your ear



3 Bend the clip around your ear



4 Adjust another earphone

■ Note

- M-size earpieces are attached at the time of purchase. If they are not the right size, replace them with S or L-size earpieces (supplied).

■ Attention

- Do not bend the clip more than necessary. The clip can not be adjusted if it is damaged.

Listening to music

If the Bluetooth® compatible device supports the “A2DP” and “AVRCP” Bluetooth® profiles, music can be played back with remote control operations on the unit.

- **A2DP** (Advanced Audio Distribution Profile): Transmits audio to the unit.
- **AVRCP** (Audio/Video Remote Control Profile): Allows remote control of the device using the unit.

1 Connect the Bluetooth® device and the unit (→ P. 4)

2 Select and play the music on the Bluetooth® device

- The selected music is output to the earphones of the unit.

Operating time of battery

Battery type	Operating time
Rechargeable battery (installed in the unit)	Approx. 6 hours

Operating time may be less depending on the operating conditions.

■ Attention

- The unit might leak sound depending on the volume level.
- When the volume is increased to near maximum level, music may sound distorted. Decrease the volume until the distortion is cleared.

Remote controlling

You can control the Bluetooth® device using the unit.


- Depending on Bluetooth® devices, some functions below do not work, or work differently via operation of the unit.

(Operation example)

Play/Pause/Call		
①	Press	Play/Pause/Call
	Press twice quickly	Reject the incoming call/ Switch the calling device

Previous/Next/Volume		
+	Press	Increase the volume
	Press and hold	Forward to the start of next track
-	Press	Decrease the volume
	Press and hold	Return to the start of current track

Remote controller



■ Note

- The volume can be adjusted in 15 levels. When the maximum or minimum volume is reached, a beep will sound.

Making a phone call

With Bluetooth® enabled phones (cell phones or smartphones) that support the “HSP” or “HFP” Bluetooth® profile, you can use the unit for phone calls.

• HSP (Headset Profile):

This profile can be used to receive monaural sounds and establish two-way communication using the microphone on the unit.

• HFP (Hands-Free Profile):

In addition to the HSP functions, this profile has the incoming and outgoing calls function.


1 Connect the Bluetooth® enabled phone and unit (→ P. 4)

2 When answering an incoming call

Press **⓪** on the unit and answer the call

- During an incoming call, ringtone will sound from the earphones and the LED will blink.
- (HFP only) To reject the incoming call, press **⓪** twice quickly until the ringtone stops.

Remote controller



3 Start talking

- The LED will repeatedly blink 2 times during a call.
- The volume can be adjusted during a phone call. For setting instructions, see "Remote controlling". (→ P. 5)

4 Press **⓪** to end the phone call

- A beep will sound.

■ Note

- There may be instances when hands free setting needs to be done on the Bluetooth® enabled phone.
- Depending on the Bluetooth® enabled phone, you may hear incoming and outgoing call ringtones of the phone from the unit.
- (HFP only) Press **⓪** twice quickly on the unit. The calling device will be switched between the Bluetooth® enabled phone and the unit.
- When the illumination lights are turned on, the LED indicator light will be turned off.

When making an outgoing call

Make an outgoing call on the Bluetooth® enabled phone

- Also refer to the operating manual for the Bluetooth® enabled phone.
- (Checking and operation steps on the unit are explained below)
- During an outgoing call, ringtone will sound from the earphones and the LED will blink.
 - To cancel the outgoing call, press **⓪**. A beep will sound.

Useful functions

LED illumination

The unit is equipped with the blue LED illumination lights on the right and left earphones. The LED illumination is off by factory default. It is set to off every time the unit is turned off.

To turn the lights on, press + and – simultaneously. To turn them off, press + and – simultaneously for approximately 3 seconds.

- When the battery level is getting low, the illumination lights will be turned off.
- When the illumination lights are turned on, the LED indicator light will be turned off.
- When the LED illumination is turned on, operating time will be shorter.

Resetting the unit

This unit can be reset when all operations are rejected. To reset the unit, connect the unit to a computer using the USB charging cord. All the previous operations will be cancelled. (The pairing device information will not be deleted.)

Auto power off

If the unit is silent for approximately 5 minutes and operations for Bluetooth® devices are idle during that period, a beep will sound and the power will be automatically turned off.

LED indicator light

When the battery level is low during use of the unit, the blue blinking LED on the right earphone will change to red. A beep will sound every 1 minute. When the battery runs out, the power will turn off.

Restoring to the factory settings

When you want to delete all pairing device information, etc., you can restore the unit to the factory settings (original settings upon purchase). Charge the battery before restoring the unit.

1 Press and hold  for approximately 5 seconds

- Start searching for Bluetooth® devices to connect.

2 Press and hold + and – for 5 seconds or more simultaneously while searching

- The LED will blink fast in blue. The unit will restore to the factory settings.

Copyright, etc.

- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Panasonic Corporation is under license.
Other trademarks and trade names are those of their respective owners.
- Other system names and product names appearing in this document are in general the registered trademarks or trademarks of the respective developer companies.
Note that the ™ mark and ® mark do not appear in this document.

Maintenance

Clean this unit with a dry and soft cloth.

- Do not use solvents including benzine, thinner, alcohol, kitchen detergent, a chemical wiper, etc. This might cause the exterior case to be deformed or the coating to come off.

Keeping the battery performance

- During the long period of disuse, full charge this unit once every 6 months to keep the battery performance.

Safety precautions



■ Unit

- Avoid using or placing this unit near sources of heat.
- Do not listen with this unit at high volume in places where you need to hear sounds from the surrounding environment for safety, such as at railroad crossings, and construction sites.
- Do not block the ventilation of this unit with items such as cloth for long periods of time while charging or while the power is on.

■ Earpieces

- Keep the earpieces out of reach of children to prevent swallowing.

■ Allergies

- Discontinue use if you experience discomfort with the earphones or any other parts that directly contact your skin.
- Continued use may cause rashes or other allergic reactions.

■ Precautions for listening with the Earphones

- Do not use your earphones at a high volume. Hearing experts advise against continuous extended play.
- If you experience a ringing in your ears, reduce volume or discontinue use.
- Do not use while operating a motorised vehicle. It may create a traffic hazard and is illegal in many areas.
- You should use extreme caution or temporarily discontinue use in potentially hazardous situations.

This unit may receive radio interference caused by mobile telephones during use. If such interference occurs, please increase separation between this unit and the mobile telephone.

This unit is intended for use in moderate and tropical climates.

Declaration of Conformity (DoC)

Hereby, "Panasonic Corporation" declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. Customers can download a copy of the original DoC to our R&TTE products from our DoC server:

<http://www.doc.panasonic.de>

Contact to Authorised Representative: Panasonic Marketing Europe GmbH, Panasonic Testing Centre, Winsbergring 11, 22525 Hamburg, Germany

For Singapore only

Complies with
IDA Standards
DB01017

For Thailand only

This telecommunication equipment conforms to NTC/NBTC technical requirement.

About Bluetooth®

Panasonic bears no responsibility for data and/or information that is compromised during a wireless transmission.

■ Frequency band used

This unit uses the 2.4 GHz frequency band.

■ Certification of this unit

- This unit conforms to frequency restrictions and has received certification based on frequency laws. Thus, a wireless permit is not necessary.
- The actions below are punishable by law in some countries:
 - Taking apart/modifying the unit.
 - Removing specification indications.

■ Restrictions of use

- Wireless transmission and/or usage with all Bluetooth® equipped devices is not guaranteed.
- All devices must conform to standards set by Bluetooth SIG, Inc.
- Depending on the specifications and settings of a device, it can fail to connect or some operations can be different.
- This system supports Bluetooth® security features. But depending on the operating environment and/or settings, this security may not be sufficient. Transmit data wirelessly to this system with caution.
- This system cannot transmit data to a Bluetooth® device.

■ Range of use

Use this unit at a maximum range of 10 m.

The range can decrease depending on the environment, obstacles or interference.

■ Interference from other devices

- This unit may not function properly and troubles such as noise and sound jumps may arise due to radio wave interference if this unit is located too close to other Bluetooth® devices or the devices that use the 2.4 GHz band.
- This unit may not function properly if radio waves from a nearby broadcasting station, etc. is too strong.

■ Intended usage

- This unit is for normal, general use only.
- Do not use this system near an equipment or in an environment that is sensitive to radio frequency interference (example: airports, hospitals, laboratories, etc).

Specifications

■ General

Power supply	DC 5 V, 500 mA (Internal battery: 3.7 V (Li-polymer 90 mAh))
Operating time*1 (SBC mode)	Approx. 6 hours
Charging time*2 (25 °C)	Approx. 1.5 hours
Charging temperature range	10 °C to 35 °C
Operating temperature range	0 °C to 40 °C
Operating humidity range	35%RH to 80%RH (no condensation)
Mass	Approx. 22 g
Water resistant	IPX5 equivalent

*1 It may be shorter depending on the operating conditions.

*2 Time taken to recharge from empty to full.

■ Bluetooth® section

Bluetooth® system specification	Ver. 4.1
Wireless equipment classification	Class 2 (2.5 mW)
Frequency band	2.4 GHz band FH-SS
Supported profiles	A2DP, AVRCP, HSP, HFP
Supported codec	SBC, AAC, aptX®
Operating distance	Up to 10 m

■ Speaker section

Driver units	12 mm
---------------------	-------

■ Terminal section

DC IN	DC 5 V, 500 mA
--------------	----------------

■ Microphone section

Type	Mono
-------------	------

■ Accessory section

USB charging cord	0.1 m
--------------------------	-------

● Specifications are subject to change without notice.

Troubleshooting guide

Before requesting service, make the following checks. If you are in doubt about some of the check points, or if the remedies indicated do not solve the problem, consult your dealer for instructions.

General

The unit does not respond

- Connect the unit to a computer using the USB charging cord. The unit will be reset. (→ P. 6)

Power supply and charging

Cannot charge the unit

- Make sure the computer is turned on and is not on standby or sleep mode.
- Is the USB port you are currently using working properly? If your computer has other USB ports, unplug the connector from its current port and plug it into one of the other ports.
- If the measures mentioned above are not applicable, unplug the USB charging cord and plug it in again.
- If the charge time and operating time become shortened, the battery may have run down. (Number of charging times of the installed battery: Approximately 300.)

LED does not light during charging / Charging takes longer

- Is the USB charging cord (supplied) connected firmly to the USB terminal of the computer? (→ P. 3)
- Make sure to charge in a room temperature between 10 °C and 35 °C.

The power does not turn on

- Is the unit being charged? The power cannot be turned on during charging. (→ P. 3)

Bluetooth® device connection

The device cannot be connected

- Delete the pairing information for this unit from the Bluetooth® device, then pair them again. (→ P. 4)

Sound and audio volume

No sound

- Make sure that the unit and the Bluetooth® device are connected correctly. (→ P. 4)
- Check if music is playing on the Bluetooth® device.
- Make sure that the unit is turned on and the volume is not set too low.
- Pair and connect the Bluetooth® device and the unit again. (→ P. 4)

Low volume

- Increase the volume of the unit. (→ P. 5)
- Increase the volume on the Bluetooth® device.

Sound from the device is cut off / Sound quality is bad


- Sound may be disrupted if signals are blocked. Do not fully cover this unit with the palm of your hand, etc.
- The device may be out of the 10 m communication range. Move the device closer to this unit.
- Remove any obstacle between this unit and the device.
- Switch off any wireless LAN device when not in use.
- A communication problem may arise if the battery is not fully charged. Charge the unit. (→ P. 3)

Phone calls

You cannot hear the other person

- Make sure that the unit and the Bluetooth® enabled phone are turned on.
- Check if the unit and the Bluetooth® enabled phone are connected. (→ P. 4)
- Check the audio settings of the Bluetooth® enabled phone. Switch the calling device to the unit if it is set to the Bluetooth® enabled phone. (→ P. 4)
- If the volume of the other person's voice is too low, increase the volume of both the unit and the Bluetooth® enabled phone.

To remove the battery when disposing of this unit



The following instructions are not intended for repairing purposes but for the disposal of this unit. This unit is not restorable once disassembled. When disposing of this unit, take out the battery installed in this unit and recycle it.

Danger

As the rechargeable battery is specifically for this product, do not use it for any other device.

Do not charge the removed battery.

- Do not heat or expose to flame.
 - Do not leave the battery(ies) in a car exposed to direct sunlight for a long period of time with doors and windows closed.
 - Do not pierce the battery with a nail, subject it to an impact, or dismantle or modify it.
 - Do not let the wires touch any other metal or each other.
 - Do not carry or store the battery with a necklace, hair pin, or the like.
- Doing so may cause the battery to generate heat, ignite, or rupture.

Warning

Do not place the removed battery, and other items within reach of infants.

Accidental swallowing of such an item may have an adverse effect on the body.

- In the event that you think such an item has been swallowed, consult a doctor immediately.

In the event of fluid leaking from the battery, take the following measure, and do not touch the fluid with bare hands.

Fluid entering into an eye may cause loss of eyesight.

- Wash the eye with water immediately without rubbing it, and then consult a doctor.
- Fluid getting on your body or clothes may cause inflammation of the skin or injury.
- Sufficiently rinse with clean water, and then consult a doctor.

A lithium-ion polymer rechargeable battery is built in to the left earphone. Please discard according to local regulations.

When disposing this product, disassemble properly by following the procedure, and remove the internal rechargeable battery.

- Disassemble after the battery runs out.
- When disposing of the battery, please contact your local authorities or dealer and ask for the correct method of disposal.

1 Hold the top of the left earphone (L), and put a straight-slot screwdriver (commercially available) under the upper cover (A)

- Make sure to keep fingers away from the tip of the screwdriver.
- Select a screwdriver to be large enough for a space under the upper cover.

2 Use the screwdriver for leverage, and push the upper cover (A) upward

- Be careful not to touch the battery with the screwdriver.

3 Hold the battery (B), and remove it

4 Pull off the battery (B) and separate it from the left earphone by cutting off the wires, one by one, with scissors

- Insulate the wire parts of the removed battery with cellophane tape.
- Do not damage or dismantle the battery.

Disposal of Old Equipment and Batteries
Only for European Union and countries with recycling systems



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries must not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points in accordance with your national legislation.

By disposing of them correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment.

For more information about collection and recycling, please contact your local municipality.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.



Note for the battery symbol (bottom symbol):

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.