

DMR-BWT850EB, DMR-BWT850EC

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Recorder
	[E] Model No.	DMR-BWT850
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.1 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.8 Watt
		Wired LAN : 0.9 Watt
		HDMI : 0.6 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	0.9 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-PWT655EB, DMR-PWT550EB

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Player/HDD Recorder
	[E] Model No.	DMR-PWT655, DMR-PWT550
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.1 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.8 Watt
		Wired LAN : 0.9 Watt
		HDMI : 0.6 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	180 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	180 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	0.8 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-EX97EB-K

English	[C] Manufacturer's name	Panasonic
	[D] Product type	DVD Recorder
	[E] Model No.	DMR-EX97
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.1 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	HDMI : 0.6 Watt
		n.a.
		240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	n.a.
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	n.a.
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-BST760AG, DMR-BST765AG

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Recorder
	[E] Model No.	DMR-BST760, DMR-BST765
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.2 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.4 Watt
		Wired LAN : 0.4 Watt
		HDMI : 0.2 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	1.0 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-BCT760AG, DMR-BCT760AG, DMR-BCT76ENK, DMR-BCT76ECK

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Recorder
	[E] Model No.	DMR-BCT760, DMR-BCT765, DMR-BCT76
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.2 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.8 Watt
		Wired LAN : 0.8 Watt
		HDMI : 0.6 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	1.0 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-UBS90EGK

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Recorder
	[E] Model No.	DMR-UBS90
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.3 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.5 Watt
		Wired LAN : 0.6 Watt
		HDMI : 0.3 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	2.0 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-UBC90EGK

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Recorder
	[E] Model No.	DMR-UBC90
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.3 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.9 Watt
		Wired LAN : 1.1 Watt
		HDMI : 0.7 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	2.0 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-UBS70EGK, DMR-UBS70EGS

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Recorder
	[E] Model No.	DMR-UBS70
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.3 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.5 Watt Wired LAN : 0.6 Watt HDMI : 0.3 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	2.0 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-UBC70EGK, DMR-UBC70EGS

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Recorder
	[E] Model No.	DMR-UBC70
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.3 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.9 Watt Wired LAN : 1.0 Watt HDMI : 0.7 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	2.0 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

DMR-UBT1EC-K

English	[C] Manufacturer's name	Panasonic
	[D] Product type	Blu-ray Disc Recorder
	[E] Model No.	DMR-UBT1
	[F] Power consumption in off mode (Watt or n.a.)	n.a.
	[G] Power consumption in standby mode (Watt or n.a.)	0.3 Watt
	[H] Power consumption in network standby mode(s) (Watt or n.a.)	Wireless LAN : 0.9 Watt
	[I] Default time to switch to off mode (minutes or n.a.)	n.a.
	[J] Default time to switch to standby mode (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[K] Default time to switch to networked standby mode(s) (minutes or n.a.)	240 minutes (20 minutes is inappropriate for the intended use.)
	[L] Power consumption in networked standby if all wired network ports are connected and all wireless network ports are activated (Watt or n.a.)	2.0 Watt
	[M] Guidance on how to activate and deactivate wireless network ports (See user manual or n.a.)	See online manual

Deutsch	[A] Ecodesign Informationen	[B] Verordnung (EU) 2023/826	[C] Name des Herstellers	[D] Produktart
	[E] Modell Nr.	[F] Leistungsaufnahme im Aus- Zustand [Watt oder nicht anwendbar]	[G] Leistungsaufnahme im Bereitschaftszustand [Watt oder nicht anwendbar]	
	[H] Leistungsaufnahme im vernetzten Bereitschaftszustand [Watt oder nicht anwendbar]		[I] Zeitdauer bis zum Aus- Zustand [Minuten oder nicht anwendbar]	
	[J] Zeitdauer bis zum Bereitschaftszustand [Minuten oder nicht anwendbar]	[K]Zeitdauer bis zum vernetzten Bereitschaftszustand [Minuten oder nicht anwendbar]		
	[L] Leistungsaufnahme im vernetzten Bereitschaftszustand, wenn alle drahtgebundenen Netzwerk-Ports mit dem Netzwerk verbunden und alle drahtlosen Netzwerk-Ports aktiviert sind [Watt oder nicht anwendbar]			
	[M] Hinweise zur Aktivierung und Deaktivierung drahtloser Netzwerk-Ports (siehe Bedienungsanleitung oder nicht anwendbar			
Nederlands	[A] Ecodesigninformatie	[B] Verordening (EU) 2023/826	[C] Naam van de fabrikant	[D] Producttype
	[E] Model-nr.	[F] Elektriciteitsverbruik in uit-stand (watt of n.v.t.)	[G] Elektriciteitsverbruik in stand-by-stand (watt of n.v.t.)	
	[H] Elektriciteitsverbruik in netwerkgebonden stand-by (watt of n.v.t.)		[I] Tijdsperiode tot overschakeling naar de uit-stand (minuten of n.v.t.)	
	[J] Tijdsperiode tot overschakeling naar de stand-by-stand (minuten of n.v.t.)	[K] Tijdsperiode tot overschakeling naar netwerkgebonden stand-by (minuten of n.v.t.)		
	[L] Elektriciteitsverbruik in netwerkgebonden stand-by wanneer alle bedrade netwerkpoorten verbonden zijn en alle draadloze netwerkpoorten geactiveerd zijn (watt of n.v.t.			
	[M] Leidraad in verband met het activeren en deactiveren van draadloze netwerkpoorten (Zie gebruikershandleiding of n.v.t.			
Français	[A] Informations sur l'écoconception	[B] Règlement (UE) 2023/826	[C] Nom du fabricant	[D] Type de produit
	[E] N°du modèle	[F] Consommation d'électricité en mode d'arrêt (Watt ou N.A.)	[G] Consommation d'électricité en mode de veille (Watt ou N.A.)	
	[H] Consommation d'électricité en mode(s) de veille avec maintien de la connexion au réseau (Watt ou N.A.		[I] Laps de temps pour passer en mode d'arrêt (minutes ou N.A.)	
	[J] Laps de temps pour passer en mode de veille (minutes ou N.A.)	[K] Laps de temps pour passer en mode(s) de veille avec maintien de la connexion au réseau (minutes ou N.A.		
	[L] Consommation d'électricité en veille avec maintien de la connexion au réseau si tous les ports réseau filaires sont connectés et tous les ports réseau sans fil sont activés (Watt ou N.A.			
	[M] Orientations sur l'activation et la désactivation des ports réseau sans fil (voir manuel de l'utilisateur ou N.A.)			
Svenska	[A] Ekodesigninformation	[B] Förordning (EU) 2023/826	[C] Tillverkarens namn	[D] Produktslag
	[E] Modellnr	[F] Effektförbrukning i frånläge (watt eller ej tillämpligt)	[G] Effektförbrukning i standbyläge (watt eller ej tillämpligt)	
	[H] Effektförbrukning i nätverksanslutet standbyläge (watt eller ej tillämpligt)		[I] Tidsperiod fram till frånläge (minuter eller ej tillämpligt)	
	[J] Tidsperiod fram till standbyläge (minuter eller ej tillämpligt)	[K] Tidsperiod fram till nätverksanslutet standbyläge (minuter eller ej tillämpligt)		
	[L] Effektförbrukning i nätverksanslutet standbyläge om alla fasta nätverksportar är anslutna och alla trådlösa nätverksportar är aktiverade (watt eller ej tillämpligt)			
	[M] Vägledning om hur man aktiverar och avaktiverar trådlösa nätverksportar (se bruksanvisning eller ej tillämpligt			
Norsk	[A] Ecodesign informasjon	[B] Forordning (EU) 2023/826	[C] Produsentens navn	[D] Produkttype
	[E] Modell nr.	[F] Effektopptak i av-tilstand [watt eller brukes ikke]	[G] Effektopptak i driftsberedskap [watt eller brukes ikke]	
	[H] Effektopptak i fornettet driftsberedskap [watt eller brukes ikke]		[I] Tidsvarighet inntil av-tilstand [minutter eller brukes ikke]	
	[J] Tidsvarighet til driftsberedskap [minutter eller brukes ikke]	[K] Tidsvarighet til fornettet driftsberedskap [minutter eller brukes ikke]		
	[L] Effektopptak i fornettet driftsberedskap, når alle ledningsbundede nettverksporter er forbundet med nettverket og alle trådløse netterksporter er aktiverte [watt eller brukes ikke			
	[M] Henvisninger for aktivering og deaktivering av trådløse nettverksporter (se bruksanvisning eller brukes ikke)			
Dansk	[A] Ecodesign-information	[B] Forordning (EU) 2023/826	[C] Producentens navn	[D] Produkttype
	[E] Model nr.	[F] Effektforbrug i slukket tilstand [watt eller ikke anvendelig]	[G] Effektforbrug i standbytilstand [watt eller ikke anvendelig]	
	[H] Effektorbrug i netværksforbundet standbytilstand [watt eller ikke anvendelig]		[I] Tidsinterval, efter hvilket udstyret slås over i slukket tilstand [minutter eller ikke anvendelig	
	[J] Tidsinterval, efter hvilket udstyret slås over i standbytilstand [minutter eller ikke anvenc	[K] Tidsinterval, efter hvilket udstyret slås over i netværksforbundet standbytilstand [minutter eller ikke anvendelig		
	[L] Effektforbruget i netværksforbundet standbytilstand, hvis alle kablede netværksporte er tilsluttet og alle trådløse netværksporte er aktiveret [watt eller ikke anvendelig			
	[M] Vejledning om, hvordan trådløse netværksporte aktiveres og deaktiveres (se brugervejledning eller ikke anvendelig)			
Italiano	[A] Informazioni progettazione ecocompatibile	[B] Regolamento (UE) 2023/826	[C] Nome del fabbricante	[D] Tipo di prodotto
	[E] Modello n.	[F] Consumo di energia elettrica in modo spento [Watt o non applicabile]	[G] Consumo di energia elettrica in modo stand-by [Watt o non applicabile]	
	[H] Consumo di energia elettrica dalla rete in modo stand-by [Watt o non applicabile		[I] Lasso di tempo fino al modo spento [minuti o non applicabile]	
	[J] Lasso di tempo fino al modo stand-by [minuti o non applicabile]	[K] Lasso di tempo fino al modo stand-by in rete [minuti o non applicabile]		
	[L] Consumo di energia elettrica dalla rete in modo stand-by quando tutte le porte di accesso alla rete cablata sono collegate e quando tutte le porte di accesso alla rete senza fili sono attivate [Watt o non applicabile			
	[M] Informazioni su come attivare e disattivare le porte della rete senza fili (si vedano le istruzioni per l'uso o non applicabile			
Suomi	[A] Ecodesign - tiedot	[B] Asetuksen (EU) 2023/826	[C] Valmistajan nimi	[D] Tuotelaji
	[E] Tyyppi nr.	[F] Tehonkulutus pois kytkettyssä tilassa [watti tai ei soveltuva]	[G] Verkkovalmiustilan tehonkulutus [minuutit tai ei soveltuva]	
	[H] Tehonkulutus verkkovalmiustilassa [watti tai ei soveltuva]		[I] Aikaväli pois-tilassa [minuutit tai ei soveltuva]	
	[J] Aikaväli valmiustilaan saakka [minuutit tai ei soveltuva]	[K] Aikaväli verkkovalmiustilaan saakka [minuutit tai ei soveltuva]		
	[L] Verkkovalmiustilan tehonkulutus, kun kaikki kiinteästi kytketyt verkkoportit on kytketty päälle ja kaikki langattomat verkkoportit on kytketty käyttöön [watti tai ei soveltuva			
	[M] Ohjeistus siitä, miten langattomat verkkoportit kytketään käyttöön tai poistetaan käytöstä [katso käyttöohje tai ei soveltuva]			