


U REMOTE CONTROLLER



- 1 LCD display for an easy overview of the operation status.
- 2 Power button.
- 3 Switch on nanoe™ mode to activate nanoe™ X and nanoe-G for air purification and deodorisation even when the air conditioner is switched off.
Activate Inside Cleaning function by turning off the air conditioner, and press nanoe™ button for more than 3 seconds to clean the inside of the air conditioner.
- 4 iAUTO-X cools your home with FAST COOLING and provides continuous comfort with SHOWER COOLING to avoid direct cooling. Reactivate faster cooling during stable temperature with a second press of the iAUTO-X button.
- 5 Press up or down to set the temperature.
- 6 Toggles between iAUTO-X, COOL and DRY setting mode.
- 7 Set the airflow direction.
- 8 Adjusts the FAN SPEED or QUIET mode so you can sleep comfortably at night.
- 9 Delays off timer with temperature control for better sleep.
- 10 Switch on the ECO Mode with A.I. Control to let you enjoy the comfort cooling with minimal energy waste.
- 11 Set the 24-hour Dual ON & OFF Timer.
- 12 Set the actual time [hour and minute].