


1. Installing the programme:


Run "Setup" to install video wall manager



2. Programme activation:




Programme would be run as trial ver. until user complete activation.



Activation key would be generated after programme successfully installed on PC.

Customer could find the activation key through accessing "Video Wall Manager" programme folder and find ZCM.text file.



Go to Function set >> Register

Please input activation key saved on "ZCM.txt" file and click register

