

Operating Instructions <Setup>


Wireless Speaker System Model No. SC-ALL2

Thank you for purchasing this product. Please read these instructions carefully before using this product, and save this manual for future use.

This manual contains quick set up information. More detailed instructions are contained in "Operating Instructions <Full version>" which can be downloaded at the bottom right links.



1 Connect




2 Turn On Unit



The network indicator starts blinking in blue and red.


After approximately 1 minute, it will blink in blue slowly.

If the blinking in blue does not start, perform a network reset (see below - Network Reset).




3 Configure with Smartphone/Tablet

Go to wireless settings on your smartphone or tablet.




Select "ALL2 [] [] [] [] [] []_AJ"※.

※ This can sometimes take 1 minute to appear.




NOTE: If this operation does not work correctly, please repeat it several times.

Name your device e.g. Kitchen, Lounge or whatever you would like it to appear.




NOTE: If this page is not automatically displayed, type "http://172.19.42.1/" into your internet browser URL address field.

Select your network. (enter password if needed)





NOTE: If you encounter an error message asking you to reconfigure your router to WPA2™ security, please refer to your router's manual or contact your service provider for instructions on how to do this.

Wait a few seconds and...



...you're connected!*

※ After a short wait, your smartphone/tablet should be automatically reconnected to your Wi-Fi® network. In case you are not reconnected automatically, please re-select your Wi-Fi network from the settings / Wi-Fi settings menu on your device.



The network indicator blinks in red for a few seconds, and then lights up solid blue when a network connection is established.

4 Download App


Download the free "Panasonic Music Streaming" app

iOS : App Store

Android : Google Play™



5 Stream your music



For details on the app, refer to the site below. (These sites are in English only.)

iOS : http://panasonic.jp/support/global/cs/audio/app/music_streaming/ios/

Android : http://panasonic.jp/support/global/cs/audio/app/music_streaming/android/

Network Reset

1 Touch and hold [NET] and [1] for more than 4 seconds, "... .." on the display will start blinking.

2 Touch [NET] within 10 seconds, the network indicator starts blinking blue/red.

Further Support


For Operating Instructions <Full version>, FAQs, video tutorials, or further help, please visit <http://panasonic.jp/support/global/cs/audio/ALL/index.html> (This site is in English only.)

Alternatively, scan the QR code.



Accessories

- 1 AC mains lead



Bluetooth® operations

Preparation

- Turn on the Bluetooth® feature of the device and place the device near this unit.

- Touch [Ⓚ].
- Select "SC-ALL2" from the Bluetooth® device's Bluetooth® menu.
- Start playback on the Bluetooth® device.

To restore the settings to the factory defaults

You need to perform a factory reset if you want to clear and reset the memory contents.


- If you want to restore the network settings, perform a network reset (see on the reverse - Network Reset).

- Touch and hold [⏻/⏪] for more than 4 seconds.

Top view



Display




- While still holding [⏻/⏪], touch and release [NET].

Top view



- During the reset process, "--:--" will be displayed.

Top view



Display



- The unit will turn off.

"--:--" appears and the reset is complete.

For further dedicated help, support and advice about your ALL Series product please visit:
<http://panasonic.jp/support/global/cs/audio/ALL/index.html>
 (This site is in English only.)

Precautions

WARNING

Unit

- To reduce the risk of fire, electric shock or product damage,
 - Do not expose this unit to rain, moisture, dripping or splashing.
 - Do not place objects filled with liquids, such as vases, on this unit.
 - Use only the recommended accessories.
 - Do not remove covers.
 - Do not repair this unit by yourself. Refer servicing to qualified service personnel.
 - Do not let metal objects fall inside this unit.
 - Do not place any item on top of this unit.

AC mains lead

- To reduce the risk of fire, electric shock or product damage,
 - Ensure that the power supply voltage corresponds to the voltage printed on this unit.
 - Insert the mains plug fully into the socket outlet.
 - Do not pull, bend, or place heavy items on the lead.
 - Do not handle the plug with wet hands.
 - Hold onto the mains plug body when disconnecting the plug.
 - Do not use a damaged mains plug or socket outlet.
- The mains plug is the disconnecting device.
 Install this unit so that the mains plug can be unplugged from the socket outlet immediately.

CAUTION

Unit

- Do not place sources of naked flames, such as lighted candles, on this unit.
- This unit may receive radio interference caused by mobile telephones during use. If such interference occurs, please increase separation between this unit and the mobile telephone.
- This unit is intended for use in moderate climates.

Placement

- Place this unit on an even surface.
- To reduce the risk of fire, electric shock or product damage,
 - Do not install or place this unit in a bookcase, built-in cabinet or in another confined space. Ensure this unit is well ventilated.
 - Do not obstruct this unit's ventilation openings with newspapers, tablecloths, curtains, and similar items.
 - Do not expose this unit to direct sunlight, high temperatures, high humidity, and excessive vibration.

AC mains lead

- Do not use AC mains lead with other equipment.

Product Identification Marking is located on the bottom of the unit.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Panasonic Corporation is under license. Other trademarks and trade names are those of their respective owners.



The Wi-Fi CERTIFIED™ Logo is a certification mark of Wi-Fi Alliance®. The Wi-Fi Protected Setup™ Identifier mark is a certification mark of Wi-Fi Alliance®. "Wi-Fi" is a registered trademark of Wi-Fi Alliance®. "Wi-Fi Protected Setup™", "WPA™", and "WPA2™" are trademarks of Wi-Fi Alliance®.

Google Play and Android are trademarks of Google Inc.

App Store is a service mark of Apple Inc.

All other trademarks are trademarks of their respective owners.

This product incorporates the following software:

- the software developed independently by or for Panasonic Corporation,
- the software owned by third party and licensed to Panasonic Corporation,
- the software licensed under the GNU General Public License, Version 2.0 (GPL V2.0),
- the software licensed under the GNU LESSER General Public License, Version 2.1 (LGPL V2.1), and/or
- open source software other than the software licensed under the GPL V2.0 and/or LGPL V2.1.

The software categorized as (3) - (5) are distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY, without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. Please refer to the detailed terms and conditions thereof shown in our website below.

http://panasonic.jp/support/global/cs/audio/oss/all8_3_1c.html

At least three (3) years from delivery of this product, Panasonic will give to any third party who contacts us at the contact information provided below, for a charge no more than our cost of physically performing source code distribution, a complete machine-readable copy of the corresponding source code covered under GPL V2.0, LGPL V2.1 or the other licenses with the obligation to do so, as well as the respective copyright notice thereof.

Contact Information: oss-cd-request@gg.jp.panasonic.com

The source code and the copyright notice are also available for free in our website below.

<http://panasonic.net/avc/oss/>

Panasonic Warranty

- The product is warranted for 12 months from the date of purchase. Subject to the conditions of this warranty Panasonic or its Authorised Service Centre will perform necessary repair on the product without charge for parts or labour, if in the opinion of Panasonic, the product is found to be faulty within the warranty period.
- This warranty only applies to Panasonic products purchased in Australia and sold by Panasonic Australia or its Authorised Distributors or Dealers and only where the products are used and serviced within Australia or its territories. Warranty cover only applies to service carried out by a Panasonic Authorised Service Centre and only if valid proof of purchase is presented when warranty service is requested.
- This warranty only applies if the product has been installed and used in accordance with the manufacturer's recommendations (as noted in the operating instructions) under normal use and reasonable care (in the opinion of Panasonic). The warranty covers normal domestic use only and does not cover damage, malfunction or failure resulting from use of incorrect voltages, incorrect installation, accident, misuse, neglect, build-up of dirt or dust, abuse, maladjustment of customer controls, mains supply problems, thunderstorm activity, installation by insects or vermin, tampering or repair by unauthorised persons (including unauthorised alterations), introduction of sand, humidity or liquids, commercial use such as hotel, office, restaurant, or other business or rental use of the product, exposure to abnormally corrosive conditions or any foreign object or matter having entered the product.
- This warranty does not cover the following items unless the fault or defect existed at the time of purchase:
 - Cabinet Part(s)
 - Video or Audio Tapes
 - SD cards or USB devices
 - User replaceable Batteries
 - DVD, Blu-ray or Recordable Discs
 - Video / Audio Heads from wear and tear in normal use
 - Information stored on Hard Disk Drive, USB stick or SD card
 - DTV reception issues caused by TV Aerial / Cabling / Wall socket(s) etc
- Some products may be supplied with Ethernet connection hardware. The warranty is limited on such products and will not cover:
 - Internet and or DLNA connection / setup related problems
 - Access fees and or charges incurred for internet connection
 - The use of incompatible software or software not specifically stipulated in the product operations manual; and
 - Any indirect or consequential costs associated with the incorrect use or misuse of the hardware, its connection to the internet or any other device.
- To claim warranty service, when required, you should:
 - Telephone Panasonic's Customer Care Centre on 132600 or visit our website referred to below and use the Service Centre Locator for the name/address of the nearest Authorised Service Centre.
 - Send or take the product to a Panasonic Authorised Service Centre together with your proof of purchase receipt as a proof of purchase date. Please note that freight and insurance to and / or from your nearest Authorised Service Centre must be arranged by you.
 - Note that home or pick-up/delivery service is available for the following products in the major metropolitan areas of Australia or the normal operating areas of the nearest Authorised Service Centres:
 - Plasma/LCD televisions / displays (screen size greater than 103 cm)
- The warranties hereby conferred do not extend to, and exclude, any costs associated with the installation, de-installation or re-installation of a product, including costs related to the mounting, de-mounting or re-mounting of any screen, (and any other ancillary activities), delivery, handling, freight, transportation or insurance of the product or any part thereof or replacement of and do not extend to, and exclude, any damage or loss occurring by reason of, during, associated with, or related to such installation, de-installation, re-installation or transit.

Panasonic Authorised Service Centres are located in major metropolitan areas and most regional centres of Australia, however, coverage will vary dependant on product. For advice on exact Authorised Service Centre locations for your product, please telephone our Customer Care Centre on 132600 or visit our website and use the Service Centre Locator.

In addition to your rights under this warranty, Panasonic products come with consumer guarantees that cannot be excluded under the Australian Consumer Law. If there is a major failure with the product, you can reject the product and elect to have a refund or to have the product replaced or if you wish you may elect to keep the goods and be compensated for the drop in value of the goods. You are also entitled to have the product repaired or replaced if the product fails to be of acceptable quality and the failure does not amount to a major failure.

If there is a major failure in regard to the product which cannot be remedied then you must notify us within a reasonable period by contacting the Panasonic Customer Care Centre. If the failure in the product is not a major failure then Panasonic may choose to repair or replace the product and will do so in a reasonable period of time from receiving notice from you.

THIS WARRANTY CARD AND THE PURCHASE DOCKET (OR SIMILAR PROOF OF PURCHASE) SHOULD BE RETAINED BY THE CUSTOMER AT ALL TIMES

If you require assistance regarding warranty conditions or any other enquiries, please visit the **Panasonic Australia** website www.panasonic.com.au or contact by phone on **132 600** *If phoning in, please ensure you have your operating instructions available.*

Panasonic Australia Pty, Limited

ACN 001 592 187 ABN 83 001 592 187
 1 Innovation Road, Macquarie Park NSW 2113

PRO-031-F11 Issue: 4.0

01-01-2011

Panasonic Corporation



Web Site: <http://www.panasonic.com>

© Panasonic Corporation 2015

