

Panasonic®

Installation Guide

Home Network System Motion Sensor

Model No. **KX-HNS102AZ**



Thank you for purchasing a Panasonic product.

This document explains how to install the motion sensor properly.
For details about how to use the system, refer to the User's Guide
(page 15).

Please read this document before using the unit and save it for future
reference.

Table of Contents

Introduction

Accessory information3

Important Information

About this system4

For your safety4

Important safety instructions5

For best performance5

Other information6

Setup

Part names and functions7

LED indicator7

Setup overview7

Inserting the batteries8

Registering the motion
sensor8

Information about sensor
features9

Confirming the usage area11

Wall mounting12

Appendix

Testing the motion sensor15

Adjusting the sensor
sensitivity15

Features available when using the
[Home Network] app15

Accessing the User's Guide15

Specifications16

Warranty (for New Zealand)17

Accessory information

Supplied accessories

No.	Accessory item/Part number	Quantity
①	Batteries*1	2
②	Wall mounting adaptor*2	1
③	Wall mounting screws (25 mm)	2

*1 When replacing batteries, see "Power source" of "Specifications", page 16 for battery information.

*2 The motion sensor can be wall mounted with or without the wall mounting adaptor (page 12).



Other information

- Design and specifications are subject to change without notice.
- The illustrations in these instructions may vary slightly from the actual product.

Trademarks

- iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries.
- Android is a trademark of Google Inc.
- Microsoft, Windows, and Internet Explorer are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- All other trademarks identified herein are the property of their respective owners.

Important Information

About this system

- This system is an auxiliary system; it is not designed to provide complete protection from property loss. Panasonic will not be held responsible in the event that property loss occurs while this system is in operation.
- The system's wireless features are subject to interference, therefore functionality in all situations cannot be guaranteed. Panasonic will not be held responsible for injury or damage to property that occurs in the event of wireless communication error or failure.

For your safety

To prevent severe injury and loss of life/property, read this section carefully before using the product to ensure proper and safe operation of your product.

WARNING

Power connection

- Use only the power source marked on the product.
- Do not connect non-specified devices.

Installation

- To prevent the risk of fire or electrical shock, do not expose the product to rain or any type of moisture.
- Do not place or use this product near automatically controlled

devices such as automatic doors and fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.

- Keep small parts (screws, etc.) out of the reach of children. There is a risk of swallowing. In the event they are swallowed, seek medical advice immediately.
- It is advised not to use the equipment at a refuelling point. Users are reminded to observe restrictions on the use of radio equipment in fuel depots, chemical plants or where blasting operations are in progress.

Operating safeguards

- Do not disassemble the product.

Medical

- Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids, to determine if they are adequately shielded from external RF (radio frequency) energy. DECT features operate between 1.88 GHz and 1.90 GHz with a peak transmission power of 250 mW.
- Do not use the product in health care facilities if any regulations posted in the area instruct you not to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

